


NASA Tech Briefs

Official Publication of the
National Aeronautics and
Space Administration
January 1993 Vol 17 No. 1

Transferring Engineering
Technology to Over 200,000
Qualified Readers Throughout
Industry and Government



Andrew's Aftermath

Ask six questions before purchasing a borescopic measuring system...

1. Is it accurate and repeatable?
2. Can it measure on curved surfaces?
3. Can it measure objects at any orientation?
4. Is it easy to use and learn?
5. Can it be used with all existing scopes?
6. Is it compact, rugged, and portable?

Wire-frame CAD model of turbine blade on IW-1 screen automatically conforms to digitized image of blade for measurement with new Olympus 3-D borescopic measurement system, despite blade orientation.

Only Olympus measuring systems answer YES!

Our new 3-D borescopic measuring system is the most accurate and repeatable of any system available today. It measures on curved surfaces (for example turbine blades) at any orientation or distance. It's easy to learn and easy to use.

And it works with any type or make of fiberscope, borescope, or video scope. No need to buy new, dedicated instruments. Use your existing inventory.

The Olympus 3-D measuring system is compact, rugged, and portable. It utilizes new, patented software resident in the computerized Olympus Video Analyzer, IW-1.



It's based on CAD principles and is a snap to use. You'll like the image management capabilities you get too: complete image storage and instant retrieval, text, enhancement, comparison, transmission.


Ask these six questions before purchasing and ask us for more information. We back our answers up!

Call 1-800-446-5260 or write.
Olympus Corporation, Industrial Fiberoptics Division,
4 Nevada Drive, Lake Success, NY 11042-1179

For Immediate Attention Circle No. 334


For Literature Circle No. 335

OLYMPUS
INDUSTRIAL



IMAGINE...3D MODELING IN WINDOWS!

Introducing Autodesk 3D Concepts



The unique Rotation Cube lets you turn objects to any angle.

Whether you're designing mechanical parts, planning urban facilities, or creating electronics packaging, you can visualize your ideas more quickly and with greater accuracy if you model your designs as three dimensional objects. And now there's a product that lets you do just that. Quickly. And affordably.

Autodesk 3D Concepts™ for Windows™ is a unique new software program that lets you create wire frames and surface render the models to give your design a realistic appearance. Autodesk 3D Concepts is extraordinarily easy to use, thanks to its innovative tool set and its familiar Windows menus and commands.

Here are a few of the features that make Autodesk 3D Concepts unique:

- ▶ *Rotation Cube lets you view objects from any angle*
- ▶ *Ground Plane for visual reference*


- ▶ *Sculpting Tool for shaping surfaces*
- ▶ *Perspective and Isometric Views*
- ▶ *Light Source Shading*
- ▶ *Works with AutoCAD .DXF and Generic CADD*
- ▶ *Transfers to other Windows programs*

If you want to cut your time from concept to production, look into Autodesk 3D Concepts. In fact, if you own another 3D modeling package, you can get Autodesk 3D Concepts for Windows for just \$129. For details on this limited time offer, call Autodesk Retail Products at (800) 228-3601 and ask for InfoPak A46.

 **AUTODESK**

For More Information Circle No. 504

THE ALL NEW ASTRO-MED MONITOR & RECORD



- No Delay...see full traces on monitor while recording!
- Personal Chart Setups with on-board floppy drive
- Data Capture...up to 32 megabytes in RAM; 120 megabyte internal hard drive; stream to external drive via SCSI
- 8 to 32 Waveform Channels...plus 64 events; DC to 20 kHz; chart speeds to 500 mm/sec
- Laser Printer Chart Resolution...300 dpi; clear, crisp traces

Put simply, the MT95K2 is another major Astro-Med innovation in "chart recording": you can preview your

data, record it, store it, play it back, send it to disk for analysis, record it again, and more! Whether you need basic 8 channel recorder or a sophisticated 32 channel recording system, the MT95K2 is the perfect platform for you today.

Call, Fax, or write for details!

Astro-Med, Inc.

Astro-Med Industrial Park, West Warwick, Rhode Island 02893
Phone: (401) 828-4000 • Toll Free (800) 343-4039
Fax (401) 822-2430 • Telex 710-382-6409


Sales and Service Centers in London, Paris, Frankfurt and Milan

The First Revolution in Instrumentation Software...


Graphical Programming

The Second Revolution...


Platform Independence



LabVIEW for Windows



LabVIEW for Sun



LabVIEW for Macintosh

Over six years ago, LabVIEW® for Macintosh revolutionized the development of data acquisition, instrument control, and data analysis systems. No longer did you have to write text-based programs. With LabVIEW, you could graphically build virtual instruments (VIs) with front panel interfaces and block diagram programs. But, you had to have a Macintosh...

Introducing LabVIEW for Windows and LabVIEW for Sun. Now you can choose from three industry-leading computing platforms – control your GPIB, VXI, and RS-232 instruments – acquire data from your plug-in data acquisition boards – and perform data analysis, from simple statistics to real-time digital signal processing. Best of all, you're not locked into one computer platform. All of your programs are portable between platforms.

If you're searching for an alternative to text-based programming, or considering another icon-based system – try the original, try LabVIEW – and draw your own solution!

For a **FREE** LabVIEW Demo Disk, call:

(512) 794-0100 or
(800) 433-3488 [U.S. and Canada]



6504 Bridge Point Parkway
Austin, TX 78730-5039
Fax: (512) 794-8411

For More Information Circle No. 681

Branch Offices: Australia 03 879 9422 • Belgium 02 757 00 20 • Canada 519 622 9310 • Denmark 45 76 73 22 • Finland 00 524566 • France 1 48 65 33 70 • Germany 089 714 50 93 • Italy 02 48301892
Japan 03 3788 1921 • Netherlands 01720 45761 • Norway 03 846866 • Spain 91 896 0675 • Sweden 08 984970 • Switzerland 056 27 00 20 • U.K. 0635 523545

© Copyright 1992 National Instruments Corporation. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.

See us at Nepcon West, booth 4722 See us at Southcon, booth 2007



BRING US YOUR MEANEST, TOUGHEST, DIRTIEST.

Get the muscle to tame all your signal conditioning problems with system friendly Precision 6000.

HP, LP, BP, notch, TD and amps all programmably friendly.

As many as 128 channels.

Frequencies to 2MHz.

Typical match of 0.25°

and 0.25%. Differential

input, gain, monitor, zero

suppress. Go/no-go end-to-

end cal, plus diagnostics. Group configuration. Frequency-band translators. Friendly computer control. Status and other reports.



System Friendly

Sense/control other devices with buffered I/Os. Customize with Proto-cards. Control the flow with programmable switch matrix. The choice is all yours, and you can change as requirements change.

Throw our book at your tough guys.

Call. Fax. Or write. Ask for our brochure and our videotape.




PRECISION FILTERS, INC.

240 Cherry Street, Ithaca, New York 14850
607-277-3550

Fax: 607-277-4466

For More Information Circle No. 415



Reduce Your Design Time in No Time

Call (800) 344-2571 for your *free* video

Department A191

Easy to learn.

Face it: time is money. The less time you spend learning CAD software the more time you can spend making money. With Ashlar Vellum's Drafting Assistant you'll be producing professional quality drawings in about two hours. Lines, arcs, NURB splines, symbols, and many more design tools are just a click away. Plus, Ashlar Vellum's on-screen tool coach will prompt you exactly how to use each tool you select.

Gets work done faster.

Ashlar Vellum's Drafting Assistant completely automates the process of finding endpoints, tangencies, intersections and any other logical constraint. You're done in a fraction of the time it takes by hand or with other CAD packages. In fact, the Drafting Assistant is so unique that it has been issued a patent by the U.S. Patent Office (PAT. No. 5,123,087). Plus, Ashlar Vellum comes with DXF and IGES translators built-in so you can share files with other CAD systems fast.

Gives you all the design tools you need.

With over 20 smart design tools, built-in parametrics, 3D wireframe construction, mechanism animation, 8 editing tools, a text tool that will support any installed font, 9 different ways to pan and zoom, fill patterns like steel, aluminum, rubber, glass and over a dozen more and free toll-free technical support, you will find all the tools you need. Plus, you get an extensive symbol library of fasteners, slots, holes and more, that can be automatically resized and placed into a drawing. Call now for more information on Ashlar Vellum (800) 344-2571.

"the only way to fully appreciate Ashlar Vellum is to sit down and use it; tackle a tough job, right off."

Burt Rutan

Inventor, Engineer - Designer of the Voyager aircraft

"we use Vellum to do complete drawings... what used to take weeks now only takes a couple of days."

Michael "Bake" Riebeek

Designer, Engineer, Builder

Ashlar Vellum®

Reduce Your Design Time in No Time™

Ashlar Incorporated • 1290 Oakmead Parkway • Sunnyvale • CA • 94086 • (800) 877-2745

System Requirements: Macintosh system 6.0.2 or greater (system 7 compatible), SE/30, Mac II family or Quadra, 4MB RAM. **IBM and compatibles** - 386 or 486, Microsoft Windows 3.0 or greater, 4MB RAM, mouse. Ashlar Vellum 2D \$1,995, Ashlar Vellum 3D \$2,495 (Ashlar Vellum 3D available for Macintosh only, prices subject to change). Trial versions, videos and data sheets are available, just ask your salesman. To place an order or speak with a sales person, call (800) 877-2745.

© 1992 Ashlar Incorporated. Ashlar and Vellum are registered trademarks of Ashlar Incorporated. Reduces Your Design Time In No Time is a trademark of Ashlar Incorporated. Other brands and product names are trademarks of their respective holders.

For More Information Circle No. 530

Contents

NASA Tech Briefs

Transferring Engineering Technology to
Over 200,000 Qualified Readers
Throughout Industry and Government

FEATURES

- 12 Editorial Notebook
- 12 Letter Writing Contest Winners
- 14 Mission Accomplished
- 69 NASA Software Update

TECHNICAL SECTION

22 Special Focus: Test and Measurement



This section marks the debut of a new monthly tech briefs section called "Special Focus" covering additional areas you, our readers, have told us are important to your work. Look for upcoming sections on communications, CAD, optoelectronics, composites, and other fields that complement our ten regular sections.

- 22 Compact Raman Spectrometers Would Detect Hydrogen
- 22 Test-Signal Generator for SNR Calibration
- 28 X-Ray and Acoustic Measurements Yield Stiffnesses
- 30 Noncontact Measurement of Shaft Speed, Torque, and Power
- 36 Pressure-Coupled Acoustic-Transducer Assembly
- 36 Measuring Deflections of Propeller and Fan Blades
- 40 Machine Tests Optical Fibers in Flexure

42 Electronic Components and Circuits



- 42 Dummy Cell Would Improve Performance of Fuel-Cell Stack
- 42 Low-Crosstalk Composite Optical Crosspoint Switches
- 44 Improved Grid-Array Millimeter-Wave Amplifier
- 46 High-Temperature-Superconductor Films in Microwave Circuits

48 Electronic Systems



- 48 Robot Avoids Collisions With Obstacles
- 48 Interface for MIL-STD-1553B Data Bus
- 50 Voice-Recognition System Records Inspection Data
- 54 Demonstration AOTF Imaging Spectrometer




Photo courtesy Lewis Research Center

NASA Lewis researchers are investigating ways to incorporate high-temperature superconducting (HTS) materials into microwave circuits. The photo above shows a technique for depositing an HTS thin-film on a microwave substrate. This technology has the potential to reduce electrical losses in such components as ring resonators, filters, transmission lines, phase shifters, and feed lines in phased-array antennas. See the report on page 46.

- 55 Differential Interferometry for Spacecraft Navigation
- 55 Effects of Environmental Electrical Charges on Spacecraft
- 56 More About Laser Scanner Tests for Single-Event Upsets
- 56 Telemetry Tests of the Advanced Receiver II
- 57 Development of Infrared Imager for Spacelab

58 Physical Sciences



- 58 Mapping Temperatures on Heat Pipes
- 60 Degree of Development of Waves and Bias in Radar Altimetry
- 60 Calorimetric Vacuum Emissometry at 773 to 923 K

62 Materials



- 62 Improved Composite Flexible Blanket Insulation
- 64 Poly(1,2,4-Triazoles) Via Aromatic Nucleophilic Displacement
- 65 Research on Bi-Based High-Temperature Superconductors
- 66 Electrochemical Impedance Spectroscopy of Metal Alloys

(Continued on page 8)



Honey, I shrunk the recorder.

Gould shrinks the best of recording systems into a space not much bigger than this page. Introducing the TA11 Recording-System Portable. The first system that brings 4, 8 or 16 channels of conditioning, monitoring, capturing, storing, recording and communicating down to a portable size. At a very economical price.



Measuring just 14"W x 16"D x 7³/₈"H and weighing approximately 28 lbs., the rugged TA11 features built-in, programmable signal conditioning suitable for most of your industrial applications, plus a unique 11" chart.

For More Information Circle No. 418

For easy operation, we've included traditional, push-button recorder controls for basic functions. A flip-up LCD panel with proven touchscreen technology provides straightforward setup and control of advanced functions. It also minimizes paper waste by allowing you to set up and monitor traces without running the chart. And because it displays in real time, you can work more efficiently, viewing slow-changing signals as they occur.

The TA11 takes flexibility even further with multi-channel, logical OR triggering for capturing transients. It also offers two levels of waveform capture memory for up to 8MS of total memory. Allocate it to all 16 channels, and

you can have up to 512kS per channel. And for storing data and setups, there's a built-in RAM card.

Once again, Gould puts its expertise to work for you, condensing high-performance recording system capabilities to create a whole new class of instruments. Starting at under \$10,000. Call Gould at (216) 328-7000 for details, or for immediate response, complete the FAST ACTION FAX and send it today.

**\$1000
Value FREE!**

Place your order for the TA11 before April 30, 1993 and take \$1000 off the unit price, or off any Gould product or supplies ordered at the same time. Offer not applicable with other discounts.

FAST ACTION FAX (216) 328-7400

Yes!

- ☐ Have a Gould Representative call me to arrange a demonstration
- ☐ Rush me a free TA11 technical brochure
- ☐ I'm interested in Gould's convenient rent-to-own plan

(Please print)

Name: _____

Title: _____

Company: _____

Street: _____

City: _____ State: _____ Zip: _____

Telephone: (_____) _____

FAX or mail coupon/photocopy (you may affix business card) to Gould Inc., Test and Measurement Group, 8333 Rockside Road, Valley View, OH 44125.

Contents *(continued)*

67 Computer Programs



- 67 Simulating the SSF Information System
- 68 Analyzing Stresses in Orthotropic Materials

70 Mechanics



- 70 Self-Damping Sprung Wheel
- 71 Viscous/Inviscid Interaction on an Oscillating Airfoil
- 72 Lightweight Right-Angle Valve for Cryogenics
- 72 Disk Valve for Cryogenics
- 73 Measuring Tollmien-Schlichting Instabilities in Laminar Flow
- 74 Single-Tip Probe Senses Pressure or Temperature
- 75 Fail-Safe Pressure Plug
- 75 Six-Degree-Of-Freedom Magnetic Vibration Isolator

77 Machinery



- 77 Robot Would Reconfigure Modular Equipment

78 Fabrication Technology



- 78 More About the Farley Three-Dimensional Braider
- 79 Apparatus Splits Glass Tubes Longitudinally
- 80 Adjustable Bracket for Entry of Welding Wire
- 81 Separation of Metals Bonded With Two-Sided Tape

82 Mathematics and Information Sciences



- 82 Advancing-Front Algorithm for Delaunay Triangulation
- 83 Algorithm for Enlargement of Digitized Images
- 84 Elements of Theory of Multidimensional Complex Variables




Photo courtesy Kennedy Space Center

Kennedy Space Center has developed a plant growth system (pictured above) that conserves water by supplying nutrient solution to seedling roots only as needed. The invention may have applications in arid environments.

88 Life Sciences



- 88 Monolithic Continuous-Flow Bioreactors
- 89 Water-Conserving Plant-Growth System
- 90 Isotonic and Isokinetic Exercise During Bed Rest
- 91 Temperature Affects Fatty Acids in *Methylococcus Capsulatus*

ABP **BPA**

DEPARTMENTS

New Product Ideas	18
NASA TU Services	20
New on the Market	92
New Literature	95
Subject Index	98
Advertisers Index	99

on the cover:

Images such as this one taken just days after Hurricane Andrew swept through southern Florida played an important role in the state's post-disaster assessment. The images, precise enough to calculate damage to individual buildings, were captured by Stennis Space Center aircraft equipped with NASA-developed remote sensing technology. Turn to Mission Accomplished, page 14.

Photo courtesy Stennis Space Center

This document was prepared under the sponsorship of the National Aeronautics and Space Administration. Neither Associated Business Publications Co., Ltd. nor anyone acting on behalf of Associated Business Publications Co., Ltd. nor the United States Government nor any person acting on behalf of the United States Government assumes any liability resulting from the use of the information contained in this document, or warrants that such use will be free from privately owned rights. The U.S. Government does not endorse any commercial product, process, or activity identified in this publication.

Permissions: Authorization to photocopy items for internal or personal use, or the internal or personal use of specific clients, is granted by Associated Business Publications, provided that the flat fee of \$3.00 per copy is paid directly to the Copyright Clearance Center (21 Congress St., Salem, MA 01970). For those organizations that have been granted a photocopy license by CCC, a separate system of payment has been arranged. The fee code for users of the Transactional Reporting Service is: ISSN 0145-319X/92 \$3.00+.00

NASA Tech Briefs, ISSN 0145-319X, USPS 750-070, copyright © 1993 in U.S., is published monthly by Associated Business Publications Co., Ltd., 41 E. 42nd St., New York, NY 10017-5391. The copyrighted information does not include the (U. S. rights to) individual tech briefs which are supplied by NASA. Editorial, sales, production and circulation offices at 41 East 42nd Street, New York, NY 10017-5391. Subscription for non-qualified subscribers in the U.S., Panama Canal Zone, and Puerto Rico, \$75.00 for 1 year; \$125.00 for 2 years; \$200.00 for 3 years. Single copies \$10.00. Foreign subscriptions one-year U.S. Funds \$150.00. Remit by check, draft, postal, express orders or VISA, MasterCard, and American Express. Other remittances at sender's risk. Address all communications for subscriptions or circulation to NASA Tech Briefs, 41 East 42nd Street, New York, NY 10017-5391. Second-class postage paid at New York, NY and additional mailing offices.

POSTMASTER: please send address changes to NASA Tech Briefs, 41 E. 42nd Street, Suite 921, New York, NY 10017-5391.


EASY5^x.

It gives you the power to visualize complex problems
the way you want to see them.

Model documented
via user-defined icons.

Motif[®]-based graphical
user interface.

Wide variety of non-linear
and linear analyses.



Nested "submodels"
simplify large models.

User-supplied code integral
to block diagram.

Continuous and multi-rate
sampled-data components.

Almost all engineering analysis software works fairly well on nickle-and-dime problems. But when it comes to really difficult jobs, you run into a lot of limitations.

EASY5x is different.

It gives you the ability to look at big, complex problems. You can use it to model, simulate, and analyze virtually any type or size of dynamic system—even sampled-data control systems.

Easily build your own components.


With EASY5x's open architecture, you can create your own application-specific components. Then store them, reuse them, and share them with other engineers.

Or, you can use any of our 195 modeling components.


These standard "building blocks" will help you efficiently model dynamic effects or physical systems. Including tricky problems like friction and hysteresis, or two-phase refrigeration cycles.

Concentrate on the problem, not the software.

EASY5x gives you unparalleled flexibility. Yet it's easy to learn and simple to use.



Non-linear simulation results viewed interactively or off-line.



Frequency-response data displayed in Bode, Nichols, or Nyquist formats.

The X Window[®]-based graphical interface lets you work on engineering workstations without forcing you to learn special commands.

And when your problem becomes complex enough for speed to be important, EASY5x is an order of magnitude faster than our competitors' software. You can even run your analyses on a supercomputer.

Designed by engineers for engineers.

EASY5x wasn't created in an academic setting. It was developed, tested, and refined at Boeing, one of the world's leading aerospace companies.

Altogether, in fact, more than 2,700 Boeing engineers have used EASY5x. And the software has logged more than a million man-hours designing the airplanes you fly. But that's only the beginning.

Because thousands of other engineers and students worldwide are using EASY5x to model and analyze electrical, mechanical, hydraulic, pneumatic, thermal, and chemical systems. And they're applying their findings to the aerospace and automotive industries. Plus robotics, heavy equipment, nuclear power, and environmental control.

Try EASY5x for free.

All things considered, EASY5x is the best value on the market. And we'd like to prove it to you.

Call us for a free, 30-day trial offer. Phone 1-800-426-1443 or FAX to 206-865-2966. Or write to Boeing, P.O. Box 24346, MS 7L-46, Seattle, WA 98124-0346.

BOEING

For More Information Circle No. 497

The Link Between Computer Graphics and Video



RGB/Videolink® 1600U

The only scan converter to offer
both video taping and high quality
video projection

- Adjustment free auto-locking to all workstations, PCs and Mac IIs
- Interlaced and non-interlaced inputs
- Pan, scroll and zoom
- Flicker-free output
- Video overlay capability
- Full 24 bit color
- Genlock
- RS-232 control
- Broadcast quality NTSC/PAL composite video S-Video, RGB RS-170/EBU, Y, R-Y, B-Y
- RGB 31.5 kHz for video projection
- Other models from \$10,995



SPECTRUM®

950 Marina Village Parkway Alameda, CA 94501
Tel: (510) 814-7000 Fax: (510) 814-7026

NASA Tech Briefs

Official Publication of
National Aeronautics and
Space Administration



NASA Tech Briefs:

Published by **Associated Business Publications**
Editor-in-Chief/Publisher **Bill Schnirring**
Associate Publisher/Editor **Joseph T. Pramberger**
Managing Editor **R.J. Laer**
Associate Editor **Sarah L. Gall**
Technical Advisor **Dr. Robert E. Waterman**
Production Manager **Rita Nothaft**
Traffic Manager **James E. Cobb**
Art Director **Pierre Granier**
Marketing Director **Wayne Pierce**
Advertising Coordinator **Nipa Joshi**
Telecommunications Specialist **Evelyn Mars**
Reader Service Manager **Scott Floman**

Briefs & Supporting Literature:

Provided to National Aeronautics and Space Administration by
International Computers & Telecommunications, Inc.
NY, NY with assistance from **Logical Technical Services, NY, NY**
Technical/Managing Editor **Ted Selinsky**
Art Director **Luis Martinez**
Administrator **Elizabeth Teixeira**
Chief Copy Editor **Lorne Bullen**
Staff Writers/Editors **Dr. James Boyd, Dr. Larry Grunberger,**
Dr. Theron Cole, Jordan Randjelovich,
George Watson, Oden Browne
Graphics **Zinaida Gimpeleva, Vernald Gillman,**
Pamela Baynham, Charles Sammartano
Editorial & Production **Bill Little, Ivonne Valdes,**
Susan Kyu Oh, Frank Ponce

NASA:

NASA Tech Briefs are provided by the National Aeronautics and Space Administration, Technology Transfer Division, Washington, DC:
Administrator **Daniel S. Goldin**
Assistant Administrator for Commercial Programs **John G. Mannix**
Deputy Assistant Administrator(Programs) **Frank E. Penaranda**
Deputy Director Technology Transfer Division (Publications Manager) **Leonard A. Ault**
Manager, Technology Transfer Office, NASA Center For AeroSpace Information **Walter M. Heiland**

Associated Business Publications

41 East 42nd Street, Suite 921, New York, NY 10017-5391
(212) 490-3999 FAX (212) 986-7864
President **Bill Schnirring**
Executive Vice President **Frank Nothaft**
Vice President/Chief Operating Officer **Domenic A. Mucchetti**
Operations Manager **Rita Nothaft**
Controller **Felecia Lahey**
Trade Show Director **Wendy S. Janiel**
Systems Analyst **Patrick Wolfert**

Advertising:

New York Office: (212) 490-3999 FAX (212) 986-7864

Account Executives:

NY, NJ, OH, MI **Brian Clerkin**
at (201) 366-2751
NJ (Area Codes 201 and 908) **Debby Crane**
at (201) 967-9838
PA, DE, NJ (Area Code 609) **Tara Morie**
at (215) 640-3118
VA, DC, MD, WV **John D. Floyd, CBC**
at (215) 399-3265
Eastern MA, NH, ME, RI **Paul Gillespie**
at (508) 429-8907; **Bill Doucette** at (508) 429-9861
Western MA, CT, VT **George Watts**
at (413) 253-9881
West Central, Southeast, Southwest **Douglas Shaller**
at (212) 490-3999
Midwest—IL, WI **Paul Leshner, CBC**
at (312) 296-2040
MN **David Haggett**
at (708) 934-9123
Northwest—WA, OR **Bill Hague**
at (206) 858-7575
West Coast—CA, AZ, NV, NM, UT **Stillman Group**
at (310) 372-2744
for Area Codes 602/702/505/818/805: **Paul Sanacore**
for 310/619/714: **Robert D'Alexander**
for 408/415/916/209/707/801: **Tom Stillman**

NTBM-Research Center

Account Supervisor **Lourdes Del Valle**

CFD Bulletin

REPORTING ON FIDAP—THE INDUSTRY STANDARD IN CFD SOFTWARE


ANNOUNCING FIDAP 7.0

A MAJOR NEW RELEASE FROM FDI THAT SOLVES MORE CFD PROBLEMS MORE EASILY.

FIDAP 7.0 combines increased problem solving capabilities with a new, intuitive, graphical pre-processor. These significant enhancements make FIDAP an even more proficient ally in helping the serious engineer solve an expanding array of CFD problems.

A NEW, EASY-TO-USE PRE-PROCESSOR.

- Interactive model building
- Interactive mesh generation
- Interactive data input
- Interactive graphical display of results



COMPREHENSIVE PROBLEM SOLVING CAPABILITIES.

- Incompressible and subsonic compressible flow
- Single-phase and two-phase flow
- Laminar & turbulent flow
- Chemically reacting flow
- Newtonian and viscoelastic fluids
- Conduction, convection, and radiation
- Free surfaces and interfaces
- Phase change

Learn how today's industry standard in CFD software has just become tomorrow's. For more information about FIDAP 7.0, call or write today.



FLUID
DYNAMICS
INTERNATIONAL

500 Davis Street, Suite 600
Evanston, IL 60201
Tel: 708-491-0200, Fax: 708-869-6495

For More Information Circle No. 391



Editorial Notebook

We're delighted to announce the winners of the 1992 Letter Writing Contest. A lot's been written about the lack of interest in science, math, and engineering among American children, and deservedly so, in my opinion. Less than half of the graduate engineering students at American universities are Americans and, unlike in previous eras, fewer and fewer foreign students elect to remain here after graduation. We're educating almost everyone but ourselves—and today's temporary "glut" in the engineering job market, thanks to corporate downsizing and a slow economy, doesn't mean we aren't facing a future famine. We are.

But you needn't worry about the winner of both the grand prize and children's prize in the contest, according to our Associate Editor, Sarah Gall. When Sarah called to notify eleven-year-old Adam Gulley that he'd won, she first spoke to his dad, an electrical engineer who confessed that he used to be a reader of *NASA Tech Briefs*. Now he's a reader of what Adam thinks are the most interesting tech briefs to share with his dad...because Adam gets *NASA Tech Briefs* first and marks the good parts. Adam saw the column in *NASA Tech Briefs* announcing the contest and entered himself, with no prodding from his dad. Indeed, Adam's brother Aron, age 9, also entered.

The adult winner, ceramic engineer Diane Folz, was as excited about winning as Adam, Sarah reported, and equally as eager to go to Space Camp. It is this kind of enthusiasm that needs to be communicated to our elected officials. As Mark Hopkins of Spacecause (the contest judges) pointed out, though the contest is over, the need to write, call, or fax Congress and the executive branch remains as exigent as ever.

Please, if you haven't written, do so now. Your future, your children's future, and the future of the country depend upon it. I hope you enjoy the following letters as much as we did...they've inspired *me* to get back at the keyboard and bang out some more letters.

Bill Schnirring

Bill Schnirring

THE WINNERS: THE TOP LETTERS IN SUPPORT OF THE US SPACE PROGRAM

Grand Prize and Children's Winner

Adam Q. Gulley, Cleveland Heights, OH

Dear Representative Stokes:


May I ask you to support the space station Freedom? It could serve as a laboratory for learning how to use the microgravity of space, making possible the materials which would help us all. Maybe we could even discover new ways of improving parts on cars. I'm sure you remember that before the space program, we didn't have very long mileage tires for cars. Now we do. Satellites help us talk to people and watch TV all over the world. If it wasn't for the space program, we wouldn't have these technologies.

Freedom could help us answer many questions and problems. We may find cures for terrible diseases that scare us such as AIDS, cancer, leukemia, and Alzheimer's.

It has been estimated that the space station Freedom program will employ more than 70,000 people in at least 40 states. These jobs will contribute new ideas, new knowledge, and new products to our economy. Perhaps even I will be among those employed because of space station Freedom. I hope to do something in the field of space someday. But I still have a lot of studying to do.

So please, Mr. Stokes, support the space station Freedom.

Sincerely,
Adam Q. Gulley



Adam Gulley, 11, is schooled at home by his mother, Mildred. His father Dan, an electrical engineer, describes Adam and his younger brother Aron as "space nuts" who have both dreamed of going to the US Space Camp. Adam has won a tuition-free stay at the camp, and the family hopes to send Aron as well.

Adult Prize Winner

Diane C. Folz, Gainesville, FL

Dear Senator Gore:

In the economic and political climate of our country today, we can hardly justify giving up the tremendous driving force behind a major portion of our commercial successes. Over the past 12 years, we have allowed foreign competitors to walk away with billions of dollars worth of enabling technologies. Weakening the space program will undermine one of our few remaining opportunities to regain our competitive posture in the global marketplace.

There are those who espouse that "sending money into outer space is ludicrous when people are starving in our cities." However, creation of new products, medical advances, environmental technologies, and the host of vital new materials developed as part of the space program will have far-reaching effects that will increase the quality of life for **ALL** citizens.

There is little doubt that humankind is at best when reaching beyond perceived limitations to achieve the "impossible." Economic security is a by-product of scientific adventure. Can we really afford to suppress technological pioneers? Can we afford to wave off the opportunity for our children to experience the wonder of exploration? What an empty legacy ... what a message of hopelessness ... how much less than our parents left us.

A sincerely concerned citizen,
Diane C. Folz



Diane Folz, 34, is a ceramic engineer working at the University of Florida in Gainesville, from which she received her BS in materials science and engineering in 1987. She currently is president of the American Ceramic Society, Florida section, and secretary treasurer of the National Institute of Ceramic Engineers. She has won a tuition-free stay at the US Space Camp.

We would like to award honorable mentions to the following letter-writers and to thank everyone who participated in the contest:

Michael Alessio, Bakersfield, CA
Georgia Anderson, Memphis, TN
Mark Armstrong, Seattle, WA
Lisa Atzman, Rego Park, NY
Philip Barnes-Roberts, Altadena, CA
Gene A. Barton, Carson City, NV
Thomas R. Belden, New Vienna, OH
Brian Blake, Woburn, MA
Don Bloese, Riverside, CA
Michael M. Boyle, Elk Grove, CA
Dale Brackman, Helena, MT
Olin Brown, Lynnfield, MA
Becky Brunette, Green Bay, WI
Amy Michele Burns, Landrum, SC
Michael Burrell, Tacoma, WA
Joseph C. Cain, Tallahassee, FL
Robert L. Campbell, Poway, CA
Barrie Carlson, Phoenix, OR
Paul Cartwright, So. St. Paul, MN
Norman F. Chance II, Indianapolis, IN
David Cherne, Harbor Springs, MI
Cherilyn Chin, Oakland, CA
William F. Clapp, Stratham, NH
Judith G. Clark, Cottage Grove, OR
Henry B. Classe, Fort Smith, AK
Carolynn Lee Conley, Houston, TX
Norman L. Cook, Monrovia, CA
Kathleen Cortese, Burbank, CA
Jessica C. Crandell, Ridgecrest, CA
Alison Daigle, Hoover, AL
Jared M. Dame, Ridgecrest, CA
Darrick K. Dean, New Castle, PA
Natalie Deans, Hoover, AL
Paul DeGeorge, Valley Stream, NY
Connie Dishong, Sherman, TX
Kyson Dominguez, Hoover, AL
Renee Durette, Merritt Island, FL

Leslie Esbeck, Inverness, FL
K. Evezych, Kitteridge, CO
Mary Fedde, Huntsville, AL
Ronald M. Fish, White Plains, NY
W.G. Foerster, Kiel, WI
Roland A. Foulkes, Gainesville, FL
Floyd Fowler, Severn, MD
Richard & Cheryl Ann Ganci, Minnetonka, MN
Dr. & Mrs. Charles A. Gaston, Poughkeepsie, NY
Michael Dean Gibson, Long Beach, CA
Mike Girdwood, Perth, ONT Canada
Robert Graham, Huntington Beach, CA
Herbert Greenberg, Springfield, NJ
Aron C. Guley, Cleveland Heights, OH
Jemma Harbaugh, Caraopolis, PA
Dian L. Hardison, NASA
Luise Heitz, Greenlawn, NY
Blake Herring, Birmingham, AL
Alfred C. Hexter, Ph.D., Kensington, CA
Frank L. Hicks, Jr., Park City, UT
Arthur Horbach, Doylestown, PA
Jennifer Jager, Harrisonburg, VA
Michael J. Jaski, Elk Grove Village, IL
Joshua S. Johnson, Dubois, WY
John A. Jossy, Union City, CA
M.S. Kaminaka, Arroyo Grande, CA
Carl F. Knoll, Jr., Allentown, NJ
Erich Kring, Washington, MI
Darrell H. Lack, LaCrescent, MN
Tony Laricica, Erie, PA
Amanda Lavender, Birmingham, AL
Jamie Lennon, North Plainfield, NJ
Ilia Linka, Cambridge, ONT Canada
Steve Lovoy, Birmingham, AL
Richard G. Lugar, Washington, DC

Laureen Macko, Charlotte, NC
Frederick Marich, San Mateo, CA
Ian S. Martin, Holland Patent, NY
Jimmy Martin, Hoover, AL
Jessica Ashleigh-Thorne Matthews, USAF Academy, CO
Ken Montanye, Butler, NJ
Michael R. Morehouse, Anaheim, CA
William J. Naivar Jr., Lithia Springs, GA
Abbas Naqvi, Birmingham, AL
Sarah K. Noble, Big Lake, MN
Chet Novak, Simsbury, CT
Dennis J. O'Neill, Pembroke, MA
Chris O'Quier, Mt. Vernon, OH
Mike Otis, Aberdeen, SD
Patrick Paolone, Birmingham, AL
Ronald Peck, St. Petersburg, FL
Glenn & Susan Petrie, Bartlett, IL
Mary Pfifer, Mt. Vernon, OH
Linda L. Williford Pifer, Ph.D., Memphis, TN
Daniel Pinkoski, Harker Heights, TX
Charles Poirier
Pattie R., Mimbres, NM
Nancy Ralston, Tequesta, FL
Elizabeth D. Ray, Corona, CA
Gary Rice, Albany, IN
Robert G. Roberts, Newington, CT
Heidi Robinson, Stonington, CT
Susan K. Rawson, Simi Valley, CA
William David Rice Jr., Vero Beach, FL
George M. Ruby, Des Moines, IA
Steve Russell
Henry Salisbury, Chula Vista, CA
Michelle Santoro, Hoover, AL
David Schwartz, Susanville, CA
Paul S. Shanley, Auburn, AL

David Shapiro, Colmar Manor, MD
Brent Sherwood, Huntsville, AL
Barbara L. Sieg, San Jose, CA
Amy J. Simpson, Yonkers, NY
Robert Sorenson, Berwyn, IL
Steven A. Sousa, Hyde Park, MA
Kristen Spangler, Lewisberry, PA
Wayne Spencer, Suffolk, VA
Juanita Starr, Soldotna, AK
Kyle Stewart, Birmingham, AL
David Strain, Higbee, MO
Juston L. Stratemeyer, Metropolis, IL
Rema Summers, Smithfield, NC
Joseph S. Swartz, Alta Loma, CA
John Tait, Kennewick, WA
Chas. B. Kaloli Taliferro, Hawaii City, Hawaii
Steven Tauber
Robert A. Taylor, St. James, NY
Samuel Dale Theller
Ashley Thigpen, Birmingham, AL
Philip Mitchell Torrance III, Spokane, WA
Philip W. Tracey, Cupertino, CA
Wade Trimm, Hoover, AL
Corrina Tuemp-Nishi, Vancouver, BC, Canada
Julie Twardowski, Wilmington, DE
David Uneel
Donna T. Weeks, Bakersfield, CA
Marc Weiss, Edison, NJ
Mark Westphal, Yardley, PA
A. Wilson
Meredith Wilson, Hoover, AL
Jeni Wozniak, Flushing, MI
Antoinette S. Zabala, San Jose, CA

Mission **A**ccomplished

Through the technology transfer process, many of the systems, methods, and products pioneered by NASA are reapplied in the private sector, obviating duplicate research and making a broad range of new products and services available to the public.

Flying swiftly in the wakes of hurricanes Andrew and Iniki, NASA aircraft captured images of destruction vital to accurate damage assessment.

Shortly after Hurricane Andrew had bypassed NASA's Stennis Space Center to the north this past August, the

Mississippi facility received appeals from Florida to collect images for post-disaster assessment along the storm's path. Aircraft loaded with remote sensing technology and cameras arrived in Florida on August 28, four days after Andrew's initial strike. Images, first of

urban areas and then natural environments, were collected August 29-31.

"We provided the first assessment of actual dollar losses on a house-by-house basis," said Bruce Davis, mission pilot and a geographer at Stennis. "Most importantly, we responded quickly—this information is highly perishable because people start cleaning up immediately."

A week later, Florida's governor Lawton Chiles incorporated photographs and digital images captured by the Stennis crew into a briefing packet presented to the US Congress and state legislature. With the support of the images, according to Davis, the governor was able to secure adequate disaster relief funding for his state.

The digital data was acquired by the Calibrated Airborne Multispectral Scanner (CAMS), developed at Stennis for Earth observation. CAMS is a nine-channel scanning spectroradiometer with spectral bands that mimic those on the Landsat thematic mapper. The equipment was flown aboard a Lear 23 jet that also carried a 9" x 9" metric aerial camera.


The Florida images also can aid in assessing the storm-resistance of buildings and roads with an eye toward amending construction codes. Those that are digital easily can be integrated with existing land use planning, flood, and utility maps.

"There's definitely a role for NASA to play in disaster assessment," said Davis. "We have the equipment, expertise, and remote sensing technology to provide useful data to state governments, the Federal Emergency Management Agency, the National Parks Service, and other organizations."

CAMS also is being investigated for commercial uses such as market analysis in the telecommunications industry. The Earth Observation Commercial Applications Program, which establishes one-to-three year joint ventures between Stennis and industrial partners, provides a means to integrate the technology into a business environment.

In February, Stennis will expand its remote sensing capabilities with a new instrument called ATLAS (Airborne Thermal/visible Land Applications Scan-

NASA Tech Briefs, January 1993



NASA-developed remote sensing technology captured images of Florida after Hurricane Andrew (see detail above) which, when compared with images taken prior to the storm (see below), enabled lawmakers to assess losses on a precise, building-by-building basis.



THE ONLY TAPE DRIVE THAT PUTS 25GB ON A SINGLE 8MM TAPE.



Do you wish you could find a backup system with enough capacity, speed, and sophistication to backup unattended?

Could you recreate a document from scratch in the time it takes you to restore it?

FAST BACKUP, FAST RESTORE.

Introducing the CY-8500, the 8mm tape

drive that gives you up to 25 GB on a single tape. And with transfer rates of up to 90 MB per minute, backup takes less time, frees resources, and makes frequent backup simple and convenient.

And that's not all. The CY-8500 offers fast file search capability. So you get the advantages of high capacity and

fast transfer rates plus the ability to locate and restore your files quickly – about 75 times faster than normal speed.

CONFIGURATION FLEXIBILITY.

The state-of-the-art liquid crystal display gives you complete drive status information.

Command under execution, transfer rate, tape remaining, and ECC are presented in a clear easy-to-read format. By offering such features as data compression – for five times the storage capacity per tape – and data encryption – giving you data access control – the CY-8500 adapts to your company's growing needs. We'll adapt to your site requirements

too, with rack mounting options and cable lengths of up to 80 feet.

PROVEN TECHNOLOGY.

Best of all, the CY-8500 offers peace of mind. 8mm helical scan technology, designed for data recording, gives you demonstrated performance and reliability. Not an adaptation of an audio recording format.

The CY-8500 is part of a complete family of tape backup products that range in capacity from the 250 MB ¼" cartridge streamer to the 3 TB cartridge handling system. All backed up by our in-house technical support group and 12-month warranty. For more information on how you can enjoy the best value in tape backup, call today at 804/873-9000.

CONTEMPORARY
CYBERNETICS
Group

TRUE "PLUG-AND-PLAY" COMPATIBILITY WITH:

Alliant	HP	PC 386/ix
Alpha Micro	IBM AS/400	PC MS-DOS
Altos	IBM	PC Xenix/
Apollo	Mainframe	Unix
Arix	IBM RISC/6000	Pertec
AT&T	IBM RT	Plexus
Basic-4	IBM S/38	Prime
Concurrent	ICL	Pyramid
Convergent	Intergraph	Sequent
DataGeneral	Motorola	Silicon
DEC 3100/5000	Macintosh	Graphics
DEC BI-Bus	McDonnell	Stratus
DEC DSSI	Douglas	Sun
DEC HSC	NCR	Texas
DEC Q-Bus	NeXT	Instruments
DEC TU/TA81	Novell	Unisys
DEC Unibus	OS/2	Wang
Gould/Encore	PS/2	and more

For More Information Circle No. 322

Rock Landing Corporate Center · 11846 Rock Landing, Newport News, VA 23606 · 804/873-9000 · FAX 804/873-8836

Masterflex® EASY-LOAD® PUMP HEADS



**QUICK, EASY
& COST EFFICIENT**

Easy-Load® pump heads are EASY!



OPEN



SHUT

EASY to maintain...

Change tubing for fast pump cleanup.
Chemical resistant housings/rotors.

EASY to change flow rates...

Each pump head accepts several sizes
of tubing. Flow ranges from
0.06 ml/min to 13 LPM.

EASY to stack for multichannel pumping...

Change tubing without dismantling pump.

EASY on your budget...

Affordably priced with a
2 year warranty.

**Enjoy the benefits of a
high value, low-cost
Masterflex system!**

Get the complete story in
the 128-page *Masterflex
Reference Book*. Send for
your **FREE** copy today.

FREE!



Cole-Parmer® Instrument Co.

7425 N. Oak Park Avenue • Niles, IL 60714

DIAL: 1-800-323-4340 or 1-708-647-7600

FAX: 1-708-647-9660

ner), a 15-channel scanner that goes directly to digital tape.

"The ability to use ATLAS data right away could be especially useful in disasters," said Davis. ATLAS will be joined with CAMS and TIMS, the thermal infrared multispectral scanner, to form the Airborne Instrument Test System. Potential commercial applications of the new system include environmental monitoring, facilities management, and mineral exploration.

NASA Helps Hawaii

Just three weeks after Andrew, Hurricane Iniki roared ashore in Hawaii. An urgent request from the state's Office of Emergency Planning for high-altitude aerial images brought a quick response from NASA's Ames Research Center in California.

"We got the call on Monday, had a team in Hawaii on Tuesday with 5000 pounds of equipment, and were in the air Wednesday morning," said John Arvesen, Ames' high altitude missions branch chief, who directed flights over the entire state with special emphasis on hardest-hit Kauai island. "Most importantly, we assessed lost vegetation and determined



An ER-2 aircraft (pictured in foreground) from Ames Research Center captured high-altitude aerial images over the state of Hawaii to assess Hurricane Iniki's impact.

storm surges to help develop new setbacks for properties."

The mission was undertaken by an ER-2 aircraft carrying a commercial scanner similar to CAMS and cameras to collect black and white, color, and color infrared images. Flying at 68,000 feet, the plane can acquire data similar to that gathered by space-based satellites.


Initially, the images helped to pinpoint and map areas that suffered major damage to buildings and structures, to plan access routes and mobilization areas for work crews, and to make accurate cost estimates for presentation to state and federal legislatures. Subsequent uses included identification of forest and wetland damage, documentation of changes to shorelines and stream courses, and location of fallen trees and landslides obstructing trails and remote roadways.

"The NASA aircraft and equipment are uniquely qualified to respond to disasters," said Arvesen, who recalled that Ames was called in during the Yellowstone, Oakland, and Yosemite fires and after the San Francisco earthquake.

Ames and Stennis are coordinating additional missions in Florida, Louisiana, and Hawaii. These return trips will assess both regrowth and lingering damage to natural and urban resources, and examine particular areas such as the Florida Everglades. □

For more information about the technologies described in this article contact Bruce Davis, Mail Stop HA30, Stennis Space Center, MS 39529, or John Arvesen, Ames Research Center, Mail Code N240-6, Moffett Field, CA 94035.

Highly parallel computing.



Computer reconstruction of proton/anti-proton collision at Fermilab.

Fermilab is tapping a new source of power.

If there's one thing you can count on in science, it's that your data will increase exponentially but your funding won't.

The scientists at Fermi National Accelerator Laboratory (Fermilab) have encountered this problem in a very big way. The data Fermilab processes for subnuclear event reconstruction and modeling has reached 40 terabytes a year. And they've developed an innovative solution to meet their needs.

Instead of relying on supercomputers, Fermilab has distributed a significant part of the workload to clustered IBM RISC System/6000® workstations. They've combined 108 of them, at latest

count, in a LAN-connected processor farm.

"The result," as Thomas Nash, Head of Computing at Fermilab puts it, "is better science." At a fraction of the cost of using supercomputers.

Many users are discovering the affordable, scalable power of clustered RISC System/6000 workstations.

We can help you, too—with consulting services, open systems integration and Business Partner software.

To make some discoveries of your own about parallel processing, call IBM Technical Computing Systems at 1 800 472-4966.



IBM and RISC System/6000 are registered trademarks of International Business Machines Corporation. © 1992 IBM Corp.



New Product Ideas

New Product Ideas are just a few of the many innovations described in this issue of *NASA Tech Briefs* and having promising commercial applications. Each is discussed further on the referenced page in the

appropriate section in this issue. If you are interested in developing a product from these or other NASA innovations, you can receive further technical information by requesting the TSP referenced



at the end of the full-length article or by writing the Technology Utilization Office of the sponsoring NASA center (see page 20). NASA's patent-licensing program to encourage commercial development is described on page 20.

Self-Damping Sprung Wheel

This wheel includes its own shock-absorbing suspension for a wheelchair. Installed in place of the conven-

tional large rear wheels on standard wheelchairs, the new wheel will reduce discomfort to users riding over rough surfaces. (See page 70.)

MODEL 9064



**FREQUENCY
DEVICES™**

Call Us Today at
(508) 374-0761

25 Locust Street • Haverhill, MA 01830 • FAX (508) 521-1839

Improved Grid-Array Millimeter-Wave Amplifier

These amplifiers operate at millimeter and submillimeter wavelengths and are being developed for use in communications and radar. In the improved amplifiers, feedback is suppressed by making the input polarizations orthogonal to the output polarizations. (See page 44.)

Robot Avoids Collisions With Obstacles

A developmental robot is equipped with infrared sensors and with a control system to allow the manipulator arm to move around obstacles. The robot can avoid collisions with other objects even when they are moving in unpredictable ways. (See page 48.)

Mapping Temperatures on Heat Pipes

Paints containing thermochromic crystals can be used to map temperatures on heat pipes and thermosyphons. The color of such coats changes reversibly, each distinct color indicating a particular temperature. (See page 58.)

Improved Composite Flexible Blanket Insulation

This insulation is a quilt of layers of advanced lightweight insulating materials, each optimized individually to inhibit the flow of radiative, conductive, or convective heat. The insulation can protect people and equipment against temperatures of up to 1,650°C. (See page 62.)

Poly(1,2,4-Triazoles) Via Aromatic Nucleophilic Displacement

This synthesis involves nucleophilic displacement of monomers with activated aromatic dihalides. The process opens up a large variety of new high-molecular-weight polymers that may be used in producing films, moldings, adhesives, and composites. (See page 64.)



COMM
LINK

ELINT
SELECT

SATCOM
ENABLE

FREQ
△

The NVIS-Sunlight Readable Electro-Optical Display System.

The VIVISUN 5000 electro-optical display system incorporates LED lighting that is both NVIS compatible and sunlight readable per MIL-L-85762A. This interactive system also provides rugged reliability and meets the environmental extremes that military programs demand.

The VIVISUN 5000 LED dot-matrix electro-optical display has a 1000:1 dimming ratio which achieves NVIS compatibility and sunlight readability (10,000 foot-candles). System features include: Total Legend Flexibility • Serial Data Line via RS-232C or RS-422

• Interactive Tactile Response.

The VIVISUN 5000 electro-optical display system is the solution for your ruggedized military design requirements.

Contact us today.




AEROSPACE OPTICS INC.

3201 Sandy Lane, Fort Worth, Texas 76112
Phone (817) 451-1141 • Fax (817) 654-3405

*VIVISUN 5000 electro-optical
display system.*

*The day-night all weather
lighting solution.*



SERIES

VIVISUN 5000™



HOW YOU CAN BENEFIT FROM NASA'S TECHNOLOGY UTILIZATION SERVICES

If you're a regular reader of TECH BRIEFS, then you're already making use of one of the low-and no-cost services provided by NASA's Technology Transfer Program. But a TECH BRIEFS subscription represents only a fraction of the technical information and applications/engineering services offered by this Program. In fact, when all of the components of NASA's Technology Transfer Network are considered, TECH BRIEFS represents the proverbial tip of the iceberg.

We've outlined below NASA's Technology Transfer Network—named the participants, described their services, and listed the individuals you can contact for more information relating to your specific needs. We encourage you to make use of the information, access, and applications services offered.

How You Can Access Technology Transfer Services At NASA Field Centers:

Technology Utilization Officers & Patent Counsels—Each NASA Field Center has a Technology Utilization Officer (TUO) and a Patent Counsel to facilitate technology transfer between NASA and the private sector.

If you need further information about new technologies presented in *NASA Tech Briefs*, request the Technical Support Package (TSP). If a TSP is not available, you can contact the Technology Utilization Officer at the NASA Field Center that sponsored the research. He can arrange for assistance in applying the technology by putting you in touch with the people who developed it. If you want information about the patent status of a technology or are interested in licensing a NASA invention, contact the Patent Counsel at the NASA Field Center that sponsored the research. Refer to the NASA reference number at the end of the Tech Brief.

Ames Research Ctr.

Technology Utilization
Officer: Geoffrey S. Lee
Mail Code 223-3
Moffett Field, CA 94035
(415) 604-4044
Patent Counsel:
Darrell G. Brekke
Mail Code 200-11
Moffett Field, CA 94035
(415) 604-5104

Lewis Research Center

Technology Utilization
Officer: Anthony F.
Ratajczak
Mail Stop 7-3
21000 Brookpark Road
Cleveland, OH 44135
(216) 433-5568
Patent Counsel:
Gene E. Shook
Mail Code LE-LAW
21000 Brookpark Road
Cleveland, OH 44135
(216) 433-5753

John C. Stennis

Space Center
Acting Technology
Utilization Officer:
Charles Hill
Code HA-30
Stennis Space Center,
MS 39529
(601) 688-1929

John F. Kennedy

Space Center
Technology Utilization
Officer: James A.
Aliberti
Mail Stop PT-PAT-A
Kennedy Space
Center, FL 32899
(407) 867-3017
Patent Counsel:
Bill Sheehan
Mail Code PT-PAT
Kennedy Space
Center, FL 32899
(407) 867-2544

Langley Research Ctr.

Technology Utilization
Officer: Joseph J.
Mathis, Jr.
Head, TU & AO Office
Mail Stop 200
Hampton, VA 23681-0001
(804) 864-2484
Patent Counsel:
Dr. George F. Helfrich
Mail Stop 143
Hampton, VA 23681-0001
(804) 864-3221

Goddard Space Flight Center

Technology Utilization
Officer: Dr. George Alcorn
Mail Code 702
Greenbelt, MD 20771
(301) 286-5810
Patent Counsel:
R. Dennis Marchant
Mail Code 204
Greenbelt, MD 20771
(301) 286-7351

Jet Propulsion Lab.

NASA Resident Office
Technology Utilization
Officer: Arif Husain
Mail Stop 180-801D
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-4862
Patent Counsel:
Thomas H. Jones
Mail Code 180-801G
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-5179
Technology Utilization
Mgr. for JPL: Dr. Nor-
man L. Chaffin
Mail Stop 156-211
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240

George C. Marshall

Space Flight Center
Technology Utilization
Officer: Ismail Akbay
Code AT01
Marshall Space Flight
Center,
AL 35812
(205) 544-2223
Patent Counsel:
Robert L. Broad, Jr.
Mail Code CC01
Marshall Space Flight
Center,
AL 35812
(205) 544-0021

Lyndon B. Johnson

Space Center
Technology Utilization
Officer: Dean C. Glenn
Mail Code IC-4

Houston, TX 77058

(713) 483-3809
Patent Counsel:
Edward K. Fein
Mail Code AL3
Houston, TX 77058
(713) 483-4871

NASA Headquarters

Technology Utilization
Officer: Leonard A. Ault
Code CU
Washington, DC 20546
(703) 557-5598
Assistant General
Counsel for Patent
Matters: Robert F.
Kempf, Code GP
Washington, DC 20546
(202) 453-2424

How You Can Utilize NASA's Regional Technology Transfer Centers (RTTCs)—A nationwide network offering a broad range of technology transfer and commercialization services.

You can contact NASA's network of RTTCs for assistance in solving a specific technical problem or locating technology or markets that match your interests. The RTTCs are experienced in working with industry to define technology needs and acquire and commercialize applicable technology. User fees are charged for most services. **For more information, call 1-800-472-6785** and you will be connected to the RTTC in your geographical region (or you may call or write directly to the RTTC in your region).

REGIONAL TECHNOLOGY TRANSFER CENTERS (RTTCs)

RTTC Directors

NORTHEAST

Dr. William Gasko
Center for Technology
Commercialization
Massachusetts Technology Park
100 North Drive
Westborough, MA 01581
(508) 870-0042

MID-ATLANTIC

Ms. Lani S. Hummel
University of Pittsburgh
823 William Pitt Union
Pittsburgh, PA 15260
(412) 648-7000
(800) 257-2725 (toll-free US)

SOUTHEAST

Mr. J. Ronald Thornton
Southern Technology Application
Center
University of Florida
College of Eng.
Box 24
One Progress Boulevard
Alachua, FL 32615
(904) 462-3913
(800) 225-0308 (outside FL)

MID-CONTINENT

Mr. Gary Sera
Texas Engineering Experiment Station
Texas A&M University System
237 WERC College Station,
Texas 77843-3401
409-845-8762

MID-WEST

Dr. Joseph W. Ray
Great Lakes Industrial Technology Center
25000 Great Northern Corporate Center
Suite 450
Cleveland, OH 44070-5310
(216) 734-0094

FAR-WEST


Mr. Robert Stark
Technology Transfer Center
University of Southern California
3716 South Hope Street,
Suite 200
Los Angeles, CA 90007-4344
(213) 743-6132
(800) 642-2872 (CA only)
(800) 872-7477 (toll-free US)

If you are interested in information, applications, research, training, and services relating to satellite and aerial data for Earth resources, contact NASA's transfer point for earth observing technology: **Technology Application Center, University of New Mexico, 2500 Yale Blvd. S.E., Suite 100, Albuquerque, NM 87131-6031; Dr. Stan Morain, Director (505) 277-3622.**

If you represent a public sector organization with a particular need, you can contact NASA's Application Team for technology matching and problem solving assistance. Staffed by professional engineers from a variety of disciplines, the Application Team works with public sector organizations to identify and solve critical problems with existing NASA technology. **Technology Application Team, Research Triangle Institute, P.O. Box 12194, Research Triangle Park, NC 27709; Dr. Doris Rouse, Director, (919) 541-6980**

A Shortcut To Software: COSMIC®—For software developed with NASA funding, contact COSMIC, NASA's Computer Software Management and Information Center. New and updated programs are announced in the Computer Programs section. COSMIC publishes an annual software catalog. For more information call or write: **COSMIC®, 382 East Broad Street, Athens, GA 30602 John A. Gibson, Director, (706) 542-3265; FAX (706) 542-4807.**

If You Have a Question..NASA Center For AeroSpace Information can answer questions about NASA's Technology Transfer Network and its services and documents. The CASI staff supplies documents and provides referrals. Call, write or use the feedback card in this issue to contact: **NASA Center For AeroSpace Information**, Technology Transfer Office, P.O. Box 8757, Baltimore, MD 21240-0757. **Walter M. Heiland, Manager, (410) 859-5300, Ext. 245.**



POWER TOOLS FOR THE BRAIN

If you've ever had the opportunity to shop for a CAD system, you might think high performance and low cost are contradictory terms.

Not necessarily.

Digital and Cadkey, Inc. have teamed up to give you optimal power, versatility, and performance in mechanical engineering CAD — all at a very affordable price.

The Personal DECstation™ 5000 and CADKEY® 5.0 design and drafting software can unleash the design genius within you. Easy to learn and easy to use, they make it possible to go from raw concept to finished part

faster and more easily than you ever thought possible.

The DECstation 5000 combines the power of a UNIX®-based workstation, with the flexibility of a PC. Processing speed and abundant storage capacity make it the perfect choice for use with large design files.

CADKEY — the most advanced 3D design software you can buy — is just part of a family of comprehensive desktop concurrent engineering tools that seamlessly integrate the design-to-manufacture cycle.

Both companies provide exceptional support, a worldwide sales and training

network, and "investment protection" thanks to Digital's open architecture and CADKEY's bi-directional translators.

Digital and Cadkey offer small to medium sized companies an affordable, comprehensive solution to their CAD system problems. For more information contact your Cadkey or Digital dealer today.

digital™

Cadkey, Inc.

4 Griffin Road North, Windsor, CT 06095
(203) 298-8888 □ FAX: (203) 298-6401

For More Information Circle No. 558

CADKEY® is a registered trademark of Cadkey, Inc. The DIGITAL logo and DECstation™ are trademarks of Digital Equipment Corporation. UNIX is a registered trademark of UNIX System Laboratories, Inc., in the USA and other countries.



Special Focus: Test and Measurement

Compact Raman Spectrometers Would Detect Hydrogen

Advantages would include speed, dynamic range, and ease of calibration.

John F. Kennedy Space Center, Florida

Compact Raman spectrometers are being developed to measure concentrations of hydrogen as low as hundreds of parts per million in air, nitrogen, or other carrier gases. Similar spectrometers could also be developed to detect other gases that emit characteristic Raman spectra.

The use of Raman spectrometry for this purpose is not new and has been described in several recent articles in *NASA Tech Briefs*. In this case, the novelty lies in a design concept that incorporates a Raman-scattering apparatus into a compact instrument that would measure the concentration of hydrogen leaking into a stream of gas or into a gas enclosed in a small space. The original intended use is the detection of leaks of hydrogen from rocket fuel systems; should hydrogen-fueled cars and trucks come into widespread use, instruments of this type could be used to detect leaks from vehicles and supply equipment, to help prevent explosions.


The figure is a schematic diagram of a laboratory prototype. A stream of the gas to be sampled flows through a chamber. Light from a helium-neon or argon-ion laser is directed past a chopper and into the chamber, where it is reflected back and forth between two concave mirrors. Light scattered from the gas approximately perpendicular to the optical axis of the concave mirrors is collected, then passed through a band-pass filter to remove Rayleigh-scattered light (at the laser wavelength) and background light. The emerging beam, consisting predominantly of light at the Raman wavelength characteristic of the

hydrogen or other gas to be detected, is focused onto a photomultiplier tube. The output of the photomultiplier is fed to a lock-in amplifier synchronized with the chopper, and the output of the amplifier is sent to data-recording and -processing equipment.

Speed of response is one advantage of

the Raman spectrometer: it has a characteristic response time of the order of seconds. In contrast, the response times of electrochemical hydrogen and oxygen sensors are of the order of minutes. It is capable of operation over the wide dynamic range from a few hundred parts per million to an all-hydrogen atmosphere. In tests, the lower limit of detectability of hydrogen in a carrier gas at atmospheric pressure was found to be 100 parts per million, using a 10-mW argon-ion laser and a response time of 2 seconds. The performance of the prototype instrument was found to agree with predicted performance based on Raman signal and noise levels.

This work was done by William R. Helms of Kennedy Space Center and Steven Adler-Golden of Spectral Sciences, Inc. For further information, Circle 15 on the TSP Request Card. KSC-11441



This Laboratory Raman Spectrometer has been used to test the concept of a compact Raman-scattering leak detector. A fully-developed instrument is expected to occupy a volume of 0.6 ft³ (about 0.017 m³), to weigh about 35 lb (about 16 kg), and to be capable of monitoring He, H₂, N₂, O₂, and Ar concurrently at 9 locations at 3 locations per second.

Test-Signal Generator for SNR Calibration

Analog signals with accurate signal-to-noise ratios will be synthesized digitally.

NASA's Jet Propulsion Laboratory, Pasadena, California

An assembly of commercial and custom-made electronic equipment is designed to generate noisy intermediate-frequency or baseband received phase-modulation data-communication signals with accurately known signal-to-noise ratios. The signals will be used to perform signal-to-noise-ratio calibrations and other tests of the responses of data-communication receivers to noisy incoming signals. This test-signal-generating system is intended specifically for use with spacecraft-telemetry receivers

of the Deep Space Network, but the underlying principle is also applicable to the generation of test signals for other advanced data-communication receivers.

The test signal and test noise are generated by digital synthesis followed by digital-to-analog conversion. The subsystems of the test-signal generator (see figure) include a commercial personal computer, a custom-made signal-generator box, a test-support assembly (which feeds clock signals and externally encoded data sig-

nals to the signal-generator box), and a commercial frequency synthesizer.

The monitoring, controlling, and other signal-processing programs reside in the personal computer. Commands from the personal computer are sent to the central processing unit of the signal-generator box. In response to these commands, this central processing unit reconfigures the connections among various other high-speed subunits of the signal-generator box to generate the calibrated output signals. Oper-

Data acquisition boards are like cable TV.

The more channels you have, the greater your chances of finding something you've never seen before.

Data Translation's new DT2839 is getting high ratings from data acquisition professionals everywhere.

That's because its unprecedented number of channels and high-speed sampling deliver the data you need to get a clearer, more complete picture of your test subject.

The DT2839 is one of the fastest data acquisition boards available. And a great productivity tool for mechanical test, biomedical, or high channel count applications required for the neurosciences.

Technical Highlights

- 1MHz for one channel and up to 416kHz for 32 SE or 16 DI channels
 - Up to 224 channels
 - Variable channel scan
- Full software configuration and calibration
 - Analog threshold triggering
 - Dynamic Digital™ circuitry for clocked digital outputs



Care To Check Out A Few More Channels?

The DT2839 keeps on growing. With our DT2896 Channel Expander,




Photo courtesy of BrainWave Systems Corporation.

you can continue to add channels in 96 SE or 48 DI input increments.

And, of course, it's compatible with DT-Connect™ for direct connection to high speed processor boards.

The DT2839 features variable channel scan, which allows sampling rates to vary significantly from channel to channel to meet the exact needs of your application. For example, you could configure 28 channels to sample at 10kHz each while 4 channels sample at 100Hz.

Some Of The Best Programs You've Ever Seen.

Data Translation is also a leader in data acquisition software.

The DT2839 is supported by GLOBAL LAB® Data Acquisition Library for Microsoft® Windows™

among others. And since it conforms to DT-Open Layers™, the accepted standard for data acquisition software, you know your investment is protected.

Our Quality Is A Big Hit With Customers.

Data Translation's meticulously designed analog front end assures that the DT2839's 12-bit accuracy is never impaired by harmonic distortion. That's an advantage you rarely find. And a good example of the quality you'll find in all our data acquisition solutions.

Call us today, and we'll rush you more details on the remarkable DT2839, and our 3-Book Set, chock full of the latest product and application information.


Because when it comes to data acquisition, Data Translation is definitely the one to watch.



DATA TRANSLATION®

For More Information Circle No. 549

FOR MORE PRODUCT INFORMATION OR OUR FREE 3-BOOK SET CALL 800-525-8528.
100 LOCKE DRIVE, MARLBORO, MA 01752-1192. FAX 508-481-8620. IN CANADA CALL 800-268-0427.



The **Test-Signal Generator** generates baseband or intermediate-frequency phase-modulation data signals plus noise with accurately known signal-to-noise ratios, by use of digital synthesis followed by digital-to-analog conversion.

ating in conjunction with the frequency synthesizer, the signal generator then produces the various signal spectra, including intermediate-frequency, dual-subcarrier, and/or quadrature-phase-shift-keying components.

The lower part of the figure illustrates the relationships among the functions and subunits of the signal-generator box. The pattern generator, when configured to generate noise, accepts data bytes from the central processing unit to be mapped into a random-access-memory (RAM). After the RAM has been loaded, it is read sequentially by a random-address generator, which is a pseudonoise code generator with inherently uniform output distribution and a period longer than 24 hours. The distribution function of the data bytes mapped into the RAM acts in conjunction with the uniform distribution function of the ad-

resses with which this RAM is read to determine the distribution function of the output of the noise generator. Usually, the distribution function mapped into the RAM is a Gaussian distribution quantized to a specified number of bits from the corresponding analog probability function.

The main purpose of the filter-and-attenuator subunit is to synthesize low-pass filters defined by the user when generating a baseband spectrum or to synthesize band-pass filters when generating an intermediate-frequency spectrum. Noise and data are filtered independently by two digital filters. These filters can, if desired, have the same frequency response.

The function of the digital-to-analog-conversion subunit is fairly self-explanatory. The statistics-monitor subunit performs multiplication and accumulation functions to generate some statistical measures of the

digital and analog outputs.

Overall, high accuracy is maintained by simultaneous generation of digital noise and signal spectra at a given baseband or passband. The digital synthesis provides a test signal embedded in noise with the statistical properties of a stationary random process. Accuracy depends only on test integration time, with a limit imposed by the quantization noise of this system (estimated to be 0.02 dB). The worst-case root-sum-square error on a given signal-to-noise-ratio setting is estimated to be 0.11 dB.

This work was done by Benito O. Gutierrez-Luaces of Caltech for NASA's Jet Propulsion Laboratory. For further information, Circle 30 on the TSP Request Card.

NPO-18495

When you can't be there,

A removable Universal Input Module directly handles 20 analog input channels of virtually any sensor type—including thermocouples, RTDs, DC voltage, AC voltage (true rms), frequency, and resistance—without external signal conditioning.

Hydra Data Bucket features alarm limits, Mx+B scaling, min/max/last memory, direct printer output, real-time clock, and selectable scan triggers.

Simple to set-up and operate from the front panel.

A portable Memory Card lets you transfer setup and configuration information to a remote unit and transfer collected data to your PC for analysis.

Menu-driven software (included) lets you upload collected data to a PC, directly from a Memory Card or via Data Bucket's RS-232 port, for analysis with familiar spreadsheets.

send a card.

PC-based data acquisition is easier, faster, and more convenient with Fluke's new Hydra Data Bucket featuring a removable Memory Card.

Now, you don't have to haul data acquisition equipment back and forth from a remote site to your PC. Simply let the data flow into your Hydra Data Bucket. Then send a card. And keep collecting data without interruption.


Use Hydra Data Bucket's removable Memory Card to transfer data to your PC for archiving, analysis, or report generation. Or send configuration information to the field so non-technical users can run a test in a snap. Either way, you'll find nothing does a better job of capturing the memory of an event like a card.

For literature or more information, call **1-800-44-FLUKE.**



©1992 John Fluke Mfg. Co., Inc., P.O. Box 9090, M/S 250C, Everett, WA 98206-9090. U.S. (206) 356-5400
Canada (416) 890-7600. Other countries: (206) 356-5500
All rights reserved. Ad No. 00270

Cable assemblies for your toughest applications. Or your tenderest.





Your need may be defined by signal requirements: the speed demands of today's 'hot' designs. Or your need may derive from the environment a signal passes through, or even the signal's source. High-performance cable assemblies from AMP come in just as many types as you have needs. With the level of reliability—and support—you require.

Microminiature cable assemblies for the medical field serve in environments where space, weight, and maneuverability

are critical, and 'friendliness' isn't a nicety, but a necessity. We design and manufacture assemblies to meet your most demanding requirements. They offer outstanding signal fidelity. They're rugged enough for heavy use. Yet they're astonishingly small, flexible, and easy to handle.


Our cable assemblies for high-speed data applications answer to a different challenge: moving your signals transparently. Fast data streams require coaxial or transmission-line assemblies for







effective signal management. We custom-engineer around your performance requirements—matching cable, connector, and termination technology to the critical impedance/risetime needs of your design. And meeting your critical business needs for a cost-effective, time-effective solution.

The know-how we bring to your high-performance interconnect needs can be extended as much as you need, too: we offer services that pick up from your



initial design concept and take you all the way to production. Starting with in-depth analysis and verification, we can provide board layout and routing, full software simulation of and proof of first article, thermal and electrical analysis,



package design, and fabrication.

For more information, contact our Product Information Center at 1-800-522-6752 (fax 717-986-7575). AMP Incorporated, Harrisburg, PA 17105-3608. In Canada call 416-475-6222.

For More Information Circle No. 613

THIS IS AMP TODAY.

AMP

X-Ray and Acoustic Measurements Yield Stiffnesses

Data from nondestructive tests are combined for use in calculating stresses and strains.

Langley Research Center, Hampton, Virginia

An analytical technique combines ultrasonic scanning measurements of the local velocity of sound in a specimen of material with x-ray computed tomographic measurements of its local mass density to compute the local stiffness of the material. The stiffnesses at various locations in the specimen can then be used in a finite-element mathematical model of the elastic behavior of the specimen to compute local stresses, local strains, and overall deformations. Thus, the new technique enhances the value of quantitative nondestructive x-ray and ultrasonic measurements. It is especially useful in the characterization of carbon/carbon composites and other advanced materials that are not homogeneous and for which the customary simplifying assumption of constant density and/or constant stiffness is not valid.

Figure 1 illustrates the main steps of the analytical technique. The x-ray computed tomographic images are processed to convert the data on the local absorption of x rays into local density with the help of either a reference sample of the same material having known density or else a conversion table for calibration. The processing of the ultrasonic measurements is

more complicated because if the material is anisotropic, the velocity of sound depends on the direction of propagation; namely,

$$\sum_{j=1}^3 \sum_{l=1}^3 C_{ijkl} \alpha_j \alpha_l - \rho V_s^2 \delta_{ik} = 0$$

where the C_{ijkl} are coefficients of stiffness, α_j and α_l are direction cosines of the propagation of the sound; ρ is the local density, and V_s is the speed of sound along the indicated direction. The direction cosines can be deduced by Snell's law from the angle of incidence of sound on the specimen and the measured speeds of sound in the specimen and in the coupling medium in which the specimen is immersed. The equation can then be solved by iterative numerical means to obtain the stiffness.

The velocity along a given ultrasonic-measurement path from the transmitting to the receiving transducer is measured in terms of the time of flight of a pulse or the shift in phase of a wave along the path. Measurements are taken with the trans-

mitting and receiving transducers at various positions in the coupling medium and oriented at various angles with respect to the specimen (see Figure 2), using offsets calculated by considerations of refraction and energy-flux density paths. Because the time of flight or change in phase is an integral of the reciprocal of speed of sound along the path, the measured speed is, in effect, an average value that corresponds to this integral. Speeds of sound must be measured along multiple directions to include the effects of anisotropy. For example, an orthotropic material has nine independent coefficients of stiffness, requiring nine independent measurements of velocity for each position.

This work was done by Eric Irvine Madaras of Langley Research Center and Ronald A. Kline of the University of Oklahoma. No further documentation is available.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Langley Research Center [see page 20]. Refer to LAR-14108.

Figure 1. **X-Ray and Ultrasonic Measurements** are combined with an analytical technique to obtain more information on an anisotropic specimen than can be obtained by either technique alone. The combination yields data on the coefficients of stiffness, which can be used in a finite-element mathematical model of the elastic behavior of the specimen.






Figure 2. The **Speed of Sound** is measured along multiple paths through the specimen at various angles to obtain data on its anisotropic-stiffness properties.





GOULD
Electronics



Gould's newest recorder. With 48 megabytes.

The new Gould TA5000 offers an unprecedented memory capacity that's bound to make you smile. This is the only 24-channel recorder with a 15" thermal array printhead and up to 48MB of on-board memory. Which means you can record over longer periods of time *and* increase your sample rate to 250KS/s on all channels. So you're guaranteed the bandwidth you need for comprehensive analysis.


And when we say the TA5000 has the flexibility to record what you want, how you want it, we're hardly making idle chatter. Modular design allows for easy configuration or expansion for 8, 16 or 24 channels. The widest selection of the most accurate signal conditioners are yours to

choose from. And our single, thermal array printhead lets you position traces anywhere in full overlap or discrete channels - with no blank zones.

In addition, Gould's Micropulsing™ technology provides reliable operation and the resolution you need to see your signals clearly, at every frequency and chart speed.

All this in a rugged, economical package backed by the largest sales and support organization in the recorder industry. It's the kind of value you can really sink your teeth into. Just remember, it's only from Gould.

Call Gould today at (216) 328-7000 or, for immediate response, complete the coupon and FAX it to us today.



NTB 1/93

Yes! ☐ Have a Gould Representative call me to arrange a demonstration

☐ Rush me a free TA5000 brochure

(Please print, or affix business card.)

Name: _____

Title: _____

Company: _____

Street: _____

City: _____ State: _____ Zip: _____

Telephone: _____

Send to: Gould Inc., Test and Measurement Group, 8333 Rockside Road, Valley View, Ohio 44125. Fax: (216) 328-7400.

Noncontact Measurement of Shaft Speed, Torque, and Power

A fiber-optic sensor monitors the speed and twist of the shaft.


Lewis Research Center, Cleveland, Ohio

A noncontact fiber-optic sensor and associated electronic equipment measure the twist and the speed of rotation of a shaft. From these measurements, a data processor can determine the torque and power. The response of the sensor remains linear even at cryogenic temperatures, unlike the responses of other noncontact sensors based on magnetic, inductive, or capacitive principles. Unlike strain gauges that measure twist, this sensor requires no slip rings or telemetry to transfer signals from the shaft — techniques that are difficult to implement at high speeds and low temperatures. The fiber-optic sensor is therefore well suited for providing data on the performances of turbopumps for such cryogenic fluids as liquid oxygen and liquid hydrogen.

The sensor differs from previous fiber-optic sensors for speed, torque, and power in that its raw outputs are analyzed in groups of data points rather than as a stream of individual data points. By analyzing data in batches, a computer can enhance a signal that has been corrupted by nontransparent impurities in the optical path, by bubbles in the pumped fluid, or by lateral movement of the shaft out of focus of the monitoring optics. One disadvantage of batch analysis, however, is that speed, torque, and power cannot be determined in real time: a small time is needed to collect the specified number of data, transfer them to the computer, and process them.

In the sensor, a beam from a helium/neon laser is directed into a single-strand, multimode optical fiber (see figure). A bidirectional coupler splits the beam into two beams traveling along two fibers. At the ends of each fiber, a gradient-index-of-refraction (GRIN) lens focuses the light onto the shaft. These two sensing tips enable measurement of differential rotation at two points on a line parallel to the axis of the shaft. A reflective surface that covers part of the circumference of the shaft at each sensing tip reflects a pulse of light as it passes through the beam at its location. The reflected light goes back into each fiber through its GRIN lens, and a bidirectional coupler at each such lens transmits the light to a photodiode. The outputs of the photodiodes are digitized and sent to a microprocessor for analysis.

The frequency of the pulses of reflected light represents the speed of rotation. The difference between the times of the pulses from the two reflectors is multiplied by the speed of rotation to obtain the twist. From the twist and the torsional stiffness of the shaft, one can infer the torque. The power



Reflective Strips on a rotating shaft reflect two series of light pulses back into the optical system. A bidirectional coupler in each of the two optical fiber paths separates the reflected light from the incident light, sending it to a photodiode for output to an analog-to-digital converter and a computer.

equals the torque multiplied by the angular speed of rotation.

This sensor concept was tested on a phenolic shaft 0.5 in. (12.7 mm) in diameter and 48 in. (1.22 m) long spinning at 1,180 rpm (19.67 Hz). The speed was measured at a sampling rate of 5×10^4 Hz. Angles of twist between 0.005° and 10° were inferred from measurements made at a sampling rate of 2.5 MHz. It was found that increasing the sampling rate of the analog-to-digital converter could improve the measurement resolution and that decreasing the spot size of the focused beam

could increase accuracy.

This work was done by George C. Madzsar of Lewis Research Center. Further information may be found in NASA TM-102481 [N90-21360], "A Fiber Optic Sensor for Noncontact Measurement of Shaft Speed, Torque and Power."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700.

LEW-15099



APOLLO COMMEMORATIVE POSTER—

Actual size: 30" x 21" In Full Color! Printed on quality poster stock.

Price only \$8.95 each plus \$5.00 for shipping and handling. (NY residents add sales tax to total)

Mail payment to:

NASA Tech Briefs, Dept. F, 41 East 42nd St.,
New York, New York 10017

For credit card orders call: (212) 490-3999

**I need a regulated,
low ripple,
high voltage DC supply
in a 3½ inch rack...**

No problem!



Only Glassman can deliver *three* different series of high voltage DC power supplies...all with 3½ inch panels and your choice of 100, 300, or 500 watts of space-saving power.

The Series EH, ER, and EW are available in various models starting with DC ranges from 0 to 1 kV.

All models feature air insulation for light weight and easy serviceability, low stored energy for safety, and automatic crossover from constant-voltage to constant-current regulation for protection from overloads, arcs, and shorts. They can be ordered with dual analog meters, digital meters, or a blank panel for OEM/system applications. Common specifications include:

- Voltage regulation <0.005%, line or load
- Ripple <0.02% (0.03%, EH) at full load
- Current regulation <0.05% from short circuit to rated load
- Operation Local/remote control and monitoring
- Polarity Positive, negative, or reversible

The Series EW even provides a bonus. For outputs up to 84% of rated voltage, maximum current capability is equivalent to a 600 W supply!

For more information on these or other supplies, ranging from 1 kV to 500 kV, 15 W to 15 kW, or anything in between, write or call today. All are backed by responsive application assistance, the best on-time delivery in the industry, a 3-year no-nonsense warranty, and factory service available on three continents. Glassman can deliver...with no problems!



Series EH
100 W
to 60 kV

Series ER
300 W
to 75 kV

Series EW
500 W
to 60 kV

Innovations in high voltage power supply technology.

GLASSMAN HIGH VOLTAGE INC.



GLASSMAN U.S.A.

Glassman High Voltage, Inc.
P.O. Box 551
Route 22 East
Salem Industrial Park
Whitehouse Station, NJ 08889
U.S.A.
Telephone: (908) 534-9007
TWX: 710 480-2839
FAX: (908) 534-5672

GLASSMAN EUROPE

Glassman Europe Limited
Studio 4
Intec 2
Wade Road
Basingstoke
Hampshire RG240NE
England
Telephone: (0256) 810808
FAX: (0256) 810815

GLASSMAN JAPAN

Glassman Japan High Voltage Limited
Taira Building
1-17, Taira 1-chome
Miyamae-ku, Kawasaki 216
Japan
Telephone: (044) 877-4546
FAX: (044) 877-3395

Circle Reader Action No. 487

No logic analyzer is, for that matter.

Because at speeds above 25 MHz, even the best designer needs a scope to handle nightmares like race conditions, ground bounce, and crosstalk. And not just any scope, but one tailored specifically for high-speed digital design.

At Tektronix, we understand this need all too well.

As proof, we've not only designed and built a great logic

analyzer

— our

powerful

new GPX —

but also a perfect companion. The TDS 640 digitizing oscilloscope.

To get you started, the GPX provides more channels than cable TV. Up to 160, for instance, of 80 MHz state analysis, and 32 channels of 1 GHz timing or 160 channels of 200 MHz transitional timing.



In short, enough to handle the world's fastest

microprocessors. And with that

kind of performance, you can easily track your system at clock rates well beyond 50 MHz, which allows you to locate complex coding errors quickly and accurately.




EVEN THOUGH OUR NEW LOGIC HIGH SPEED DIGITAL DESIGN,






Enter the TDS 640.

With a 500 MHz bandwidth and 2 GS/s real-time sampling on four channels, the TDS displays logic and timing errors with absolute accuracy. And because it was created with the digital designer in mind, the TDS lets you trigger directly on common



digital circuit events like glitches, runt pulses, and

ANALYZER IS GREAT FOR IT'S NOT NEARLY ENOUGH.



excessive clock jitter or skew. Put all that together with the power of the GPX and you have a remarkably effective solution.

Cost effective, too. In fact, the GPX and TDS together sell for less than competing scope/logic analyzer combinations. And if you buy the pair between now and February 28, 1993, we'll take an additional 10% off the retail price.

Enough, already.

For more information on the very best high-speed digital design tools available, call Tektronix today at 800-426-2200. Ask for extension 120.

For More Information Circle No. 637

Tektronix
Test and Measurement

Multiple Pages Intentionally Left
Blank

Pressure-Coupled Acoustic-Transducer Assembly

Reliable high-temperature connections can be made and moved from one location to another.


Langley Research Center, Hampton, Virginia

Prior high-temperature measurement systems have typically included acoustic transducers hard-coupled to delay lines by use of epoxies, brazing alloys, indium alloys, ceramics and silicones. The acoustic couplings in such a system involve stationary bonds to the delay line and limit the mobility and use of the transducer assembly. An improved acoustic-transducer assembly developed for use at NASA Langley Research Center is easy to assemble, is relocatable, and can be used at high temperatures.

In the improved assembly, a piezoelectric acoustic transducer is pressure-coupled to a delay line or fixture through a soft metal like aluminum, copper or gold. The transducer subassembly includes a layered structure (see figure) of the coupling material, the transducer, a thin disk of the coupling material that acts as a cushion for the transducer, an electrode disk with a coaxial cable lead attached, insulation/damping material, and a pressure plate.

The fabrication of the transducer subassembly begins with the attachment of the coupling material to one end of a hollow metal cylinder that serves as the outer container of this subassembly. The coupling material can be any soft material that will withstand the operating temperature of the transducer. A cylindrical insulator is placed inside the outer metal container and serves to electrically insulate the transducer and hold the layers of the subassembly in place. Coupling pressure is applied via a rounded bolt threaded through a metal fixture. A coaxial-cable lead is attached to the electrode disk, and the shielding is attached to the metal cylinder so that the cylinder acts as an electrical ground plane as well as an enclosure for the assembly. The acoustic signal can be enhanced by matching the thickness of the coupling material to a quarter wavelength.

This assembly is designed to be used in the acoustic characterization of materials at high temperatures. It can be used at temperatures up to the melting temperature of the coupling metal. (This melting temperature must be less than



Coupling Pressure Is Applied by tightening the bolt onto the transducer subassembly.

the Curie temperature of the transducer.) Because this transducer is not hard-coupled to a delay line, it can be moved easily from one location to another. Also, pressure coupling precludes the problem of matching the coefficients of thermal expansion

of the transducer, coupling material, and delay line.

This work was done by F. Raymond Parker of Langley Research Center. No further documentation is available.
LAR-14283

Measuring Deflections of Propeller and Fan Blades


Bends and twists are deduced from timing of laser-beam shadows.

Lewis Research Center, Cleveland, Ohio

A method based on measurement of interruptions of a laser beam provides information on deflections of the blades of

an airplane propeller or an unducted turbofan. The deflections in question are bends and twists caused by centrifugal

and aerodynamic loads. The method provides for nonintrusive measurement in a wind tunnel or on an open test stand. Here-



Introducing the DAS-1600. Fasten your seatbelts.

Turbocharged data acquisition performance at an economy price—only \$899.

When we introduced the DAS-16 in the early '80s, it raced quickly into the top spot among general purpose data acquisition boards.

Well, here we go again. We've just taken the wraps off the next generation: the DAS-1600. A board with breakthrough performance and the best software support in the industry. For the incredible price of \$899—less than our original DAS-16.

Packed with advanced features you need for the '90s. Including:


- 100 ksample/sec with 12-bit resolution.
- Burst mode to simulate simultaneous sample and hold.
- 8 differential or 16 single-ended analog inputs.
- 32 bits of digital I/O.
- 2, 12-bit D/As with 5 selectable



ranges for greater flexibility.

- Advanced ASIC design for lower cost and higher reliability.
- High-quality four-layer printed circuit board

for reduced noise. □ Pop Up Control Panel for quick start-up. □ Optional Windows® 3.1 software. □ Extensive third-party software support.

 **Special "Fast Track" offer.**
\$300 off new EASYEST AG™

software from Keithley Asyst when you buy a DAS-1600 board by **Oct. 31, 1992**. Get quick start-up, troubleshooting, acquisition to disk, and graphics for only \$95 (normally \$395). With a price of \$899, and an offer like this, the DAS-1600 will go even faster.

Call 800-348-0033

and ask for Cora Vette to order or for more information. And give yourself the winning edge.


**SOFTWARE
OFFER
EXTENDED
THROUGH
JAN. 31,
1993**

KEITHLEY METRABYTE
DATA ACQUISITION

DAS 1:NT193

VOYAGER TO NEPTUNE POSTERS

Set of four posters in full color showing unusual photographs of Neptune's rings, arcs, and moons; flybys of Jupiter, Saturn, and Uranus; sightings of the surface of Neptune with Triton in the offing; and a colorful glimpse of Neptune's total atmosphere. Posters measure 36 by 24 inches. Shipped in a tube.



NEPTUNE—Large blue lettering dramatically sets off a photo of Neptune.


TRITON—Eye-catching photos show icy calders and ridges that scar the equatorial terrain. Large lettering is in lavender.



Rings—Satellites is the theme. Large lettering appears in peach.



Atmosphere—A colorful poster with magenta lettering and a pink cast of color outlining the planet.



Rush me _____ set(s) of Voyager to Neptune posters. Price per set of four posters is \$21.95.

Add shipping and handling charges—

- Orders up to \$50.00 add \$5.00
- Orders \$51.00 to \$100.00 add \$8.50
- Orders \$101.00 to \$150.00 add \$9.50
- Orders outside North America up to \$50.00 add \$20.00

Name _____

Company _____

Address _____

City, State, Zip _____


Send payment to:

NASA Tech Briefs, Dept F
41 East 42nd Street, Rm 921
New York, NY 10017


For Credit Card Orders call:

(800) 944-NASA

(NY state): **(212) 490-3999**



MEASURING SETUP IN WIND TUNNEL



MAGNIFIED VIEW ALONG CENTERLINE, SHOWING LASER BEAM IN RELATION TO ONE BLADE ABOUT TO PASS THROUGH IT

Figure 1. The **Beam From Laser 1** is chopped by the passage of the blades as the propeller or fan rotates. The beam from laser 2 is reflected once per revolution from a mirror on the hub.

tofore, deflections of blades on ducted and unducted rotors have been observed by other optical methods that involve various disadvantages. The present method overcomes the disadvantages and is particularly noteworthy in comparison with methods that rely on the reflectivity of the blades.

In this method (see figure), the beam from a low-power helium/neon laser intersects the plane of rotation near the tip radius, where the deflections are expected to be the largest. Typically, the beam is aimed at an angle of about 10° relative to the pressure surface chord of the blade in a plane nearly perpendicular to the pitch axis.

When the beam is not blocked by a blade, it strikes a photodetector on the wall opposite the wall on which the laser is mounted. Thus, the output of the photode-

tector is a constant positive voltage except when the blade blocks the beam, when the voltage drops to zero. The leading and trailing edges of these relatively negative pulses correspond to the times of passage of the leading and trailing edges of the blades. In addition to these blade pulses, a once-per-revolution reference pulse is generated by reflecting a second laser beam from a small mirror mounted on the hub.

The pulse data are recorded. On playback, the data are digitized at a reduced speed and processed on a minicomputer to obtain either the steady-state bending and twist deflections or the corresponding vibratory amplitudes. The analysis takes into account the geometry of the laser beam and blades and the relationship between the stationary reference frame and

We made this ad the same way some people still do calculations.

Aside from the quarter million or so people who already use Mathcad®, most engineers and scientists continue to do calculations by hand. Using calculators and

And print presentation quality documents complete with text, graphics and equations in real math notation.

Mathcad comes with more

than 200 commonly used

functions built-in, including exponentials, differentials, cubic splines, FFTs and more. Full symbolic capabilities are available with a menu pick, so you can evaluate any integral, Taylor series or infinite

to fully interactive formulas, diagrams and data tables directly from popular reference books. Work with them right in the handbook itself. Or

click and paste them for use in your Mathcad documents.

Plus optional

Applications Packs with modifiable templates are available for all major engineering and science fields.


So put down your pencil, pick up the phone and call now to get a free Mathcad Working Model and complete information. Or mail or fax the coupon below.

Once you get your hands on Mathcad, you'll never do math the same way again.

Call: 617-577-1017

Fax: 617-577-8829

1-800-MATHCAD



scratch pads. Or jamming them into spreadsheets. Or pounding away at code on their keyboards.

Which is all quite unnecessary when you consider that Mathcad provides a faster, more natural, less error-prone alternative. Simply enter equations anywhere on the worksheet. Graph results in 2-D and 3-D. Change variables and instantly update answers. Add text to support your work.

Sum just by clicking.

Optional Electronic Handbooks* give you instant access

FREE Mathcad Working Model.



The Mathcad Working Model includes a concise demonstration and a fully functioning version of the product. It's the best way to introduce yourself to the power and ease of Mathcad.

Name _____

Title _____

Company _____

Address _____

City _____

State _____

Zip _____

Country _____

Phone _____

SPECIFY:

☐ PC Windows™

☐ PC DOS ☐ UNIX®


☐ Macintosh®

☐ 3 1/2" ☐ 5 1/4" Diskette

MathSoft, Inc. 201 Broadway, Cambridge, MA 02139 USA • Phone: 1-800-628-4223 • 617-577-1017 • Fax: 617-577-8829

For information on Mathcad distributors outside of the U.S., contact MathSoft USA © 1992 MathSoft, Inc. TM and ® signify manufacturer's trademark or registered trademark respectively.

*Electronic Handbooks require Mathcad 3.1.



A calendar featuring each month breathtaking four-color photographs of the space shuttle in action! Dates and space launches from the 1960s to present included. Printed on deluxe coated stock with laminated colorful covers.
Only \$10.95.

Send _____ NASA Calendar(s) at \$10.95 each. Add \$5.00 for shipping and handling charges. Orders from \$51.00 to \$100.00 add shipping and handling charge \$8.50 (NY residents add sales tax to total)
TOTAL ENCLOSED \$ _____

Name _____

Company _____

Address _____

City/State/Zip _____

Mail to: NASA Tech Briefs, Dept. F,
41 East 42nd St., # 921

New York, New York 10017

For credit card orders call
(212) 490-3999

Machine Tests Optical Fibers in Flexure

Candidate fibers can be screened inexpensively.

Lewis Research Center, Cleveland, Ohio

A machine repeatedly flexes a single optical fiber or a cable or bundle of optical fibers at low temperature. The machine is inexpensive to build and operate. It tests under repeatable conditions so that candidate fibers, cables, and bundles can be evaluated for general robustness before they are subjected to expensive shock and vibration tests.

The machine bends specimens back and forth over a 45° angle, forcing them around mandrels of 1/2-in. (12.7-mm) diameter while they are immersed in liquid nitrogen at a temperature of -300 °F (-184 °C). The flexure assembly fits in the top part of a liquid-nitrogen Dewar flask (see figure). The lower end of the specimen is held in a narrow metal supporting tube. The specimen passes between the two mandrels, which are mounted on an epoxy/glass circuit board at the upper end of the supporting tube.

The upper end of the specimen passes through a hole in a piston rod. The temperature at this end is well above that of liquid nitrogen. The piston reciprocates left and right, bending the specimen over the mandrels alternately. Tape compatible with

the reference frame that rotates with the hub and blades.

This work was done by Anatole P. Kurkov

of Lewis Research Center. For further information, Circle 55 on the TSP Request Card. LEW-15287





Figure 2. The **Outputs of the Photodetectors** are processed into data on the bending and twisting of the blades. These are measurement traces from a high-speed test of a 0.61-m-diameter rotor equipped with composite-shell blades.

Liquid Nitrogen Surrounds the Specimen as is bent back and forth by the motion of the piston.



liquid oxygen covers the edges of the hole in the piston rod to protect the specimen from abrasion.

A function generator sends electrical pulses, at a rate of about once per second, to a solenoid valve, which admits pressurized nitrogen to the cylinders at opposite sides of the piston in alternation, thus driving the piston back and forth. An electronic

counter measures the pulses, and thus the number of cycles. Typically, a specimen is subjected to 10,000 cycles.

This work was done by Hadi Darejeh, Henry Thomas, and Ray Delcher of Rockwell International Corp. for Lewis Research Center. No further documentation is available. LEW-15128

C.ITOH

D880 Graphic LCD Module

**Introducing our
full line of
Design Tools!**



C.ITOH now introduces all the tools for speeding the time to market for building panel displays. Every aspect is considered in the application of the D880:

- DK800 Multi-Function Development System
- DC800 Intelligent Controller
- Legend - Font Maker Software
- DB840/845 PC Boards
- DU848 Keyboard
- DM800 Development Module
- DS800 Custom Socket
- DP800 Panel Mount & Waterproof Housing
- DU800 Demonstration Unit

**Announcing our complete
Multi-Function Development
System and support products
to fit every application!**

Our unique LCD keyswitch puts a simple man-machine interface at your fingertips. Communication is simplified through use of this compact size programmable graphic module with multi-color backlight.

The D880 integrates a low power graphic LCD, utilizing super twist technology, with a custom IC Driver - all on a key cap of a single pole, single throw, momentary contract switch with dimensions of .9 x .75 x .88". The D880 consists of 864 pixels in a 24 x 36 matrix which provides full screen graphics.

*For Technical Manual, Reliability Data
or more information, please call:*

C.ITOH

C.ITOH TECHNOLOGY, INC.

Electronics Components Division

2515 McCabe Way • Irvine, CA 92713-9657

(800) 347-2484, Extension: 4529 • Fax: (714) 757-4423

Distributed in the U.S. by DIGI-KEY • (800) 344-4539 • In Canada, contact: SACO CONTROLS • (514) 745-0310



Electronic Components and Circuits

Dummy Cell Would Improve Performance of Fuel-Cell Stack


An inactive cell would reduce the loss of heat and help prevent flooding.

Lyndon B. Johnson Space Center, Houston, Texas

The interposition of a dummy cell between a stack of alkaline fuel cells and the accessory section of a fuel-cell powerplant has been proposed to overcome operational deficiencies that plague the end-most active cell. For example, the voltage drop in the end active cell is usually several millivolts greater than that in other cells. The greater voltage drop signifies that the end cell operates somewhat wetter than the other cells, and this greater wetness is likely the result of a lower operating temperature, which is, in turn, believed to be a result of poor distribution of coolant and incomplete insulation in the end zone. In addition, the active end cell is the cell that is most vulnerable to flooding with water from the accessory section when the stack is tipped during handling. When there is too much water in a cell, the recirculation of hydrogen does not suffice to remove it, and the water can block the flow of hydrogen, so that the cell no longer generates power.

The dummy cell would contain no electrolyte and would be inactive but would otherwise resemble the other cells. The dummy cell, in combination with an additional hydrogen/coolant separator plate (see figure), would ensure that enough

The **Dummy Cell** in combination with the additional hydrogen/coolant separator plate would keep the end cell warmer and drier. The end cell is 96th in a stack of fuel cells.



heat is retained in the active end cell so that its thermal condition and performance matched those of the interior cells. The additional hydrogen channels in the dummy cell would act as a sump, where condensation entering the stack of fuel cells from the accessory section would be collected before it reached the active cells. The ample heat in the hydrogen/coolant separator

plate could evaporate large amounts of collected water. Moreover, the wicklike dummy cell would trap water until it evaporated; this water would not be spilled into the active end cell if the stack were tipped.

This work was done by G. T. Suljak of International Fuel Cells for **Johnson Space Center**. No further documentation is available. MSC-21919


Low-Crosstalk Composite Optical Crosspoint Switches

Performance is enhanced by increasing the number of elementary switches.

John F. Kennedy Space Center, Florida

The term "composite optical switch" denotes an integrated optical waveguide crosspoint switch in a switch matrix of an optical communication system. Each composite optical switch contains two elementary optical switches connected to each other and to optical absorbers in such a way that the crosstalk in one of two states of the switch is substantially less than that of an elementary switch acting alone. The principal advantage of the composite-optical-switch concept is that the crosstalk can be reduced to an acceptably low level at the moderate cost of doubling the number of elementary switches rather than at the greater cost of tightening manufacturing tolerances and exerting more-precise control over operating conditions.

Figure 1 illustrates the two modes or states of operation of an elementary four-port reversing optical switch, which con-



tains an electro-optical switching medium. Depending on the voltage applied to the medium, the switch is in state A or state B. In state A, which is designated the "off" state, the fraction of optical input power leaked between the X and Y channels is ϵ_a ; in this state, the signal-to-crosstalk ratio is $(1 - \epsilon_a)/\epsilon_a$. In state B, which is designated the "on" state, the fraction of optical input power leaked from the X (or Y) input

line to the X (or Y, respectively) output line is ϵ_b , and the signal-to-crosstalk ratio is $(1 - \epsilon_b)/\epsilon_b$.

Figure 2 illustrates the operation of the composite switch, in which both elementary switches are simultaneously in either state A or state B. In state A, the leakage between the X and Y channels is only ϵ_a^2 , and the signal-to-crosstalk ratio is $(1 - \epsilon_a^2)/\epsilon_a^2$. In state B, the leakage is ϵ_b as in an elemen-

Figure 11. An **Elementary Four-Port Optical Switch** operates in two modes or switching states. Leakage occurs in both states (after Soref and Schissler).

NOW YOU CAN SHAKE AND RATTLE AND ROLL.

Now you can acquire, display, analyze, react, store. Simultaneously. In real time.

As long as you're using a real-time solution from Concurrent Computer Corporation, you can't overload.

Today's test environments demand dynamic-analysis systems with virtually unlimited performance and based on standards.

That's why engineers at most of the world's leading automotive and aerospace test centers insist on Concurrent for their most demanding real-time measurement and control solutions. Shock. Fatigue. Structural analysis. And more.


If you have critical data coming at you from every direction, and you've got just one shot to get the results — count on getting them right. Count on Concurrent, the real-time measurement and control specialist.

For a free, stimulating paper on "Balancing Response, Throughput, and Computation in Standards-Based Real-Time Systems," call Concurrent at 1-800-631-2154 (USA and Canada only) or write: Concurrent Computer Corporation, Dept. MAS, 2 Crescent Place, Oceanport, NJ 07757 USA.



**ALL WE DO IS REAL TIME.
ALL THE TIME.**

For More Information Circle No. 339






Figure 2. The **Composite Optical Switch** includes two elementary optical switches in tandem, plus optical absorbers. Like elementary optical switches, composite optical switches can be assembled into a switch matrix.

tary switch, and the signal-to-crosstalk ratio is $(1 - \epsilon_b)^2 / \epsilon_b$. Because ϵ_a and ϵ_b are usually much smaller than 1, the signal-to-crosstalk ratio of a typical composite switch in state A is much greater than that of an elementary switch. The signal-to-crosstalk ratio of a typical composite switch in state B is slightly less than that of an elementary switch, but this does not matter in those applications (e.g., the one described below) in which the X output lines are not used. Switch configuration depicted in Figure 2 are feasible and viable, fabricated in the form of integrated optical circuits.

An $n \times n$ matrix of composite optical switches includes n redundant output ports (the X outputs) and n redundant input ports (the Y inputs), all $2n$ of which are terminated in optical absorbers to eliminate unwanted reflections. The matrix is addressed in the usual way; that is, at any given moment, no more than n of the n^2 switches are in state B (the "on" state), and no more than 1 switch is on in any row or column. If the leakage is greater in one electro-optical switching state than in another, then the matrix should be designed so that the state of greater leakage is state B ($\epsilon_b > \epsilon_a$): when this is done, the signal-to-crosstalk ratio of each composite switch in state A will be minimized, and the leakage through each composite switch in state B will be dumped harmlessly into an absorber on the right side of the matrix.

This work was done by Jing-Jong Pan and Frank Liang of E-Tek Dynamics, Inc., for **Kennedy Space Center**. For further information, Circle 61 on the TSP Request Card.

KSC-11405

Improved Grid-Array Millimeter-Wave Amplifier

Input and output are decoupled by virtue of orthogonal polarizations.

NASA's Jet Propulsion Laboratory, Pasadena, California

Improved grid-array amplifiers that operate at millimeter and submillimeter wavelengths are being developed for use in communications and radar. A grid-array amplifier is a quasi-optical two-dimensional array of gridlike antenna elements and amplifiers that operate in phase lock with each other. Prior grid-array amplifiers were constrained to operate as oscillators because their inputs and outputs shared common polarizations and were therefore coupled, giving rise to feedback and the resulting oscillations. In the improved grid-array amplifiers, feedback is suppressed by making the input polarizations orthogonal to the output polarizations.


A typical improved grid array includes an outer horizontal polarizer (a grid of vertical wires) on the input side, an outer ver-

tical polarizer (a grid of horizontal wires) on the output side, and an array of antenna elements and amplifiers between the two polarizers (see figure). Each unit cell of the array contains two amplifying devices — typically, heterojunction field-effect transistors. The transistors are mounted in a differential configuration, the geometrical and electrical symmetries of which are such as to promote isolation between input and output and to suppress the undesired coupling of radio-frequency power into the dc-bias conductors.


The input horizontal and the output vertical antenna elements are connected to the gate and drain terminals, respectively, of the transistors. To a first-order approximation limited by the small nonlinearities of and differences between the transistors,

the instantaneous drain currents of the two transistors differ from the zero-signal dc value by equal (in size) but opposite amounts. Consequently, the instantaneous combined current flowing from the common drain terminal through the circuit board to the bias line at the middle of the unit cell is always nominally the zero-signal dc value. Similarly, the output-antenna terminals at the upper and lower edges of the unit cell carry oppositely varying currents that sum, to first order, to the zero-signal dc value. This first-order cancellation of radio-frequency currents on the dc-bias lines removes some of the geometric constraints on the design of the bias lines and reduces the radio-frequency losses associated with such currents.

Like any amplifier, the grid-array ampli-



GRID-ARRAY AMPLIFIER



The **Grid-Array Amplifier** is a quasi-optical assembly of electronic devices that features polarization-isolated input and output and a differential electrical configuration that suppresses radio-frequency currents on the dc-bias conductors.

fier can be made to oscillate by introducing some feedback. For example, the input polarizer could be replaced by a mirror to reflect horizontally polarized waves back in, and the output polarizer could be tilted slightly from vertical polarization, the amount of tilt being adjusted to adjust the proportion of output power fed back to the input. Several grid-array amplifiers could also be concatenated to form a high-gain beam-amplifying unit; in such a case, each successive stage would be oriented with a polarization orthogonal to that of the pre-


ceding and succeeding stages.

This work was done by James J. Rosenberg, David B. Rutledge, R. Peter Smith, and Robert Weikle of Caltech for **NASA's Jet Propulsion Laboratory**. For further information, Circle 39 on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, NASA Resident Office - JPL [see page 20]. Refer to NPO-18548.

Stereo Viewing

Crystal EYES[®]



Affordable 3D Stereo Visualization for Computer Graphics

- ☐ Scientific Visualization
- ☐ Molecular Modeling
- ☐ Mapping
- ☐ CAD/CAM/CAE
- ☐ Computer Generated Images
- ☐ Video Images

- Increase Design Productivity
 - Enhance Wireframes/Solids
 - Reduce Time to Market
 - Improve Design Presentations
 - Understand Complex Images
- ... On All Workstations

**New 3D stereo
view/record/playback
video system**

Call Toll Free
for Complete Information on
Stereo Viewing Products
& To Order

StereoGraphics[®]

800-783-2660

2171 East Francisco Blvd.
San Rafael, CA 94901
Fax 415-459-3020

For More Information Circle No. 503

Books and Reports

These reports, studies, handbooks are available from NASA as Technical Support Packages (TSP's) when a Request Card number is cited; otherwise they are available from the National Technical Information Service.

High-Temperature-Superconductor Films in Microwave Circuits

Fabrication, characterization, and applications are discussed.

A report discusses recent developments in continuing research on the fabrication and characterization of thin films of high-temperature superconducting material and the incorporation of such films into microwave circuits. This work is motivated by the prospect of exploiting superconductivity to reduce electrical losses and thereby enhance the performances of such critical microwave components as ring resonators, filters, transmission lines, phase shifters, and feed lines in phased-array antennas.

The basic problem in fabrication is (1) to deposit a film of the desired high-temperature superconductor (e.g., $\text{YBa}_2\text{Cu}_3\text{O}_7$) on a low-dielectric-constant, low-loss substrate in such a way that the film has a

high critical temperature (e.g., near the limiting value of 77 K in the case of $\text{YBa}_2\text{Cu}_3\text{O}_7$), high critical current density in the superconducting phase, and low surface resistance in the normally conducting phase; and (2) to pattern the film into a microwave component — possibly one of the components mentioned above. In this study, the films were deposited epitaxially onto heated substrates of lanthanum aluminate and other dielectrics by laser-beam ablation from targets made of the superconductor. This laser-beam-ablation process was used because it involves lower temperatures than do other chemical and physical deposition processes; at the lower temperatures, undesired chemical reactions between the substrates and the films are suppressed. Some of the films on lanthanum aluminate substrates were patterned into microwave ring resonators by use of standard photolithography.

The films were characterized in terms of surface resistances as functions of temperature, real and complex microwave conductivities, and zero-temperature penetration depths. At temperatures less than the critical temperature, a microwave ring resonator made with the superconductor

was found to exhibit electrical losses lower than those of a similar resonator made of gold. On the basis of the measurements, it appears feasible to fabricate microwave components that contain high-temperature-superconductor films. To determine suitability for use in advanced communication systems, it will be necessary to evaluate quantitatively the tradeoffs between superconducting microwave components (with the attendant cryogenic systems) and normally conducting microwave components.

This work was done by K. B. Bhasin, J. D. Warner, R. R. Romanofsky, and V. O. Heinen of Lewis Research Center and C. M. Chorey of Sverdrup Technology, Inc. Further information may be found in NASA TM-103235 [N90-28786], "High Temperature Superconducting Thin Film Microwave Circuits: Fabrication, Characterization, and Applications."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700. LEW-15302



New Elmo low light CCD color camera — affordably priced.

For fast action and complete technical specs, call Vince Giovenco or any of our CCD/ITV experts at 1-800-654-7628.

The new Elmo TSN270 Color CCD Camera is a double breakthrough... Minimum illumination of 2 lux and a very affordable price!

Features...

Resolution is over 330 TV lines (H), selectable shutter speeds to 1/10,000 sec, 46 dB S/N, CS and optional C mount lenses, built-in circuitry for auto-iris lenses, auto-white balance and AGC.

The TSN270 Series is available in 24V AC, 12V DC, 120V AC and a power to coax model for use with our acclaimed SSC-8C Two Page Quad Controller.

Compact in size, the 24V AC model weighs a mere 17 oz. and measures 2 3/8" square by 6 1/8" long.

Ask your CCTV systems installer or distributor to demonstrate the superb new Elmo TSN270 Color Camera.

ELMO Mfg. Corp.
70 New Hyde Park Road, New Hyde Park, NY 11040
44 West Drive, Brampton, Ontario, L6T 3T6 Canada


DESIGNING YOUR OWN SWITCHING CIRCUITS? WHY RE-INVENT THE WHEEL?

LOGIC
COMPATIBILITY

SHORT CIRCUIT
PROTECTION

OPTO-
ISOLATION

BUILT-IN
TEST



TELEDYNE SOLID STATE HAS IT!

If your system requires I/O or power switching and you're considering a discrete or hybrid circuit approach we should talk! And here's why —

- We now offer an extensive "menu" of military/aerospace solid state relays for DC, bi-directional, and AC loads from low level to 25 Amps.

- Our latest designs feature "smart" options


such as: output status for built-in test, short circuit protection and CMOS logic compatibility.

- All of our relays are designed and tested to MIL-R-28750 and applicable portions of MIL-STD-883, and most are qualified to existing MIL slash sheets or DESC drawings.

- We've already selected, derated, sourced, and qualified the required chip components, i.e., opto-couplers, drivers, FETs, SCR's, etc.

And if what you need is not in our catalog, call 1-800-284-7007, or FAX 1-213-779-9161. Chances are we're already working on it.

For More Information Circle No. 517

 **TELEDYNE SOLID STATE**

Home Office, 12525 Daphne Avenue, Hawthorne, CA 90250 • Telephone: 213-777-0077 • FAX: 213-779-9161

U.S. REGIONAL SALES OFFICES: EASTERN: (908) 272-0020, SOUTHEAST: (407) 682-9044, NORTH CENTRAL: (708) 529-1060, CENTRAL: (214) 348-0898, WESTERN: (408) 978-8899.
OVERSEAS: GERMANY, 0611-7636-0, ENGLAND: (081) 571-9596, FRANCE: 47-61-08-08, BELGIUM: (02) 673-99-88, JAPAN: (3) 3797-6956.



Robot Avoids Collisions With Obstacles

Infrared sensors detect nearby objects.

John F. Kennedy Space Center, Florida

A developmental robot is equipped with infrared sensors and with a control system that act in concert to enable the manipulator arm to move around obstacles. The robot can avoid collisions with other objects, even when they are moving in unpredictable ways. The control system of the robot requires no prior knowledge of the environment, unlike traditional robot controls, which rely on complete mathematical models of the environment and are at a loss when geometric relationships change or are even partly unknown.

The sensor subsystem includes standard 40-conductor ribbon cable. Forty-pin sockets are attached to the cable at intervals of about 50 mm. An infrared light-emitting diode and a positive/intrinsic/negative photodiode are inserted in each socket. The leads of these diodes are bent

so that each makes contact with a different set of conductors in the ribbon. The diodes can thus be addressed and turned on by energizing the appropriate conductors. The ribbon cable is flexible, and can be conformed to any shape object, and placed on the robot where required.

When a light-emitting diode illuminates an obstacle, the reflection is sensed by the collocated photodetector. The control algorithm for the sensor strives to attain two goals: to move the end effector of the manipulator to a target position and to avoid obstacles. The highest priority goes to avoiding collisions; moving the end effector toward the desired position is permitted only when the path is clear.

The algorithm operates in three modes, depending on the proximity of an obstacle:

- Mode 1. The arm moves the end effec-

tor toward the target, when no objects are in range, at a standard minimum velocity.

- Mode 2. When an obstacle comes within range, the redundant degree of freedom of the arm is used to avoid hitting the obstacle while continuing to move toward the target.

- Mode 3. If the obstacle comes even closer, all the joints of the arm are moved as necessary to avoid hitting the obstacle, even if this entails moving the end effector away from the target.

This work was done by Edward Cheung, Doug Rosinski, and Dan Wegerif of Merritt Systems, Inc., for Kennedy Space Center. For further information, Circle 84 on the TSP Request Card.
KSC-11570

Interface for MIL-STD-1553B Data Bus

Advantages include low power, few integrated-circuit chips, and little need for control signals.

Lewis Research Center, Cleveland, Ohio

An electronic control-logic subsystem acts as an interface between a microcontroller and a MIL-STD-1553B data bus (see figure). This subsystem is made of a relatively small number of integrated circuits. It also places very little additional burden on the power supply and on the other data-processing circuitry: it consumes only about 500 mW of power and requires very little control by the microcontroller.

The control-logic subsystem handles the protocols for the MIL-STD-1553B bus, which is a command/response data bus. A bus controller sends commands to remote terminals to request data. Each remote terminal has a unique address and examines each command to determine whether the command contains that address. If it does, then the remote terminal accepts the command and any associated data, then transmits any data that were requested by the command.

The interface decodes each command word, looking for its address and for the number of data words to be received or transmitted. The interface puts the received command and data words into receiving first-in/first-out memories; it obtains data words to be transmitted from


transmitting first-in/first-out memories.

The interface-control logic circuit is an HD15530 integrated circuit, which provides Manchester II encoding and decoding of the data and checks parity. Three EP610 programmable logic circuits control the receiving, transmitting, address-matching, and word-counting functions.

The interface operates in a "stand-alone" manner except for a "reset" signal from the microcontroller. In effect, the interface acts like a buffer. It has been used

for instrumentation — giving data on voltage, current, and temperature readings. The most recent readings are kept in the first-in/first-out memories and can be sent whenever requested, providing fast response.

This work was done by Bryan L. Davies, Stephen H. Osborn, and Craig C. Sullender of Rockwell International Corp. for Lewis Research Center. For further information, Circle 44 on the TSP Request Card.
LEW-15038



The **Control-Logic Subsystem** (interface) handles the protocols of a MIL-STD-1553B data bus.

Precision Frequency & Time Instruments

Superior performance and reliability at an affordable price. That's the basic philosophy at Stanford Research Systems, a worldwide leader in signal recovery instrumentation for scientific research.

SRS offers a full line of precision electronic test and measurement equipment targeted for both R&D and production applications. SRS products have the features you want, the accuracy you need, the quality you demand, and the low prices which make them truly exceptional values.



Synthesized Function Generators

- 3, 15 or 30 MHz range, all with 1 μ Hz resolution
- Sine, square, ramp, triangle, and arb waveforms
- Logarithmic / linear sweeps and modulation
- Optional GPIB, RS-232 interfaces

DS335 \$995

DS340 \$1595

DS345 \$2195

FFT Spectrum Analyzers

- 476 μ Hz to 100 kHz frequency range
- 90 dB dynamic range
- PSD, octave, THD, band, sideband analysis
- Internal source, network analysis (SR770)
- GPIB, RS-232, printer interfaces, 3.5" DOS drive

SR760 \$4750

SR770 \$6500

Time Interval / Frequency Counter

- 25 ps single shot resolution
- 1.3 GHz max. frequency, 11 digit resolution
- Statistics, Allan variance, histogram outputs
- GPIB, RS-232 and printer interfaces

SR620 \$4500

Pulse / Digital Delay Generator

- 4 delay channels, delays to 1000 seconds
- 5 ps delay resolution with 50 ps rms jitter
- GPIB interface, internal or external timebases

DG535 \$3500

10 MHz Frequency Standard (LORAN-C)

- Cesium clock long term stability (10^{-12})
- Four 10 MHz outputs, adjustable TTL output
- Phase comparator with strip chart output
- GPIB interface, 8' antenna, 100' coax cable

FS700 \$4950



STANFORD RESEARCH SYSTEMS

1290 D Reamwood Ave., Sunnyvale, CA 94089, TEL: (408) 744-9040, FAX: 4087449049

Voice-Recognition System Records Inspection Data

The inspector can remain visually focused on the workpiece.

Marshall Space Flight Center, Alabama

The Main Injector Voice Activated Record (MIVAR) system acts on vocal commands and processes spoken inspection data into electronic and printed inspection reports. The system was devised to improve the acquisition and recording of data from borescope inspections of the interiors of liquid-oxygen-injecting tubes (called "posts" in the rocket industry) on the main

engine of the Space Shuttle. With modifications, the system could also be used in other situations to relieve inspectors of the manual recording of data. The system is particularly advantageous where, as in the original application, it can enhance the flow of work and the quality of the data acquired by enabling the inspector to remain visually focused on the workpiece.


The system includes a personal computer equipped with voice-recognizing, voice-synthesizing, and voice-pattern-memory circuit cards; a microphone to receive vocal input from the inspector; a loudspeaker to issue vocal prompts to the inspector; and the BUG computer program, which governs the acquisition and processing of vocal input. The system also includes another computer that runs the following two programs: (1) The MIVAR program acquires and records inspection data in a structured sequential format specific to the application; MIVAR receives data and sends prompts via BUG. (2) The IDCR program processes the data acquired by MIVAR into a structured report of defects, by category, and prints the report in a prescribed format.

BUG provides for training the system to recognize the vocal patterns of each individual inspector. During a training session, the inspector interacts with the system both vocally and in the conventional manner via a keyboard and video display. BUG prompts the inspector to speak standard commands and standard qualitative and quantitative terms used to describe defects, repeating each several times to establish a range of variations within which recognition can take place. The vocal patterns thus acquired are recorded for subsequent use during inspection. Training is repeated from time to time to update the lexicon to follow subtle changes in the inspector's speech — caused, for example, by changes in health or by changes in rhythm, tone, or volume as a result of experience with the system.

Development of the system continues. One notable deficiency that must be overcome is caused by the physical separation and, therefore, the asynchronism, between the two computers. One of the consequences of this asynchronism is that when BUG misrecognizes a word or phrase, incorrect data can be recorded. In the short term, the inspector can minimize the number of incorrect data by adhering strictly to the error-detection procedures in the instruction manual of the system.

This work was done by Larry L. Rochester of Rockwell International Corp. for Marshall Space Flight Center. For further information, Circle 2 on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Marshall Space Flight Center [see page 20]. Refer to MFS-29780.



Synchronize all computers in your network using the Network Time Protocol running under TCP/IP.

BANCOMM
DIVISION OF DATUM INC.

6541 Via del Oro
San Jose, CA 95119
Tel: (408) 578-4161 or
1 (800) 348-0648
FAX: (408) 578-4165

COLE-PARMER® INSTRUMENT COMPANY

1993 - 1994



... and it's **FREE!**

Just send in the attached card today to reserve your copy of our new 1993-1994 catalog! This indispensable resource contains 1536 pages filled with more than 35,000 quality products.



**Cole-Parmer®
Instrument Company**

Instruments for Research, Industry, and Education

7425 N. Oak Park Avenue

Niles, IL 60714

A Few Good Reasons to Order Our New 1993-94 Catalog . . .

Reason One:

A Wide Range of Products

If you work in Research, Industry, or Education, you need the new Cole-Parmer 1993-94 Catalog! You'll find 1536 pages featuring more than 35,000 quality products.

Reason Two:

Quality Service

Cole-Parmer is dedicated to providing you with quality service. You'll receive helpful assistance whenever you call our Application Specialists, our Sales Staff, or our Customer Satisfaction Associates.

Reason Three:

It's More than Just a Catalog

The Cole-Parmer catalog contains information that you can use every day—application tips, technical information, conversion tables, and extensive chemical resistance charts.

Multiple Pages Intentionally Left
Blank

Demonstration AOTF Imaging Spectrometer

Spectral images of high quality have been obtained.

NASA's Jet Propulsion Laboratory, Pasadena, California

Figure 1 is a schematic diagram of a "breadboard" acousto-optic-tunable-filter (AOTF) imaging spectrometer. As the name suggests, this is an optical system in which an AOTF serves as a spectrally dispersive element that causes the image on the final focal plane to be shifted on that plane by a distance that depends on the wavelength of light emanating from the scene. AOTF imaging spectrometers are expected to prove useful in several applications that involve the identification, via characteristic spectra, of substances in the observed scenes: examples include prospecting for minerals and detecting chemical pollutants.

Light from the scene enters the system through a camera zoom lens, which forms a real image on a first image plane. The light from the real image passes through a TeO_2 AOTF to a relay lens, which forms a virtual image that is viewed by a charge-coupled-device (CCD) video camera equipped with a zoom lens.

Acoustic waves driven by a radio-frequency generator give rise to an index-of-refraction grating in the AOTF. The frequency of the driving signal can be varied to vary the spatial period of the grating, thereby varying the angle of diffraction of each spectral component of the light traveling toward the relay lens.

In this case, the system is configured so that in the wavelength range of interest, only light from first-order diffraction of the ordinary beam in the TeO_2 medium contributes to the virtual image viewed by the camera. As the AOTF is scanned in wavelength and the angle of diffraction changes, the virtual image viewed by the camera shifts laterally. The operations of the radio-frequency generator and camera are controlled by a personal computer, which also processes, stores, and controls the display of spectral image data.

The upper part of Figure 2 shows results of a demonstration in which the system was aimed at a synthetic ruby on a light-green paper illuminated by a sunlamp. This is a mosaic of images made in spectral bands centered at wavelengths from 750 nm to 500 nm. The spectral images show that the ruby fluoresces in the deep red with a peak at 694 nm and absorbs strongly in the blue-green region. The background paper lights up in the blue-green region, as one would expect.

This work was done by Tien-Hsin Chao, Jeffrey Yu, and Li-Jen Cheng of Caltech for NASA's Jet Propulsion Laboratory. For further information, Circle 48 on the TSP Request Card.

This invention is owned by NASA, and

a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial develop-

ment should be addressed to the Patent Counsel, NASA Resident Office-JPL [see page 20]. Refer to NPO-18410.




Figure 1. The Camera Views a Virtual Image formed in diffracted light. The angle of diffraction (and, therefore, the apparent lateral position of the virtual image) depends on the wavelength of the light.




Figure 2. Each Image in this mosaic shows a synthetic ruby on a green background in 1 of 24 spectral bands. Wavelengths decrease in sequence along each column from top to bottom, then from left to right in going from column to column.

Books and Reports

These reports, studies, handbooks are available from NASA as Technical Support Packages (TSP's) when a Request Card number is cited; otherwise they are available from the National Technical Information Service.

Differential Interferometry for Spacecraft Navigation

Accurate angular-measurement technique can help navigate future Mars missions.

In an extension of Earth-based differential navigation techniques (e.g., GPS and LORAN) to the challenge of interplanetary spacecraft navigation, a report proposes the use of differential very-long-baseline interferometry (Δ VLBI) to measure very accurately the angular separation, as viewed from Earth, of two spacecraft near another planet. One of the spacecraft would be in orbit around the planet on a trajectory that had already been determined accurately, relative to the planet, by conventional Doppler tracking. The other spacecraft would be approaching the planet. The idea is to use the Δ VLBI "tie" between the two spacecraft and the previously determined "tie" between the orbiter and the planet to increase the accuracy of navigation of the approaching spacecraft relative to the planet.

Each spacecraft would transmit microwave signals at two different frequencies, called "VLBI tones." Two widely separated ground stations would aim their antennas alternately at one spacecraft, then at the other during integration periods typically a few minutes long. During each integration period, the stations would track phases of the two signals from one of the spacecraft by use of a closed-loop digital tracking receiver.

A quantity called the "one-way range observable," τ_{ij} , would be computed from the observation of spacecraft j by station i :

$$\tau_{ij} = \frac{\phi_{ij}(v_{j1}) - \phi_{ij}(v_{j2})}{v_{j1} - v_{j2}}$$

where v_{j1} and v_{j2} are the frequencies of the two VLBI tones of spacecraft j . By differencing between stations, one would obtain the interferometer delay, or differenced one-way range, for spacecraft j :

$$\tau_j = \tau_{1j} - \tau_{2j}$$

The final "observable" quantity, τ , would be computed by taking the difference between the differenced one-way range observables of the two spacecraft:

$$\tau = \tau_A - \tau_B$$

This double-differenced range observable would provide a sensitive measure of the relative angular position of the approaching spacecraft relative to the orbiter:

$$\tau = \frac{1}{c} \mathbf{B} \cdot (\hat{\mathbf{S}}_A - \hat{\mathbf{S}}_B)$$

where \mathbf{B} is the baseline vector between

the ground stations, c is the speed of light, and $\hat{\mathbf{S}}_A$ and $\hat{\mathbf{S}}_B$ are the unit vectors in the directions of the approaching and orbiting spacecraft, respectively. The final angular accuracy would thus be directly related to the total error in the Δ VLBI delay.

One significant advantage of the second subtraction is that it would cancel some Δ VLBI errors that are common to both spacecraft observables; these errors increase or decrease along with the angular separation between the spacecraft. Thus, the most accurate differential angular tracking would be obtained when it is most needed — when the spacecraft are close.

Preliminary calculations have been performed for a pair of spacecraft near Mars with VLBI tones at about 8.4 GHz separated by 40 MHz or VLBI tones at about 32 GHz separated by 400 MHz. If the spacecraft are observed on a 5-minute cycle with an integration time of 2 minutes on each spacecraft and 1 minute allowed for sluing the antennas between spacecraft, then at angular separations of a few degrees, the accuracy of the Δ VLBI measurement of the angular separation should be of the order of a few nanoradians. Such a capability could help to enable future missions to Mars, incorporating ambitious aerobraking maneuvers to achieve orbit insertion.

This work was done by Charles D.

Edwards, James S. Border, William M. Folkner, and Lincoln J. Wood of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Spacecraft-Spacecraft Very Long Baseline Interferometry For Planetary Approach Navigation," Circle 70 on the TSP Request Card. NPO-18417


Effects of Environmental Electrical Charges on Spacecraft

A handbook addresses surface and internal charging and discharging, single-event upsets, and related design issues.

A handbook presents information on three kinds of disruptive effects of environmental electrical charges upon the operations of electronic circuits and other sensitive equipment in spacecraft. These three effects are the following:

1. Electrostatic surface discharge, which occurs when differential charge accumulated on adjacent surface areas becomes sufficient to cause dielectric breakdown between those areas. The charge comes from the plasma of outer space and/or photoemission caused by ultraviolet radi-

FOR A TOUGH CASE GET HARDIGG™



Lightweight, MIL-SPEC off-the-shelf protection against shock, vibration, moisture, temperature extremes.



HARDIGG™ CASES
A Division of Hardigg Industries, Inc.

393 No. Main Street, P.O. Box 201, South Deerfield, MA 01373 (413) 665-2163 FAX: (413) 665-8061

For More Information Circle No. 478

Real Time Video On Workstations



The RGB/View™ System for Mission Critical Applications

The RGB/View displays live TV or other full motion video on workstations and high resolution displays. The RGB/View accepts video signals (NTSC or PAL) from a camera, tape recorder, videodisc or built-in TV tuner. FLIR input is also available. True color video is displayed full screen or as a scaleable window.

- Real time video under all conditions
- No impact on graphics performance
- Image capture
- Text and graphics overlays on video
- Scale, reposition, freeze
- X-Windows compatible
- Cable ready tuner
- Priced from \$7500.00

Applications include C3I, robotics, interactive videodisc training, video teleconferencing, process control, surveillance and simulation.

Standalone peripheral and board level models available

GSA Contract #GS03F2032A



SPECTRUM®

950 Marina Village Parkway
Alameda, CA 94501

Tel: (510) 814-7000 Fax: (510) 814-7026

For More Information Circle No. 469

ation from the Sun.

2. Internal discharge, which occurs when radiation penetrates the spacecraft and causes differential charging of interior points up to the breakdown level. Because internal discharges can take place within electronic circuits, their consequences can be more adverse than are those of equivalent surface discharges.
3. Single-event upset (SEU), which occurs in a microelectronic circuit when a single charged particle, usually a heavy ion or proton, deposits enough charge to change the binary logic state of the circuit, thereby creating a false datum.

The handbook devotes a full chapter to each phenomenon, discussing its environmental source, the physical mechanisms by which it affects a spacecraft and its electronic circuits, and methods of prediction. Another chapter discusses methods of designing, testing, and monitoring to make spacecraft immune to failures caused by these phenomena. The book contains several appendixes, including a bibliography, glossary, list of computer codes, and list of sensors and detectors for monitoring charged particles and discharges.

This work was done by Paul A. Robinson, Jr., of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Spacecraft Environmental Anomalies Handbook," Circle 81 on the TSP Request Card.
NPO-18350

More About Laser Scanner Tests for Single-Event Upsets

Laser-scan and heavy-ion data are found to be correlated within a factor of two.

Two reports describe preliminary theoretical and experimental studies based on the method described in "Laser Scanner Tests for Single-Event Upsets" (NPO-18216), *NASA Tech Briefs*, Vol. 16, No. 2 (February 1992), page 36. To recapitulate from the noted prior article: The laser-scanning method of testing for single-event upsets is intended to overcome the disadvantages of, complement, and/or substitute for the more-expensive cyclotron-testing method, which does not provide spatial resolution. In the laser-scanning method, picosecond pulses of light from a dye laser are focused at selected locations of the electronic device under test to determine the spatial dependence of its vulnerability to single-event upsets. The wavelength of the beam can be adjusted to a number of values above or below the gap between the valence and conduction electron-energy bands of the semiconductor device material to vary the effective depth of penetration into the device. Thus, the

laser-scanning method provides data that are spatially resolved in all three dimensions.

The device tested in the experiments was a commercial 256K n-channel metal oxide/semiconductor dynamic random-access memory, each memory cell of which consisted of an access transistor and a storage capacitor. Each memory cell occupied an area of about $50 \mu\text{m}^2$, and the area of the laser spot on the surface of the device was about $1.8 \mu\text{m}^2$. In some tests, the cells were initially in the "one" (charged) logic state, in which they are most sensitive to single-event upsets; in other tests, they were initially in the relatively insensitive "zero" (discharged) state. Bit maps of the upsets in affected memory cells were made at various wavelengths, pulse energies, and bias voltages applied to the sensing amplifiers through which the contents of the memory cells are read out. Bit maps made from the data showed the bit errors in cells in the vicinity of the laser spot.

According to the applicable theory of single-event upsets, an upset (the flip of a memory cell to the opposite logic state) occurs when the incident laser pulse or energetic ion excites a sufficient number of charge carriers that the charge collected at the affected junction of the device exceeds a critical value. In these studies, diffusion was regarded as the predominant physical mechanism for the transport of charge from the ion track or laser beam to the affected junction or junctions. A mathematical model of the bit-error response of the device, based on the theory of diffusion, was calibrated by the multiple-bit-error laser-scan data and the result compared with data on bit errors produced by exposure to energetic heavy ions. The two sets of data were found to agree within a factor of two.

This work was done by Quiesup Kim, Larry D. Edmonds, and John A. Zoutendyk of Caltech and Harvey R. Schwartz of Trend Western for NASA's Jet Propulsion Laboratory. To obtain copies of the reports, "A Study of Multiple-Bit Errors in an NMOS DRAM by a Picosecond Pulsed Dye Laser" and "Diagnosis of NMOS DRAM Functional Performance as Affected by a Picosecond Dye Laser," Circle 82 on the TSP Request Card.
NPO-18494

Telemetry Tests of the Advanced Receiver II

Performance was at least as good as that of two other receiving subsystems.

A report describes telemetry tests of the Advanced Receiver II (ARX-II) — a digital radio receiving subsystem that operates on the intermediate-frequency output of another receiving subsystem called the "multimission receiver" (MMR), that detects

carrier, subcarrier, and data-symbol signals transmitted by spacecraft, and that extracts Doppler information from the signals. The tests were performed in a laboratory called "Compatibility Test Area 21," using signals supplied by a test apparatus called the "telemetry simulator assembly" (TSA).

To obtain data for comparison, the MMR and ARX-II were tested simultaneously and in parallel with two different receiving systems: (1) a receiver of another type called "Block III" (Blk-III) followed by a baseband processor assembly (BPA) and (2) the Block-III receiver followed by a subcarrier-demodulation assembly (SDA) and a symbol-synchronization assembly (SSA).

The signal produced by the TSA and associated equipment was a 2,295-MHz carrier modulated by a square-wave subcarrier that was, in turn, phase-modulated with a pseudorandom sequence that imitated a stream of telemetry bits. The symbol signal-to-noise ratio (SSNR) and the symbol-error rate (SER) of each receiving system were measured. The decoded outputs of all three receivers were sent to a computer for processing into bit-error rates. The foregoing measures of performance of the three systems were mapped into an equivalent common measure called the "equivalent symbol signal-to-noise ratio" (SERSNR) to enable comparisons.

Data were accumulated at bit rates from 16 s^{-1} (typical of the Pioneer spacecraft) to 268.8 ks^{-1} (typical of the high-rate data channel of the Magellan spacecraft). Analysis of the data showed that the performance of the MMR/ARX-II system was comparable and sometimes superior to the performances of the Blk-III/BPA and Blk-III/SDA/SSA systems.

This work was done by Sami M. Hinedi, Roland P. Bevan, and Miguel Marina of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "The Advanced Receiver II Telemetry Test Results in CTA-21," Circle 12 on the TSP Request Card.
NPO-18459

Development of Infrared Imager for Spacelab

A terrestrial instrument is modified for use in outer space.

A report discusses progress in the development of an infrared-imaging instrument for use in microgravity scientific experiments in a manned module in the payload bay of the Space Shuttle. This imager is intended primarily for the characterization of surface temperatures in a microgravity fluid-physics experiment. The design of the imager was to be as versatile as possible so that the instrument could serve as an "off-the-shelf" unit for other experiments, eliminating the need to du-

plicate development and qualifications for spaceflight for future experiments.

Because a limit on overall development time (15 months) was the major consideration, the development team chose existing technology to eliminate uncertain development work. It was decided to modify a commercial (Inframetrics™ Model 600) scanning infrared radiometer to satisfy the requirements of the experiment and of spaceflight while maintaining the basic performance characteristics of the commercial instrument.

Some of the modifications were necessitated by the environment during launch and orbit, while others were specific to the experiment. Because of the vibrations that occur during launch, a more-rugged military scanning mechanism was used in place of the standard scanning galvanometers of the original instrument. A liquid-nitrogen Dewar that cools the detector in the original instrument was replaced by small, lower-power, closed-Stirling-cycle cooler. A 7-bit analog-to-digital converter was replaced by an 8-bit converter to increase the dynamic range. Where possible, the electronic components on each printed-circuit board were replaced with MIL-STD electronic components; this change required modifications of the patterns of three of the five printed-circuit boards. Components for which there were no MIL-STD equivalents were replaced by equivalent screened, derated commercial components of higher quality.


The method of mounting the printed-circuit boards was changed to facilitate the dissipation of heat and to increase the tolerance of vibration. Because the power consumed by the electronics was low, active cooling was not necessary. The external structures of the instrument were pressurized and sealed to contain any toxic gases that might emanate from the enclosed materials. A microprocessor was added to the experiment-controlling computer (which is in an enclosure separate from that of the imager) to perform several functions related to automatic gain control, including selection of the temperature range. The spectral passband was tailored by selectively coating windows in the optical path.

This work was done by Alexander D. Pline and Robert L. Butcher of Lewis Research Center, and Michael Conneley of Barnes Engineering Division of EDO Corporation. Further information may be found in NASA TM-102503 [N90-18752], "Space-lab Qualified Infrared Imager for Microgravity Science Experiments."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700.

LEW-15188

Display, Record and Transmit Signals from Multiple Video Sources



OmniView™

4X

the resolution of video systems

- Monitor multiple video signals
- Record and playback at full video resolution on a standard tape recorder
- Transmit on a single channel
- Process up to 15 video signals simultaneously
- Position and scale each video window independently

Applications include
surveillance, training,
human factors engineering,
video teleconferencing



SPECTRUM®

950 Marina Village Parkway
Alameda, CA 94501
Tel: (510) 814-7000
Fax: (510) 814-7026

For More Information Circle No. 479



Mapping Temperatures on Heat Pipes

Paints containing thermochromic liquid crystals make isotherms visible.

John F. Kennedy Space Center, Florida

Paints containing thermochromic liquid crystals (TLC's) can be used to map the temperatures on (and thereby assess the thermal performances of) heat pipes and thermosyphons. The color of a thermally sensitive TLC coat changes reversibly upon heating or cooling. Each distinct color indicates a particular temperature. Thus, transient and steady-state isotherms become visible as colored bands. The positions and movements of the bands yield information about startup transients, steady-state operation, cooler regions containing noncondensable gas, and other phenomena relevant to the performance of a heat pipe.

To prepare for a demonstration of this concept, copper heat pipes 15 mm in diameter and 730 mm long with annular copper mesh wicks were fabricated and charged to a working-mass quality of about 70 percent with refrigerant 12 (dichlorodifluoromethane). The outsides of the heat pipes were coated with a slurry of microencapsulated TLC's. The condenser end of each heat pipe was fitted with a Bourdon-tube pressure gauge and a filling-and-venting valve line as shown in Figure 1.

In a typical experiment conducted as part of the demonstration, the evaporator end of a heat pipe was immersed in an insulated hot-water bath. The rate of transport of heat by the pipe could be quantified by a simple enthalpy balance. Heat was removed from the pipe at the condenser end by free or forced convection of air, or the pipe could be fitted with a water-cooled jacket. Figure 2 represents the distributions of temperature and color along a heat pipe under typical steady-state demonstration conditions.


The heat-transfer behavior of a simple heat pipe of the type just described was compared with that of a solid copper rod that was also coated with TLC's. The lower ends of both were simultaneously placed in hot water baths, and the thermal behaviors visually observed. Immediately upon immersion, a rainbow-colored band began to migrate up the rod, at an initial rate of about 5 mm/s. Approximately 10 s later, when the thermal front had moved only a few centimeters up the rod, the colors of the entire adiabatic and condenser regions of the heat pipe changed quickly, indicating the quick heating of these regions to more nearly isothermal conditions.

Figure 1. This **Heat Pipe** is coated with thermochromic liquid crystals to make the distribution of temperature visible.

After several minutes of steady-state operation, the rainbow-colored region had progressed about 12 cm up the solid rod and had spread over a several-centimeter region; this is characteristic of mild thermal gradients. However, the entire heat pipe continued to be iridescent, with the selective reflection of bright colors. When noncondensable gas (air) was within the heat pipe, a distinct cold region was noticeable above the condenser region. Also noticeable was the compression of the air-filled region during initial heating. When the vent valve on the top of the heat pipe was briefly opened, the air escaped, and the distinct rainbow boundary of the region of noncondensable gas rapidly progressed to the end of the heat pipe.

This work was done by Fred S. Gunnerson and Glen E. Thorncroft of the University of Central Florida for **Kennedy Space Center**. For further information, Circle 97 on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Kennedy



Space Center [see page 20]. Refer to KSC-11577.




Figure 2. The **Distribution of Temperature** along a heat pipe that contains noncondensable gas is revealed by the colors of the TLC paint on its outer surface.

Real-World Solutions for World-Class Designs

The National Design Engineering Conference

March 8-10, 1993 • McCormick Place North • Chicago Illinois

Sponsored by the American Society of Mechanical Engineers



To achieve world-class quality, you need a constant flow of new ideas. You need practical solutions you can put to work immediately. Solutions that deal directly with the design challenges you're facing in the real world.

That's why you need the National Design Engineering Conference. (NDEC)

NDEC, a three-day conference held concurrently with the National Design Engineering Show, lets you choose from over 50 application-oriented sessions conducted by leading industry experts.

Learn how to better evaluate and select the right design technologies. How to predict and control costs. Shorten your time-to-market window. And keep your products on the leading edge of design.

Conference sessions will cover five key subject areas: Personal Development • Hot Topics/New Technologies • Materials • Case Studies • Design for Manufacturability.

New CAD/CAM Conference focuses on Design Quality Sponsored by CAE Magazine



NDEC is introducing "Maximizing CAD/CAM for World-Class Quality". A management-level conference focusing on getting the most out of your existing CAD/CAM capabilities. You'll also learn how to select additional systems to increase your productivity. And how to best train your CAD/CAM engineers.

Save up to 20%! Register by February 5!

Take advantage of pre-registration discounts. Register by February 5 and take up to 20% off your conference fees! If you're an ASME-member you can save even more! There's also a group discount for three or more colleagues who register together.

For complete program and pricing details, fill out the coupon below. You'll receive a complete Conference Brochure absolutely free. Or faster yet, call us at (203) 352-8239.



National Design Engineering Show & Conference™

March 8-11, 1993 (Exposition Dates)

March 8-10, 1993 (Conference Dates)

McCormick Place North • Chicago, IL

*We help designs make it
in the real world.*

Mail coupon today for your
FREE NDEC Brochure.

**Or faster yet,
call Customer Services
at (203) 352-8239.**



☒ **Yes! Please send me my FREE NDEC Brochure.**

☐ **Please send me more information on the
National Design Engineering Show.**

Name

Title

Company

Address

City/State/ZIP

Telephone

Mail to: NDEC, P.O. Box 3833, 999 Summer Street, Stamford, CT 06905

NAC

Books and Reports

These reports, studies, handbooks are available from NASA as Technical Support Packages (TSP's) when a Request Card number is cited; otherwise they are available from the National Technical Information Service.

Degree of Development of Waves and Bias in Radar Altimetry

An empirical correction for the sea-state bias is developed.

A report discusses the relationship between the degree of development of waves and the sea-state bias (which is defined below) in radar altimetry. The purpose of this and related studies is to increase the accuracy of estimates of sea-state bias and thereby increase the accuracy of estimates of the sea level that would be obtained if the waves at the measurement spot were suppressed. In this study, it is shown that the sea-state bias is related to a parameter called the "pseudo wave age."

The round-trip time of the altimetric radar pulses is directly related to the mean height of the specular facets of the sea surface at the measurement spot, and therefore yields an estimate of the mean

height of the surface of that spot. The design of a typical radar altimeter incorporates the assumption that the statistical distribution of surface elevations in wind-generated waves is Gaussian. In practice, the distribution deviates from Gaussian, and this deviation gives rise to electromagnetic and statistical effects that alter the estimate, by the radar altimeter, of the mean surface height. The sea-state bias (SSB) is the amount of this alteration.

The point of departure of this study is the recognition that the altimetric SSB depends on both the heights and the histories of waves: Newly generated waves are more skewed than older waves are, and consequently, the probability density function of their surface heights is less Gaussian. This concept leads to the notion that the SSB should be a function of some measure of the ages and heights of waves.

The chosen measure of height is the significant wave height ($H_{1/3}$), which is one of the outputs of the radar altimeter. The pseudo wave age mentioned earlier is the chosen measure of age, and it is an extension of the similarly named wave age, which is defined as C/U , where C is the phase speed of the dominant wave and U is the windspeed when the sea is in equilibrium with the wind. (Note that the wave age is not an age, but a dimension-

less number that is plausibly related to age.) The pseudo wave age can be expressed in terms of $H_{1/3}$ and U . Under more-general conditions when the sea is not in equilibrium with the wind, the pseudo wave age does not equal the wave age. Nevertheless, it serves as a rough indicator of the degree of development of waves.

In this study, the general trend in the dependence of the SSB on pseudo wave age was found by analysis of 2.7 years' worth of Geosat data. The analysis confirms the theoretical prediction that for a given $H_{1/3}$, the SSB decreases as the degree of development (as quantified by the pseudo wave age) increases. This empirical trend is modeled as

$$SSB = A \left(\frac{\xi}{\xi_m} \right)^M H_{1/3}$$

where ξ and ξ_m are the pseudo wave age and its average value, respectively; $A = 0.013 \pm 0.005$; and $M = -0.88 \pm 0.37$. Statistically, this model performs slightly better than does a standard model ($SSB = \beta H_{1/3}$, where β is a constant). This model reduces the global root-mean-square error of the estimate of SSB by 1.6 cm. However, the main advantage of the model is that it reduces false geographic and seasonal trends in the mean sea level, the trends associated with geographic and seasonal variability of the wave age.

This work was done by Lee-Lueng Fu and Roman Glazman of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "The Effect of the Degree of Wave Development on the Sea-State Bias in Radar Altimetry Measurement," Circle 34 on the TSP Request Card.

NPO-18392

Calorimetric Vacuum Emissometry at 773 to 923 K


CVE measurements take more time but are more accurate than are those of other techniques.

A report describes the design, construction, and tests of a calorimetric vacuum emissometer (CVE) intended to measure the total hemispherical emittances of materials in a vacuum at temperatures from 773 to 923 K. Results of measurements by the CVE are compared with those of a hohlraum (blackbody) reflectometer and an open-air elevated-temperature emissometer.

The hohlraum reflectometer measures a hemispherical spectral reflectance of a specimen at room temperature, and the open-air emissometer measures the spectral emittance perpendicular to the surface of a specimen at the desired elevated tem-


Tecplot™ New Version 5 Powerful Plotting for Engineers

Other plotting programs must first interpolate your data into a rectangular mesh. This can smooth and distort your data, and destroy boundary information. With TECPLOT interpolation is not required. You can visualize your data in its original mesh structure: rectangular, curvilinear, quadrilateral, triangular, and even ungridded data.



FEATURES: integrated XY, 2D, and 3D plotting • contour lines • color-flooded contours • vector fields • streamlines

- light-source shading • wire frames • interactive and menu driven • text/drawing tools • very large data sets • over 2000 variables per data point • multiple data sets • overlay plots • up to 16 plots per page • fast and easy to use • data




- manipulation • interpolation • triangularization • macros • stylesheets • batch mode • greek/math symbols • output PostScript, EPS, HPGL, and raster formats • very flexible • educational discounts • for 386 PCs and Unix/VMS workstations • 60-day money-back guarantee • call for FREE demo

Call 1-800-676-7568

Amttec Engineering, Inc.

P.O. Box 3633, Bellevue WA 98009
206-827-3304 • Fax 206-827-3989



For More Information Circle No. 534

perature. The total hemispherical high-temperature emittance can be deduced from such measurements, but the deductions are based on mathematical models that involve assumed angular dependences and the assumed constancies of emissivities and reflectivities under changes of temperature.

In contrast, CVE measurements do not depend on mathematical models and are nearly immune from the foregoing complications. The specimen is heated in a vacuum to the desired temperature at which emittance is to be determined, and the walls of the calorimetric cavity collect nearly all the thermal radiation emitted at all angles by the surface of the specimen.

The CVE used in this study was originally designed for use at 323 to 423 K. This instrument was left mostly unchanged, except that its specimen holder and heater were redesigned to enable operation at 773 to 923 K. The modified CVE was used to measure the emittances of plasma-sprayed alumina, carbon paint on stainless steel, arc-textured titanium, sandblasted niobium/zirconium alloy, high-temperature black paint, sanded stainless steel, polished copper, and polished stainless steel. The results of these measurements were compared with those of a hohlraum reflectometer and an open-air emissometer. Differences were attributed to temperature, atmospheric, and directional effects and to errors in the hohlraum and emissometer measurements (± 5 percent). The probable error of the CVE measurements was found to be typically less than 1 percent.


The principal advantage of a hohlraum-reflectometer measurement is that it requires less than an hour, while a CVE measurement takes much longer because of the time required to attach the thermocouple to the specimen, pump down the system, and bring the specimen to thermal equilibrium. Thus, the hohlraum reflectometer is useful for screening or preliminary measurements of, say, candidate thermal-radiator materials. Materials that survive the screening could then be placed in the CVE to obtain more reliable measurements.

This work was done by Michael J. Mirtich and Bruce A. Banks of Lewis Research Center, Curtis Stidham and Michael Kussmaul of Cleveland State University, and Frank DiFlippo of Case Western Reserve University. Further information may be found in NASA TM-102322 [N90-10309], "Total Hemispherical Emittance Measured at High Temperatures by the Calorimetric Method."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700.
LEW-15104

What do YOU want to do?

- ☐ ACQUIRE
- ☐ MANIPULATE
- ☐ INTERPRET
- ☐ REPORT
- ☐ ALL THE ABOVE



When you've acquired up to 4 million measurements in 1/20th of a second, you have a formidable amount of data to handle. That's why Nicolet high precision digital oscilloscopes - up to 14 bits - and multichannel transient analyzers are designed with built-in programming and software to give you complete solutions. With Nicolet, you have the power to do everything you want to do with your data. Now what you want to do is call us. 1-800-356-8088.

Nicolet

INSTRUMENTS OF DISCOVERY

Nicolet Measurement Instruments
Madison, Wisconsin, USA 53711-4495
608/271-3333, FAX 608/273-5061
In Canada call: 800/387-3385



Improved Composite Flexible Blanket Insulation


Lightweight blankets have low effective thermal conductivities.

Ames Research Center, Moffett Field, California

An improved class of composite flexible blanket insulation has been developed by taking advantage of advanced lightweight materials. The insulating blankets were intended originally to protect spacecraft against heating during reentry into the atmosphere but could also be used on Earth where there are requirements for lightweight, flexible, highly efficient insulating materials that can protect people and equipment against temperatures up to about 1,650 °C. They could be used, for example, as furnace curtains and as insulating layers on firefighting equipment and protective clothing.

The figure shows the structure of a typical improved composite flexible insulating blanket. The blanket is stitched together in a quilted pattern with a ceramic thread. The top side is the one that is exposed to the high temperature. The top and bottom layers are made of silicon carbide fabric, preferably with a three-ply interlock weave as shown in the detail at the bottom of the figure. The interlock weave provides a surface density and, therefore, a thermal emittance greater than those of other weaves commonly used in silicon carbide fabrics. This is an advantage in aeroconvective-heating environments like those of the original spacecraft application, in which one relies on outward reradiation of heat from the top surface to reduce the temperature of the top surface and thereby provide part of the thermal protection.

A layer of fibrous ceramic insulating material is sandwiched between the top fabric layer and an intermediate fabric layer. Below the intermediate fabric layers are multiple (typically 10) smooth reflecting layers of Kapton (or equivalent) polyimide film aluminized on one surface. These smooth reflective layers are interspersed with layers of slanted honeycomb also made of plastic film, metal foil, or a combination film like the aluminized polyimide of the reflecting layers. Together, the interspersed layers retard the radiative transfer of heat, and the walls of the honeycomb further retard the convective transfer of heat. Experiments have shown that the singly aluminized smooth reflecting layers insulate more effectively at high temperatures than do the doubly aluminized reflecting layers used




Improved Composite Flexible Blanket Insulation is a quilt of layers of advanced lightweight insulating materials. Each layer is designed to optimize its contribution to the inhibition of the radiative, conductive, and/or convective transfer of heat from the hot side to the cold side.

in some prior multilayer insulating materials. The thermal diffusivity, thermal conductivity, and weight of the honeycomb layers are less than those of prior insulating materials used in the same temperature range.

This work was done by D. A. Kourtides and D. M. Lowe of **Ames Research Center**. For further information, Circle 37 on the TSP Request Card.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Ames Research Center [see page 20]. Refer to ARC-11955.

NEW FROM INCO SPP...
EXTRA FINE NICKEL POWDER



Inco Type 210 Nickel Powder

JUST ADD YOUR IMAGINATION

SEND FOR YOUR FREE SAMPLE TODAY

INCO SPP

Park 80 West-Plaza Two, Saddle Brook, NJ 07662

Shin-Muromachi Building, 4-3 Nihonbashi-Muromachi 2-Chome, Chuo-ku, Tokyo 103 Japan

1-3 Grosvenor Place, London SW1X7EA England


15/FI Wilson House, 19-27 Wyndham Street Central, Hong Kong

For More Information Circle No. 652

3M Reveals New Long Term EMI/RFI Shielding Tape

Tin-alloy coating on both sides of copper foil offers superior solderability, environmental stability.

AUSTIN, Tex. — This new UL Recognized Scotch™ Foil Shielding Tape 1183 employs a tin-alloy coating on smooth copper foil to produce a durable and effective electromagnetic shield.



The tin-alloy coating is on both sides of the copper for thorough protection.

The tape is a tin-alloy coated version of the widely used 3M 1181 Tape and provides shielding when wrapped around flat and round cable, and cable connectors.

The unique electrically-conductive adhesive enables 1183 tape to make electrical connections across

seams and between mating sections, of electronic enclosures ranging from small equipment housings to large shielded rooms. The tape can also shield the energy radiating from seams between the sectors of dish antennas.

The special tin-alloy coating on both sides of the foil provides two significant benefits.

1. Thorough environmental stability and corrosion resistance.
2. Exceptional solderability for applications such as sealing the seams when the tape is used as a shield around cable connectors.

3M 1183 Tape also serves as a corrosion resistant contact surface for conductive gasketing, beryllium copper "spring fingers" or other resilient conducting media used around doors and openings of electronic cabinetry.

For more information about all 3M Foil Tapes, contact a 3M Electrical Specialties Division representative or authorized distributor or call 1-800-328-1368.

3M Electrical Specialties Division
6801 River Place Boulevard
Austin, Texas 78726-9000



Poly(1,2,4-Triazoles) Via Aromatic Nucleophilic Displacement

Synthesis involves nucleophilic displacement of monomers with activated aromatic dihalides.

Langley Research Center, Hampton, Virginia

Novel poly(1,2,4-triazoles) (PT) have been prepared by the aromatic nucleophilic displacement of di(hydroxyphenyl)-1,2,4-triazole monomers with activated aromatic dihalides. The reactions were carried out in polar aprotic solvents such as sulfolane and diphenylsulfone, using alkali metal bases such as potassium carbonate at elevated temperatures under nitrogen. The di(hydroxyphenyl)-1,2,4-triazole monomers were synthesized by reacting bis(4-hydroxyphenyl)hydrazide with aniline hydrochloride at 250 °C in the melt and by reacting 1,3- or 1,4-bis(4-hydroxyphenyl)phenylenedihydrazide with aniline hydrochloride in the melt. Purification of the di(hydroxyphenyl)-1,2,4-triazole monomers was accomplished by recrystallization.


The polymers exhibited desirable physical and thermal properties. Selected characteristics of three polymers are presented in the table in the figure. The inherent viscosities (η_{inh}) of the PT ranged from 1.37 to 3.4 dL/g, and the glass-transition temperatures (T_g) ranged from 192 to 216 °C. One polymer exhibited a crystalline melting temperature (T_m) of 377 °C. Thermogravimet-

ric analysis showed no loss of weight below 300 °C, and a 5-percent loss of weight at approximately 500 °C, in both air and nitrogen.

This route for the synthesis of polymers provides high-molecular-weight PT of new chemical structures, is potentially more economically favorable than other routes, and, because of the availability of a large variety of activated aromatic dihalides, provides for facile variation of chemical structure. These polymers should be useful for producing films, moldings, adhesives, and composites.

This work was done by John W. Connell and Paul M. Hergenrother of Langley Research Center and Peter Wolf of BASF Corp. For further information, Circle 38 on the TSP Request Card.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Langley Research Center [see page 20]. Refer to LAR-14440.



X	η_{inh} , dL/g	T_g , °C	T_m , °C
	2.94	207	ND*
	3.40	216	377
	1.37	192	ND*

*ND = Not Detected by DSC.

Selected Characteristics of Three Poly(1,2,4-Triazoles) are listed.

Books and Reports

These reports, studies, handbooks are available from NASA as Technical Support Packages (TSP's) when a Request Card number is cited; otherwise they are available from the National Technical Information Service.

Research on Bi-Based High-Temperature Superconductors

The bismuth-based high-temperature superconductor system was investigated.

A brief report describes the effects of melt sintering on a Bi-based high-temperature superconductor system, as well as the use of a vibrating-sample magnetometer to determine hysteresis curves at 77 K for partially melt-sintered samples. Also briefly discussed is the production of high-temperature superconducting thin films by laser ablation: such films are potentially very useful in the detection of signals of very low power.

The Bi-based superconductor system studied was $\text{Bi}_2\text{Sr}_2\text{Ca}_{n-1}\text{Cu}_n\text{O}_{4+2n}$, where $n = 1, 2$, or 3. The values of n correspond to phases that have critical temperatures (T_c 's) of 22 K, 85 K, and 110 K, respectively. Experiments were performed in the hope of enhancing the superconducting properties of the 2223 ($n = 3$, $T_c = 110$ K) phase by the substitution of Pb and Sb for Bi. New steps were taken in the preparation to increase homogeneity of Pb and Sb-substituted specimens and to decrease the sizes of particles of powders used to make them: After the initial powders were weighed, mixed, and coarsely ground, they were deposited into a ball mill with ethyl alcohol and ground for several hours. The alcohol was then evaporated from the powder mixture by placing the mixture in a furnace set at a temperature of 200 °C. The remaining sediment was heated in powder form to 810 °C for 20 h, reground, and pressed into pellets under a pressure of 6,000 psi (41 MPa). X-ray diffraction scans demonstrated these preheated powders to be a mixture of 2201 ($n = 1$, $T_c = 22$ K), 2212 ($n = 2$, $T_c = 85$ K), and Pb/Sb-dominated phases.

The attempt to substitute Sb into the 2223 phase proved successful, as determined to the limits of x-ray diffraction measurements. Transport measurements revealed no significant enhancement of the superconducting properties, as previously reported for nominal compositions of this phase.

A surprising melt-sintering effect was discovered in nominally substituted Sb/Bi/Pb compounds. Although specimens of these compounds were initially multiphased, melt-sintering conditions gave rise to film-like regions on the surfaces of the


specimens. These layers were c-axis oriented and consisted of the 2201, 2212, and 2223 phases. The amount of each phase could be controlled by control of the conditions of preparation.

A vibrating-sample magnetometer system was constructed and tuned. This system is capable of magnetic characterization of superconductors and will be used to investigate both specimens prepared in this study and specimens from previous work. This apparatus was used to take hysteresis curves of partially melt-sintered specimens of $\text{YBa}_2\text{Cu}_3\text{O}_7$ at a tempera-

ture of 77 K. The areas enclosed by the curves were found to become larger as specimens that were increasingly melt-sintered were tested. This is a result of more flux trapping in the melt-sintered specimens than in the sintered specimens.

Finally, preliminary steps were taken to set up an apparatus for the production of high-temperature-superconducting thin films by laser ablation. In the laser-ablation process, a high-energy pulse of ultraviolet light (1 to 2 J/cm², 12 ns) vaporizes the surface of a target made of the desired material; a perpendicularly emitted plume

ARE YOU SPENDING TOO MUCH TIME DRAWING FLOWCHARTS? YOU NEED FLOW CHARTING™ 3.



Every day, professionals worldwide save time and money using Flow Charting 3. It's fast, efficient, easy to use, and always produces presentation-perfect charts and diagrams.

With Flow Charting 3's built-in flexibility, you can create customized charts using a variety of shapes, lines, and text—placed where you want them.

Plus, Flow Charting 3 is now available in a LAN version. Making it easy to share files and set up work groups for specific projects.

And it's backed with free technical support and a 90-day no-risk guarantee. So if you're spending too much time drawing charts, call for a free demo and see for yourself what makes Flow Charting 3 the best-selling flowcharting software.

See your dealer today! Or for a free interactive demo disk, call 1-800-525-0082, ext. 282
International: 408-778-6557, ext. 282

Novell is a registered trademark of Novell, Inc.

PATTON & PATTON
Software Corporation

Excellence in charting the flow of ideas!

Patton & Patton Software Corp. 485 Cochrane Circle, Morgan Hill, CA 95037

For More Information Circle No. 499

of gaseous material then coats a heated substrate.

This work was done by Curtis Banks, George B. Doane III, and John Golben of the University of Alabama in Huntsville for Marshall Space Flight Center. To obtain a copy of the report, "High Temperature Superconductor Materials and Applications," Circle 65 on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Marshall Space Flight Center [see page 20]. Refer to MFS-27264.

Electrochemical Impedance Spectroscopy of Metal Alloys

The polarization resistances of 19 alloys in chloride solutions were measured.

A report describes the use of electrochemical impedance spectroscopy (EIS) to investigate the resistances of 19 alloys to corrosion under conditions similar to those of the corrosive, chloride-laden sea-

side environment of the Space Transportation System launch site. The alloys investigated were Hastelloy C-4, C-22, C-276, and B-2; Inconel* 600, 625, and 825; Inco* G-3; Monel 400; Zirconium 702; Stainless Steel 304L, 304LN, 316L, 317L, and 904L; 20Cb-3; 7Mo + N; ES 2205; and Ferralium 255. Electrochemical ac impedance measurements were performed on specimens immersed for 1 hour or longer in each of the following three electrolyte solutions: 3.55 percent aqueous NaCl, 3.55 percent NaCl in 0.1N HCl, and 3.55 percent NaCl in 1.0N HCl. The data were analyzed qualitatively by use of Nyquist plots and quantitatively by use of Bode plots. Values of polarization resistance, R_p , were obtained from the Bode plots. (R_p is considered to be a measure of resistance to corrosion. The rate of corrosion under the given conditions is approximately proportional to $1/R_p$.)

Of the alloys tested, Zirconium 702 was the most resistant to corrosion in the three electrolytes. The orders of the other alloys according to their resistances to corrosion differed at the different concentrations of hydrochloric acid in the electrolyte. The corrosion resistances of Zirconium 702 and Ferralium 255 increased with the concentration of hydrochloric acid; the corrosion resistances of the other 17 alloys decreased with the concentration of hydrochloric acid.

Alternating-current impedance data on all of the alloys except Stainless Steel 304LN, were gathered at various immersion times in the solution that consisted of 3.55 percent NaCl in 0.1N HCl. R_p was obtained from the Nyquist plot at each immersion time by processing the measurement data via the EQUIVALENT CIRCUIT software available with the impedance-measuring equipment. The R_p of Hastelloy C-22 showed the highest overall values of R_p , while Monel 400 and Inconel 600 exhibited the lowest overall values.

The corrosion performances of specimens exposed outdoors at a beach corrosion-testing site were found to be well correlated with rates of corrosion predicted on the basis of R_p values obtained from the laboratory impedance measurements. These results suggest that electrochemical impedance spectroscopy can be used to predict the corrosion performances of metal alloys.

"Inco" and "Inconel" are registered trademarks of the Inco family of companies.

This work was done by L. G. MacDowell and L. M. Calle of Kennedy Space Center. To obtain a copy of the report, "Evaluation of High Performance Metal Alloys in the STS Launch Environment Using Electrochemical Impedance Spectroscopy," Circle 29 on the TSP Request Card. KSC-11575

Burn through your data.

There's a lot more data than you thought there'd be. Difficult, uncooperative data. So don't you wish lightning would strike?

It has. BBN/Probe™ software burns through the biggest, most difficult jobs you have. It offers the most powerful graphics and analysis environment you can get for accessing and analyzing raw, time-sampled data

from multiple sources, even in real time.

Other tools leave you weeks or months of work reformatting and standardizing your data files.

Only BBN/Probe accesses your data directly — so you can focus on your analysis, not your analysis software. For UNIX and VMS.

For white-hot visual data analysis, take a look at BBN/Probe. Call 1-800-84-PROBE.

PENETRATING ANALYSIS **BBN/Probe™**

BBN SYSTEMS AND TECHNOLOGIES

A Division of Bolt Beranek and Newman Inc., 10 Moulton St., Cambridge, MA 02138 (617) 873-2120 (800) 847-7623
BBN/Probe is a trademark of Bolt Beranek and Newman Inc.





Computer Programs

COSMIC: Transferring NASA Software

COSMIC, NASA's Computer Software Management and Information Center, distributes software developed with NASA funding to industry, other government agencies and academia.

COSMIC's inventory is updated regularly; new programs are reported in *Tech Briefs*. For additional information on any of the programs described here, circle the appropriate TSP number.

If you don't find a program in this issue that meets your needs, call COSMIC directly for a free review of programs in your area of interest. You can also purchase the annual *COSMIC Software Catalog*, containing descriptions and ordering information for available software.

COSMIC is part of NASA's Technology Transfer Network.

COSMIC®—John A. Gibson, Director,
Phone (706) 542-3265; FAX (706) 542-4807
The University of Georgia, 382 East Broad Street,
Athens, Georgia 30602

Computer Programs

These programs may be obtained at a very reasonable cost from COSMIC, a facility sponsored by NASA to make computer programs available to the public. For information on program price, size, and availability, circle the reference number on the TSP Request Card in this issue.



Electronic Systems

Simulating the SSF Information System

FROST provides statistics on the generation, communication, and processing of data.

The information system of the Space Station *Freedom* (SSF) is intended to process and transmit data between the space station and the station controllers and payload operators on the ground. Components of the system would include flight hardware, communications satellites, software, and ground facilities. The Freedom Operations Simulation Test (FROST) computer program simulates the operation of the SSF information system, tracking every packet of data from generation to destination, for both uplinks and downlinks. This program collects various statistics con-


cerning the operation of the system and provides reports of these statistics at intervals specified by the user. In addition, FROST incorporates graphical-display capability to enhance interpretation of these statistics.

FROST mathematically models each of the components of the SSF information system as an object, in which packets of data are generated, received, processed, transmitted, and/or dumped. The user must provide the design of the information system, including specified parameters and interconnections among objects. To aid this process, FROST supplies an example SSF information system for simulation, but this example must be copied before it is changed and used for further simulation.

Once specified, architecture and parameters of the system are put into the input file, named the Test Configuration Definition (TCD) file. Alternative designs of the system can then be simulated simply by editing the TCD file. Within this file, the user can define new objects, alter the parameters of objects, redefine paths, redefine generation rates and windows, and redefine interconnections among objects. At present, FROST does not model every feature of the SSF information system, but it is capable of simulating many of the important functions of the system.

To generate data messages, which can

Columbus to Columbia 1492—1992T-shirt



An original and decorative T-shirt design depicts the Santa Maria sailing on a blue ocean against a burst of golden sun and blue sky. The Columbia shuttle soars in the foreground. A vivid design in splendid four-color.
Only \$12.95

Please send Columbia T-shirts at \$12.95 (quantity) _____

Circle size(s): S M L XL _____

Add \$5.00 for shipping and handling charges _____

(NY residents add sales tax)

Orders from \$51.00 to \$100.00 add shipping _____

and handling charge \$8.50 **TOTAL ENCLOSED** _____

Name _____

Company _____

Address _____

City/State/Zip _____

Mail to: NASA Tech Briefs, Dept. F, 41 East 42nd Street

New York, New York 10017

For credit card order call (212) 490-3999

ANVIL CASES . . . BUILT FOR AIR, LAND & SEA

- M.A.C.C. Cases — military application cases and containers meet or exceed the stringent testing of MIL-STD-810
- A.T.A. Cases meet or exceed the Air Transport Association specification 300 Category 1 standards



CALL FOR
OUR NEW
CATALOG!

• Custom measuring and designing available • Building quality cases since 1952

Call Today For More Information

ANVIL CASES
SUBSIDIARY OF ZERO CORPORATION

15650 Salt Lake Ave., City of Industry, CA 91745 • P.O. Box 1202, La Puente, CA 91747

(800) FLY-ANVIL (800) 359-2684

come from any object, FROST defines "windows" to specify when, what kind, and how much information is generated. All messages are classified by priority as either (1) emergency, (2) quick-look, (3) telemetry, or (4) payload data. These messages are processed by all objects according to priority. That is, all priority 1 (emergency) messages are processed and transmitted before priority 2 messages are processed, and so forth. FROST also allows for specification of "pipeline" or "direct" links. Pipeline links are used to broadcast at constant intervals, while direct links transmit messages only when packets are ready for transmission.

FROST allows the user substantial flexibility to customize output for a simulation. Output consists of tables and graphs, as specified in the TCD file, to be generated at the specified intervals. These tables can be generated at short intervals during the run to produce snapshots as simulation proceeds, or generated after the run to give a summary of the entire run.

FROST is written in SIMSCRIPT II.5 (developed by CACI) for DEC VAX-series computers running VMS. FROST was developed on a VAX 8700 computer and is intended to be run on large VAX computers with at least 32 Mb of memory. The main-memory requirement for FROST depends on the number of processors used in the simulation and the event time. The stand-

ard distribution medium for this package is a 9-track, 1,600-bit/in. (630-bit/cm) DEC VAX BACKUP format magnetic tape. An executable code is included on the tape in addition to the source code. FROST was developed in 1990.

DEC, VAX, and VMS are registered trademarks of Digital Equipment Corp. IBM PC is a trademark of International Business Machines Corp. SIMSCRIPT II.5 is a trademark of CACI.

This program was written by Govind K. Deshpande, Henry Kleine, Joseph C. Younger, Felicia A. Sanders, Jeffrey L. Smith, Robert W. Aster, Jerry M. Olivieri, and Lori L. Paul of Caltech for NASA's Jet Propulsion Laboratory. For further information, Circle 36 on the TSP Request Card.

NPO-18484



Mechanics

Analyzing Stresses in Orthotropic Materials

BOFFO implements the boundary-force method.

In fracture mechanics, stress-intensity factors are important parameters that are

used in predicting fracture strengths and fatigue lives. The Boundary Force Method for Orthotropic Materials (BOFFO) computer program performs stress analyses of two-dimensional, linearly elastic, orthotropic or composite bodies with or without cracks, by use of the boundary-force method. The boundary-force method is versatile in that it makes it possible to analyze complicated geometries, crack configurations, and load distributions with ease. The BOFFO program is easy to use because in BOFFO, only the boundaries of the region of interest are modeled mathematically by use of a built-in mesh generator. Stresses can be computed at any specified point in the body. Solutions that involve stress-intensity factors and strain-energy-release rates are computed for both mode-I and mixed-mode fracture problems.

The boundary-force method is a numerical technique in which one uses the fundamental solutions for concentrated forces and moments in an infinite sheet to obtain the solution to the boundary-value problem of interest. These fundamental solutions are used in the BOFFO program to satisfy the stress-free conditions exactly on the faces of cracks. The other boundary conditions are satisfied approximately by applying the appropriate sets of concentrated horizontal and vertical forces and moments along the boundaries.

The configuration appropriate to a given problem is defined with the help of two sets of axes. The global X and Y axes are used to define the boundaries of, loads upon, and properties of materials in, the specimen. The local axes define the length and orientation of the crack. The user can specify four types of symmetry conditions: symmetry about the X axis, symmetry about the Y axis, symmetry about the X and Y axes, or no symmetry. The lines of symmetry are not modeled as boundaries. The accuracy of the solution depends on how well the boundary conditions are approximated; this, in turn, depends on the refinement of the boundary mesh. BOFFO uses the radial-line method to generate the mesh.

BOFFO is written in FORTRAN V for execution on CDC CYBER 170-series computers running NOS. The execution time and memory required depend on the number of boundary elements in the mesh. With 12 elements, the required main memory is 26K CYBER words. Input and output are tabular. BOFFO is available on a 9-track, 1,600-bit/in. (630-bit/cm) ASCII Card Image format magnetic tape. This program was developed in 1990.

CDC CYBER and NOS are trademarks of Control Data Corp.

This program was written by Catherine A. Bigelow of Langley Research Center and Paul W. Tan of Analytical Services & Materials, Inc. For further information, Circle 59 on the TSP Request Card.
LAR-14650

We've put cost and schedule together so you don't have to.

Now you no longer have to spend extra time matching multiple software packages that claim to integrate all your project data. P/X™, the windows-based sequel to PSDI's award-winning PROJECT/2®, is the first project management system to integrate cost and scheduling in one core product for your desktop.

P/X supports . . .

- Integrated Cost/Schedule
- Multiproject
- Multiplatform
- SQL Compliance
- DoD and NASA Requirements
- Engineering Resource Management

Call us today for a free
P/X demo diskette:
1-800-366-7734
or Fax: 1-617-661-1642



PROJECT/2 is a registered trademark and P/X is a trademark of Project Software & Development, Inc., 20 University Road, Cambridge, MA 02138.



NASA Software Update

Each month *NASA Tech Briefs* features new computer programs available through COSMIC, NASA's Computer Software Technology Transfer Center in Athens, Georgia. In addition to creating new programs, NASA continually updates and enhances existing software. Programs updated in the past year include:

Systems Improved Numerical Differencing Analyzer and Fluid Integrator (SINDA '85/FLUINT) This comprehensive thermal analysis system handles complex models such as evaporators and permits the interaction of thermal and fluid problems. Design flexibility is provided by 20,000 nodes, 100,000 conductors, 100 thermal submodels, and 10 fluid submodels. SINDA '85/FLUINT is available for DEC VAX, DEC RISC, Sun, Cray, and Convex computers. *Circle 98 on the TSP Request Card. MSC-21528.*

Thermal Radiation Analyzer System (TRASYS) Working alone or with SINDA '85/FLUINT, TRASYS solves the radiation components of thermal analysis problems. A TRASYS model calculates both the internode radiation exchange and the incident and absorbed heat rate due to sunlight. Used in satellite design, the program can handle situations where one surface wholly or partially shades another from direct sunlight. It is available for DEC VAX and Cray computers. *Circle 99 on the TSP Request Card. MSC-21030.*

Science & Technology Laboratory Applications Software (ELAS) This digital image analysis system processes Landsat multispectral data, aircraft-acquired scanner data, digitized topographic data, and such ancillary data as soil types and rainfall information. Over 230 modules aid the user in performing a wide range of land cover analyses and manipulations. ELAS runs on Concurrent, DEC VAX, Sun, Masscomp, and Silicon Graphics computers. *Circle 101 on the TSP Request Card. ERL-10017.*

Structural Analysis of General Shells (STAGS) models complex thin shell structures including separate shell branches or segments connected along their boundaries. Options include static stress and vibration, transient, and bifurcation buckling analysis. Also useful for submarine design, STAGS is available for DEC VAX, DEC RISC,

Cray, Convex, Sun, Silicon Graphics, IBM RS/6000, HP9000, and Stardent Titan systems. *Circle 102 on the TSP Request Card. HQN-10967.*

NETS The NETS development tool provides an environment for simulation and development of neural networks—computer programs that “learn” from experience. Written in ANSI standard C, the program allows the user to generate C code for implementation of a neural network. NETS can run on a Macintosh computer or as a machine-independent program. *Circle 103 on the TSP Request Card. MSC-21588.*


Programs to Optimize Simulated Trajectories (POST6DPOST) Designed for optimizing simulated trajectories, POST is a point mass, three degrees-of-freedom program while the extended 6DPOST permits rigid-body six degrees-of-freedom models. The package runs on Sun and Silicon Graphics computers and handles sophisticated problems such as ascent, orbital maneuvers, and reentry. *Circle 104 on the TSP Request Card. LAR-13938.*

Global Reference Atmosphere Model (GRAM) This 4D model provides atmospheric parameter values either automatically at positions along a linear path or along any set of connected positions specified by the user. Based on actual data, GRAM provides thermal wind shear for the monthly mean winds, the percent deviation from the standard atmosphere, the mean vertical wind, and the perturbation data for each position. *Circle 105 on the TSP Request Card. MFS-28397.*

PC-SEAPAK is an interactive satellite data analysis software package developed for oceanographic research. The PC program is used to process data from the Nimbus-7 Coastal Zone Color Scanner and the NOAA Advanced Very-High-Resolution Radiometer. *Circle 106 on the TSP Request Card. GSC-13320.*

Time Warp Operating System (TWOS) Designed to support parallel discrete-event simulation, TWOS is a complete implementation of the Time Warp mechanism—a distributed protocol for virtual time synchronization based on process rollback and message annihilation. The program runs on Sun computers and the BBN Butterfly GP-1000. *Circle 107 on the TSP Request Card. NPO-18692.*

Strawberry Shortcut



To Data Acquisition and Control

Use WorkBench™ software to quickly and easily perform your data acquisition application. Just load WorkBench on your PC-DOS or Macintosh computer and you've got the most valuable shortcut to productivity you can imagine. Let us show you. Call 408/736-8800 and we'll send you a free demo disk.




Strawberry Tree

160 South Wolfe Road Sunnyvale, California 94086
(408) 736-8800 Fax: (408) 736-1041

For More Information Circle No. 659

"At DuPont, we have experienced the power of deliberate, systematic application of the de Bono tools to practical problems with remarkable results. For example, lateral thinking led to a major break-through in process continuity at a fiber plant with a radical altering of basic equipment design, reducing the number of moving parts by 80%."

—David Tanner,
Founding Director, DuPont Center
for Creativity & Innovation



This book only \$23.00 plus \$5.00 for shipping and handling. **Mail order to:**

NASA Tech Briefs, Dept F
41 East 42nd St. Suite 921
New York, New York 10017
For credit card orders call
(212) 490-3999



Self-Damping Sprung Wheel

The rim deflects in the vicinity of the contact with the ground or floor.

Marshall Space Flight Center, Alabama

The self-damping sprung wheel provides a shock-absorbing suspension for a wheelchair, reducing the user's discomfort when traversing rough terrain or obstacles. A pair of self-damping sprung wheels are installed in place of the conventional large rear wheels of a standard wheelchair, which the user then operates in the conventional manner.

Other types of shock-absorbing suspensions are not suitable for wheelchairs. For

example, when a rigid wheel on a spring suspension encounters an obstacle, the entire wheel is pushed upward, and the top of the wheel can make contact with the user's arm. In addition, the handwheel portion vibrates along with the rest of the wheel; this makes it difficult for the user to grasp and apply force to the handwheel. In contrast, the self-damping sprung wheel does not rise and fall in its entirety; the only part that deflects is a portion of the rim in the vicinity of the contact with the floor, ground, and/or obstacle.

The wheel includes a central hub that turns on conventional bearings, with radial spokes extending from the hub to a flexible rim (see Figure 1). The handwheel is attached to the spokes near their outer ends. A slot in the outer end of each spoke accommodates the radial sliding of a cylindrical knob attached to a rim connector tang. In the normal undeflected condition, the rim spring-loads every cylindrical knob radially outward against a cover plate, which retains the knob in the slot. When

a portion of the rim is deflected radially inward by contact with an obstacle, the knob(s) in the affected spoke(s) slide radially inward along the slot(s).

As shown in Figure 2, the rim includes thin inner and outer hoops of molded reinforced plastic, plus an elastomeric intermediate hoop bonded to the inner and outer hoops. Tire-retaining tabs are attached to the outer hoop, and a standard airless polyurethane-foam wheelchair tire is mounted on the tabs. Where part of the tire and rim are deflected inward, the outer hoop is loaded in compression, the inner hoop is loaded in tension, and the elastomeric intermediate hoop is loaded in shear. The shear deformation of the elastomer absorbs the energy stored in the bending of the rim, thereby providing damping.

An alternative version of the wheel could be designed for a bicycle. The tire-retaining tabs and wheelchair tire would be replaced by a continuous-strip retainer and pneumatic tire, the handwheel and its mounting fixtures would be deleted, the stiffness of the rim would be changed to accommodate greater speeds, and the hub would be modified to accommodate bicycle-style bearings and fork mounting.

This work was done by Bruce Weddendorf of Marshall Space Flight Center. For further information, Circle 27 on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Marshall Space Flight Center [see page 20]. Refer to MFS-28632.




Figure 1. The Knob Slides In the Slot to accommodate deflection of the rim.




Figure 2. The Rim Includes Inner and Outer Hoops that bend when an obstacle is encountered. The shear deformation of the elastomeric hoop between them absorbs energy. Thus, the three hoops act together as a damping spring.

Viscous/Inviscid Interaction on an Oscillating Airfoil

A computational procedure simulates complicated flow phenomena.

Ames Research Center, Moffett Field, California

A viscous/inviscid-interaction procedure has been developed for computation of the two-dimensional flow of air about an airfoil, the angle of attack of which oscillates at high amplitude (see figure). The purpose of this and similar procedures is to study the flow effects in dynamic stall, which is the unsteady condition that occurs on such airfoils as the blades of helicopter rotors, windmills, and turbomachinery cascades when the angle of attack of the airfoil dynamically exceeds the angle at which the airfoil would stall in steady flow.

As is common in computations of unsteady flows of viscous fluids, in this procedure the bulk of the flow is treated as inviscid, while the effects of viscosity are treated only on the surface of the airfoil and in the boundary layer. The inviscid part of the flow is simulated via a time-marching, unsteady-subsonic-flow panel method that incorporates appropriate distributions of unsteady surface and wake singularities.


The principal novel feature of this procedure is its provision for coupling between the panel method and a finite-difference code that calculates the unsteady laminar/turbulent boundary-layer flows about oscillating airfoils. The boundary-layer code is based on an inverse boundary-layer formulation that is an extension, to the unsteady case, of a method developed previously for steady flows and that is based on a Hilbert-integral formulation. Here, the Hilbert-integral concept is used in regions of strong viscous interaction, with several successive sweeps through the boundary layer per time step. A few global iterations in combination with the inviscid method are necessary to get a final converged solution for a complete cycle of oscillation. For turbulent flows, a two-region algebraic eddy viscosity is used on a quasi-steady basis. The location of the transition from laminar to turbulent flow is prescribed in space and time.

The problem of the motion of the region of integration because of movement of the front stagnation point is solved by a new transformation that involves a time-variable boundary-layer grid. The effect of wake circulation is taken fully into account in the inviscid part of the problem via the unsteady Kutta condition. The displacement effect of the wake, however, is simply accounted for by an algebraic equation that represents a distribution of sinks with exponential decay along the centerline of the wake.

The procedure has been applied to a number of cases of dynamic airfoil motion involving angles of incidence up to 18° , various reduced frequencies (including the quasi-steady case), various Reynolds numbers, and various airfoil sections. The comparisons with experimental data show reasonably good agreement, even for the coefficients of unsteady drag.

Based on research using this method, several areas have been identified that require further investigation. The subsonic (incompressible) treatment reaches its limits in high-incidence cases because of the development of supersonic regions and shock waves in the leading-edge area of the airfoil. The algebraic representation of the displacement effect of the wake is only approximate. The unsteady movement of transition has been rigidly and, therefore, unrealistically attached to the increment of the stagnation point. The quasi-steady application of the two-region algebraic eddy viscosity is also only approximate. These shortcomings may be overcome in the future by further development of the coupling scheme.

This work was done by L. W. Carr of Ames Research Center, W. Geissler of DFVLR Institute of Aeroelasticity, and T. Cebecci of California State University. For further information, Circle 96 on the TSP Request Card.
ARC-12472



The Flow About an Oscillating Airfoil is simulated by a computational procedure based on the concept of interacting viscous and inviscid flows.

DURABLE ECONOMICAL UniSLIDE® ASSEMBLIES

1½" TRAVEL
\$65



Available Screw Driven

Ask for Free Catalog of
950 UniSLIDE Assemblies

VELMEX INC.

P.O. BOX 38 • E. BLOOMFIELD, NY 14443
TOLL FREE 800/642-6446
IN N.Y.: 716/657-6151

For More Information Circle No. 605

DREAMS TO REALITY T-Shirt



Beautiful full-color design features blueprints of the National Aero-Space Plane and Space Station Freedom with a shuttle liftoff saluting America's space achievements. 100% heavyweight pre-shrunk white cotton shirt. Adult sizes only. \$12.95 each + \$5.00 postage and handling (NY residents add sales tax).

Please send (insert quantity) _____

T-Shirts in the following size(s):

(please circle) S M L XL

Total enclosed: \$ _____

Name _____

Address _____

City _____

State _____ Zip _____

Mail to: NASA Tech Briefs, Dept. F,
41 East 42nd St., Suite 921
New York, NY 10017

For credit card orders call (212) 490-3999

Lightweight Right-Angle Valve for Cryogenics


The valve provides trouble-free isolation under typical operating conditions.

Lyndon B. Johnson Space Center, Houston, Texas

A lightweight right-angle valve isolates a pressurized liquid or gas stream from a vacuum over a wide range of temperatures from ambient down to cryogenic. The valve is sized to fit tubes of the types ordinarily used in cryogenic equipment. Unlike prior valves designed for use with tubes, this one maintains isolation, without need for manual adjustment of its packing gland as pressure and temperature vary from medium vacuum [10^{-7} torr (about 10^{-5} Pa)] at -100°F (-73°C) to 150 lb/in.^2 (about 1 MPa) at 70°F (21°C).

The mass of the valve is less than 60 grams. The valve (see figure) is made of off-the-shelf parts and a few simple custom-machined parts.

This work was done by Richard B. Calhoun of Lockheed Engineering & Sciences Co. for **Johnson Space Center**. For further information, Circle 17 on the TSP Request Card.
MSC-21889



This **Lightweight Right-Angle Valve** is designed to provide a tight seal (without manual readjustment of its packing gland) over a wide range of temperatures and pressures. It can be made partly of commercial (Swagelok® or equivalent) components.


Disk Valve for Cryogenics

This simple unit remains leaktight over a wide range of pressures and temperatures.

Lyndon B. Johnson Space Center, Houston, Texas

The lightweight disk valve illustrated in the figure is designed to have dimensions and capabilities similar to those of the valve described in the preceding article, "Lightweight Right-Angle Valve for Cryogenics" (MSC-21889). This disk valve is designed to operate over the same range of temperatures and pressures as that of the lightweight right-angle valve; to fit tubing of the same sizes; and to remain leaktight under changing conditions, without need for manual readjustment of a packing gland. Also like the right-angle valve, this one weighs less than 60 g and can be made relatively inexpensively from some commercial and a few simple custom-machined components.

This work was done by Richard B. Calhoun of Lockheed Engineering & Sciences Co. for **Johnson Space Center**. For further information, Circle 16 on the TSP Request Card.
MSC-21888



External Tubing Is Attached to stainless-steel tubes that extend from opposite faces of the body of the disk valve. The disk contains an eccentric hole: shown here in the "open" position, it can be rotated to the "closed" position by use of a wrench pin inserted in a radial socket. Rings in the circular grooves maintain the seal.

Is your subscription about to expire?

Check the expire date. If it is less than 6 months now is the time to fill out a new qualification form before your subscription expires.

Measuring Tollmien-Schlichting Instabilities in Laminar Flow

Surface-mounted hot-film sensors detect T-S waves.

Langley Research Center, Hampton, Virginia

One of the primary objectives of today's research in laminar flow is to explore the limits of wing sweep, Reynolds number, mach number, and pressure gradients for which laminar flow can be achieved and maintained on modern airplane surfaces in typical operating environments. Past flight-research measurements of transitions in laminar flow focused on the locations of transitions without exploring the dominant instabilities responsible for initiating the transition process. Of importance to modern flight research in laminar flow is the ability to understand the specific causes of laminar-to-turbulent boundary-layer transitions. A recent NASA flight experiment was conducted to evaluate surface-mounted hot-film sensors designed to detect Tollmien-Schlichting (T-S) instability in the boundary layer in flight.

The flight experiment was conducted on a Lear Model 28/29 business jet airplane operated by NASA at Langley Research Center for flight research in the reduction of drag. The range of operating conditions includes mach numbers up to 0.81, maximum unit Reynolds numbers up to 2.65×10^8 per foot ($8.69 \times 10^8 \text{ m}^{-1}$), and maximum altitudes up to 51,000 ft (15.5 km). The wing on this airplane incorporates a non-production, modified airfoil section. The wing has a very smooth surface that is well-suited to research on laminar flow.

Nine hot-film sensors were mounted on the surface of the wing for this experiment. Each sensor consisted of nickel film deposited on a substrate of polyimide film. Each of the hot films was operated in a constant-temperature (uncompensated) mode. The anemometer electronics included the hot-film sensor as one side of a Wheatstone bridge circuit and an amplifier with internal programmable gain and filtering. In addition, each signal was externally amplified with a fixed gain prior to recording.

Three sensors were located at 20, 30, and 40 percent of chord with appropriate staggering to prevent neighboring sensors from causing premature turbulent contamination.

The flight test was conducted at mach 0.79 and an altitude of 39,000 ft (11.9 km). The data were obtained by performing slow decelerations and accelerations, which caused the transition to move across the 20-, 30-, and 40-percent-of-chord stations. Data were analyzed when the signal was still laminar but just prior to the first turbulent bursts preceding transition.

A two-dimensional linear stability analysis of the laminar velocity profiles was calculated by both the SALLY (Stability,

Analysis, Local, Linear, and Incompressible) and the COSAL (Compressible Stability Analysis) computer programs. For the T-S predictions, the data were initially analyzed by use of the SALLY over a wide range of frequencies at zero wave angle. After the most amplified frequency was identified, COSAL calculations were made for that frequency over a range of wave angles. The analytical effort showed that the hot

films correctly measured the amplified T-S frequency range. Future flight tests requiring the determination of T-S disturbance frequencies could rely on hot-film data without requiring analytical predictions.

The new technique should have considerable value in applied research aimed at extending the regions of natural laminar flow on an aircraft. It aids research into the mechanisms leading to transition from

FEA Users...

*Have you seen
COSMOS/M
in action
lately?*

The Big Boys of FEA don't want you to hear this. But COSMOS/M on PCs, Macintosh and engineering workstations, is one of the most popular analysis packages on the market.

COSMOS/M's easy to use pre- and postprocessor enables novice and seasoned engineers to take advantage of state of the art technology such as 3D automatic meshing, as well as H-Method and P-Method analysis without stressing your budget.

Features

- Linear & Nonlinear Statics / Dynamics
- Advanced Dynamics
- Linear & Nonlinear Heat Transfer
- Fluid Flow
- Electromagnetics
- Design Optimization
- Fatigue
- Crash Worthiness
- CAD & FEA Interfaces


The wide range of analysis capabilities available proves that COSMOS/M is a serious analysis tool capable of solving a variety of design problems.

To see COSMOS/M in action, call us and we'll send you a free 50-node version of the software to try on your own problems.

Remember, FEA doesn't have to be expensive - just powerful. Once you see it in action, you will agree that COSMOS/M is the right choice.



2951 28th Street,
Suite 1000
Santa Monica, CA 90404
tel 310-452-2158
fax 310-399-6421



laminar to turbulent boundary layers. The new technique makes it practical to take measurements in many locations on a wing surface for tests in flight. This tech-

nique would be useful in studying transitions in such flow as those in pipes, ducts, channels, compressors, and diffusers.

This work was done by Cynthia C. Lee,

Gregory S. Manuel, and John P. Stack of Langley Research Center. For further information, Circle 63 on the TSP Request Card. LAR-14132

Single-Tip Probe Senses Pressure or Temperature

A valve is actuated remotely to switch between pressure- and temperature-sensing modes.

Lewis Research Center, Cleveland, Ohio


A single-tip probe designed for use in a supersonic wind tunnel can be switched to sense pressure or temperature. Heretofore, it has been necessary to use separate probes to measure pressure and tempera-

ture and, if using both probes simultaneously, to place them sufficiently far apart across the flow to prevent interference (principally, via propagation of shock waves) between them. The new single-tip probe senses tem-

perature or pressure at the same point in the flow. Furthermore, in the sense that it can be switched rapidly between pressure- and temperature-measuring modes, it provides nearly simultaneous measurements of both pressure and temperature at that point. It is not necessary to stop a wind-tunnel test and exchange probes to change between pressure and temperature measurements.

The probe (see figure) includes a small valve like the valves used in bicycle and automotive tires. The valve (called a "Schraeder valve") is actuated by a push rod driven by an electric solenoid. When the valve is in its spring-loaded, normally closed condition, the flow in the probe tubes is blocked, and the pressure of the outside oncoming flow is transmitted via a tube to a standard pressure transducer located elsewhere. When the solenoid is energized, the rod pushes the valve open, allowing some flow in the probe tube. This flow aids the thermal response of a thermocouple that is mounted in the probe tube and that serves as the temperature transducer.

This work was done by Paul Trimarchi of Lewis Research Center. For further information, Circle 95 on the TSP Request Card. LEW-15296



Step Up to Algor

More than 6,000 engineers in 50 states and over 60 countries have stepped up to Algor, the most advanced finite element analysis and design software money can buy. All FEA models on this page were designed, analyzed and visualized on a PC with Algor software. The largest contains more than 24,000 nodes and 13,000 elements. Other Algor analysis packages include buckling, nonlinear gap/cable, specialized vibration, composite elements, kinematics/dynamics, piping and more.

Algor, a PC and You...The Total Design/Engineering Team

Algor, the world's leading design/analysis software for PCs, is specifically designed to fully exploit their increasing level of power. Tight bridges to CAD/CAM and other software create a seamless fit into your environment. Algor design software provides parametric design and results visualization tools (see actual screen photographs on this page) that are worthy of your expertise and creativity. And the engineering is built in.

Typical Algor Engineering Software Packages		Price
A	Linear Stress Analysis with ViziCad Plus	\$1500
B	Stress, Vibration and Mode Shape Analysis with ViziCad Plus	\$2100
C	Fluid Flow Analysis with ViziCad Plus	\$1100
D	Heat Transfer Analysis with ViziCad Plus	\$1800
E	Accupak—3-D Nonlinear Stress & Vibration	\$2500
F	Iconnex V EAGLE, Concurrent Engineering & Design Optimization	\$2300
G	Electrostatic Analysis with ViziCad Plus	\$1600

Interactive Demonstration/Tutorials - \$19 to \$49		
Finite Element Analysis	Heat Transfer	Fluid Flow
Electrostatic	PipePlus	Free 36-Page Product Guide


Your current PC has more computing power than your last one. Your next PC will have even more. Algor software is constantly updated to take advantage of the power of new PCs.

ALGOR
150 Beta Drive
Pittsburgh, PA 15238-2932 USA
412-967-2700 Fax: 412-967-2781
In California: 714-564-2541

GSA Contract # GS 00 K 89 AGS 6270 PS01



Notes: 386/486 Prices, shown in U.S. \$, may change at any time. 386/486 software uses extended memory. Weitek coprocessor and selected Unix workstation versions available. Algor software is subjected to nuclear power industry Quality Assurance standards.



The Tire Valve Is Opened or Closed by the push rod and solenoid. In the open position, the flow past the thermocouple enables measurements of temperature. In the closed position, flow is blocked and pressure in the probe backs up to a pressure transducer.

Fail-Safe Pressure Plug

This protective plug resists slowly built-up pressure or automatically releases itself if pressure rises suddenly.


Lyndon B. Johnson Space Center, Houston, Texas

A protective plug seals out moisture at pressures ranging from 50 μm of mercury (6.7 Pa) to 200 lb/in.² (1.4 MPa). The plug is designed to seal the throat of the 38 Reaction Control Thrusters on the Space Shuttle and thereby protect internal components from corrosion. Modified versions might be useful in protecting engines, pumps, reaction vessels, and other industrial equipment during shipment and maintenance.

The plug withstands slow pressurization up to 200 lb/in.² (1.4 MPa) so that thrusters can be purged and pressurized during maintenance. However, a rapid increase in pressure blows out the plug at 60 lb/in.² (0.41 MPa). Thus, if a plug is inadvertently left in at the start of a mission, it will be expelled as soon as a thruster fires in normal operation. The plug also contains a relief valve that vents at 8.5 lb/in.² (59 kPa) to prevent a buildup of internal pressure from heating or leakage from propellant valves.

The retaining element of the plug is a polytetrafluoroethylene (teflon) housing that has been slotted to form flexible fingers (see figure). When a piston inside the plug is pulled (to the right in the figure) by a bolt, the fingers flex inward so that they pass through the throat of the thruster nozzle. When the bolt is released, a spring pushes the piston to its original position. The piston expands the fingers outward so that they lock the plug into the throat. A special tool is used to insert and remove the plug. A handle on the tool is rotated to push and pull the piston. The outer end of the nozzle is fitted with a protective cover after the plug has been installed.

The teflon fingers are sized so that they fit the throat without pressing hard against it. The only loads the fingers carry are from pressure in the thruster chamber and the spring loading of the outer cover. This design feature reduces the cold flow that teflon parts typically exhibit when loaded for long times. The plug includes a basket



that holds silica gel, a desiccant, on its interior end. The gel removes residual moisture from the air remaining in the chamber.

A small orifice through the plug links the thruster chamber to the volume behind the piston. Thus, when the chamber is slowly pressurized for testing or maintenance, a counterpressure builds up behind the piston. In this slow-pressurization mode, the piston is not pushed back to release the fingers until the pressure reaches 222 lb/in.² (1.53 MPa). If, however, the chamber is rapidly pressurized — when it is fired — there is no opportunity for a counterpressure to build up. At 60 lb/in.², the rapidly rising pressure pushes the piston back, causing the fingers to be retracted, and the pressure then expels the plug. In ad-

dition, if the pressure remains above 100 psi (0.7 MPa) for a long time, the plug slowly moves out of the throat by cold flow of the teflon fingers; eventually, the seal is broken, and the pressure is thereby released.

This work was done by Paul A. Svejksky of Lockheed Engineering & Sciences Co. for Johnson Space Center. For further information, Circle 23 on the TSP Request Card.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Johnson Space Center [see page 20]. Refer to MSC-21898.

Six-Degree-of-Freedom Magnetic Vibration Isolator

Feedback control provides a soft mount and damping of vibrations.

Marshall Space Flight Center, Alabama

An active magnetic suspension system centers an inner structure (and a mass mounted on it) in position and orientation with respect to the principal Cartesian coordinate axes of a base or outer structure, which is stationary with respect to a building or vehicle. The system helps to

isolate the suspended mass (e.g., a scientific instrument) from vibrations of the building or vehicle. The system is designed primarily to isolate a 500-kg experimental apparatus from vibrations of a spacecraft, but can also be used on Earth, provided that its z axis is vertical and the system

is assisted by a low-stiffness vertical spring that, in the steady state, holds up the inner structure at the nominal vertical position.

The system (see Figure 1) includes four actuators, which are located on the +x, -x, +y, and -y sides of the inner structure. Each actuator includes two partly

Thermofoil™ Heater/Sensors

FORM

FIT

Medical diagnostic instrumentation • Aerospace devices

FUNCTION

Flexible heaters have their own built-in temperature sensors for fast response and tight control.

- Kapton, silicone rubber, polyester insulation
- Resistance thermometers with platinum and other elements, thermocouples, and thermistors
- Irregular shapes and profiled heat patterns adapt to any heat sink

7300 Commerce Ln.
Minneapolis, MN
55432-3177 USA

MINCO
PRODUCTS, INC.


Phn: 612/571-3121
Telex: 687-9025
FAX: 612/571-0927

For More Information Circle No. 541

overlapping electromagnet coils mounted on the outer structure, plus a pair of permanent magnets and associated back irons mounted on the inner structure. The electromagnet coils are sized, shaped, and positioned so that an L-shaped portion consisting of a horizontal leg of one coil and a vertical leg of the other coil lies in the gap between the permanent magnets. In the case of the actuator on the +x or -x face, the permanent-magnet field is nominally along the x axis. Current can be supplied to either or both coils, so that the current in the L-shaped portion in the magnetic field can have components in both the y and z directions. The interaction between the x magnetic field and the y (or z) current results in a Lorentz force in the z (or y) direction.

The actuators are somewhat redundant in that the four actuators produce eight independently controllable forces — two more than are needed for control in six degrees of freedom. The contribution of this redundancy to the cost and complexity of the system is offset by the simplicity of the Cartesian coordinate system and the consequent simplification of the control computations.

During operation, the inner and outer structures do not make contact. The clearances between the electromagnet coils



DETAIL OF ONE ACTUATOR




Figure 1. The **Prototype Vibration Isolator** includes Lorentz-force actuators, which are superior to other magnetic actuators in this application because they offer stable, approximately linear response.




Figure 2. **Position Feedback** from eddy-current sensors is processed into actuator currents.

and the back-iron-connecting rods allow strokes of slightly more than ± 1 cm along the principal axes, and lockable set screws serve as hard stops that limit the strokes to ± 1 cm. This stroke provides isolation at frequencies ≥ 0.04 Hz.

The position and orientation of the inner structure are measured by noncontact eddy-current sensors mounted on the outer structure. These sensors are part of a digital feedback control system (see Figure 2). The outputs of the sensors are digitized, then transformed into center-of-mass coordinates, in which the motions in the six degrees of freedom are uncoupled from each

other. A control processor implements six single-input/single-output lead/lag control algorithms, and the six resulting control outputs are subjected to another coordinate transformation to convert them into commands for the eight actuator currents. These commands are fed to amplifiers, which supply the currents to the electromagnet coils.

This work was done by Michael J. Gerver, Ralph C. Fenn, Timothy J. Hawkey, and Lawrence A. Ormord of SatCon Technology Corp. for **Marshall Space Flight Center**. For further information, Circle 94 on the TSP Request Card. MFS-26170



Machinery

Robot Would Reconfigure Modular Equipment

Human technicians would not have to enter a hostile environment.


Goddard Space Flight Center, Greenbelt, Maryland

Special-purpose sets of equipment, packaged in identical modules with identical interconnecting mechanisms, would be attached to or detached from each other by a specially designed robot, according to a proposal. In the original intended application, the modules would be those of a facility or station in outer space, and the robot reconfiguration scheme would make it unnecessary for astronauts to venture outside a spacecraft or space station. The concept may also prove useful on Earth; for example, in the assembly, disassembly, or reconfiguration of equipment in such hostile environments as underwater, near active volcanoes, or in industrial process streams.

In the example of the figure, the modules would be cylindrical, and each module would have four attachment subassemblies spaced equally around the circumference. Each attachment subassembly would consist of a flange having male fluid, electrical, and force-carrying connectors on one side. The male side of any attachment subassembly could mate with the female side of an attachment subassembly on any other module. As shown in the figure, there would be at least two rows of modules so that there would be redundant paths for passing force, fluid, data, and power. Also, any critical modules would be duplicated to provide redundancy. These redundancies would allow the robot to remove any single module without causing loss of operation of the still connected modules.

To guide the robot when it positions modules to be connected, the male sides of the attachment subassemblies would be equipped with a TV camera, and the female sides with an optical target. The force-carrying connector would consist of self-aligning kinematic mounts. Once the robot brought the male and female sides of two attachment subassemblies into contact, a motor on the male side would drive a wedge between rollers on the two sides in manner that would drive the kinematic mounts together, locking the two attachment subassemblies, as well as causing their electrical and fluid connectors to mate.

The robot would be a walker-type manipulator having two sets of three-axis wrist joints connected by an elbow joint. Each



The **Two-Arm Walking Robot** would connect and disconnect modules, operating either autonomously or under remote supervision. The robot would walk along a row of connected modules by grasping successive attachment subassemblies in a hand-over-hand motion.

joint would include the motor, gearing, and sensors for position and torque. Each end of the robot would be equipped with an end effector configured like the male side of an attachment subassembly, so that the end effector could lock itself to the female side of any attachment subassembly. The robot would be controlled by a computer that would allow it to function autonomously or under supervision of a remote operator. The robot would walk along a set of connected modules by making the end effectors successively grasp and release attachment subassemblies. If one of the robots end effectors were dedicated to car-

rying a module, then the male side of one of the carried-module attachment subassemblies would act as the second robot end effector for the purpose of walking.

*This work was done by Lloyd R. Purves of **Goddard Space Flight Center**. For further information, Circle 24 on the TSP Request Card.*

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Goddard Space Flight Center [see page 20]. Refer to GSC-13408.



APOLLO COMMEMORATIVE POSTER—

Actual size: 30" x 21" In Full Color! Printed on quality poster stock.

Price only \$8.95 each plus \$5.00 for shipping and handling. (NY residents add sales tax to total)

Mail payment to:

NASA Tech Briefs, Dept. F, 41 East 42nd St., New York, New York 10017

For credit card orders call: (212) 490-3999



More About the Farley Three-Dimensional Braider

Yarns can be incorporated at arbitrary braid angles.

Langley Research Center, Hampton, Virginia

The Farley three-dimensional braider, now undergoing development, is a machine for the automatic fabrication of three-dimensional braided structures. It can incorporate yarns into a structure at arbitrary braid angles to produce a complicated shape. The machine is intended for use in making fiber preforms for fiber/matrix composite parts — for example, multiblade propellers. [The machine is also described in "Farley Three-Dimensional Braiding Machine" (LAR-13911), *NASA Tech Briefs*, Vol. 15, No. 3, (1991,) p. 60].

The braider includes a braiding surface, which is a partial or full surface of revolution composed of movable segments (see Figure 1). Each segment is covered with an assemblage of mechanisms called "pivot points," each of which includes a rotatable disk holding a shaft that constitutes a track along which a yarn carrier can travel.

Each yarn carrier includes a spool with a rewinding mechanism and a fault sensor. The yarn carrier is propelled along the pivot points by a tractor consisting of an electric motor, a gear-head assembly, a drive gear that engages rack gears on the pivot points, and a linear-motion bearing that engages the shafts on the pivot points (see Figure 2).

The yarn carriers move across the braiding surface and between segments by moving from one pivot point to another. The direction of travel of each yarn carrier is controlled by rotating, to the appropriate orientations, the pivot points along its trajectory. The direction of travel of a yarn carrier can be changed by stopping at a designated pivot and rotating that pivot point to the desired new orientation.

The braiding surface also holds fixed tubes to feed nonbraiding (fill) yarns. These fill yarns are used as unidirectional fibers in the preform; e.g., fibers that lie parallel to the braiding axis of a preform.

The braider includes a material-takeup system, which is customized for the unique geometry of the preform. This system maintains a constant distance between the braiding plane on the preform and the segmented braiding surface. This makes it possible to control the braid angles of the yarns accurately and facilitates the maintenance of tension on the braiding yarns.

A computer and associated electronic




Figure 1. The **Braiding Surface** includes movable braiding segments containing pivot points, along which the yarn carriers travel during the braiding process.

equipment coordinate the multiple simultaneous motions of the braiding surfaces, pivot points, yarn carriers, and the material-takeup system. The multiplicity of possible motions gives the designer great

flexibility in assigning braid angles and other parameters to the yarns in the structure.

This work was done by Gary L. Farley of **Langley Research Center**. For further information, Circle 1 on the TSP Request Card.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Langley Research Center [see page 20]. Refer to LAR-14047.




Figure 2. A **Yarn Carrier** travels along a sequence of pivot points as the braiding segments move. The combined motions position the yarns for braiding onto the preform.

Apparatus Splits Glass Tubes Longitudinally

Tubes are split into half cylinders by the hot-wire/thermal-shock method.


John F. Kennedy Space Center, Florida

The apparatus shown in the figure splits glass tubes in half longitudinally by the well-known hot-wire/thermal-shock method. A tube to be cut is placed on a notched jig in the apparatus.

A nichrome wire is stretched between the arms of a pivoted carriage and oriented parallel to the notch. The wire is heated by electrical current while it rests on the tube. After heating for about 1 minute for each millimeter of thickness of glass, the tube is quenched in water and is split by the resulting thermal shock.

The apparatus has been used to split tubes in sizes ranging from $\frac{3}{8}$ in. (9.5 mm) in diameter by 1 in. (25.4 mm) long to $1\frac{1}{2}$ in. (38.1 mm) in diameter by 4 in. (102 mm) long.

This work was done by Ernest Shaw and Robert O'Neil Manahan of Lockheed Space Operations Co. for **Kennedy Space Center**. For further information, Circle 52 on the TSP Request Card.
KSC-11547



The Hot Wire Bears on the tube in the notched jig, under the weight of its pivoted carriage.

PRESSURE AND VACUUM SEALING ASSEMBLIES

No other company offers you more.

- More custom-engineering experience—over 40 years.
- More innovative designs through the application of our unequalled "soft" sealant technology to solve a wide range of sealing problems including:
 - Wires • Probes • Tubes
 - Electrodes • Fiber Optics
- More in-house capabilities—from design through testing.
- More flexibility—products to meet industrial and military quality requirements.

For more information,
including our catalog call

Toll-Free 1-800-223-2389

Conax[®]
Buffalo

An
IMI
Company

2300 Walden Ave. • Buffalo, New York 14225
(716) 684-4500 • Toll-Free 1-800-223-2389
FAX: (716) 684-7433



Adjustable Bracket for Entry of Welding Wire

The angle of the bracket can be adjusted to give a clear view.


Marshall Space Flight Center, Alabama

The wire-entry bracket on a welding torch in a robotic welding system provides for adjustment of the angle of entry of the welding wire over a range of $\pm 30^\circ$ from a nominal entry angle. The wire can thus be positioned so that it does not hide the weld joint in the view of the through-the-torch computer-vision system that is part of the robot-controlling and -monitoring system. ("Through the torch" is something of a misnomer; the view is along the axis of the torch.)

The wire-feed-through tube is mounted on the adjustable wire-entry bracket, which, in turn, is mounted on the torch head (see figure). The bracket can swivel within the limits of an arced slot, which defines the $\pm 30^\circ$ angular range on either side of the nominal central angle.

The swiveling bracket could also be used on a nonvision torch on which the wire-feed-through tube could interfere with the work-piece. The angle would simply be changed to one that gives sufficient clearance.

This work was done by Jeffrey L. Gilbert and David A. Gutow of Rockwell International Corp. for Marshall Space Flight



Center. No further documentation is available.

Inquiries concerning rights for the commercial use of this invention should be ad-

ressed to the Patent Counsel, Marshall Space Flight Center [see page 20]. Refer to MFS-29837.



Technical Graphics and Data Analysis in Windows!

only \$495.00 (\$600 Overseas) 60 Day Money Back Guarantee!

"This is the best scientific software I have found...I LOVE THIS PRODUCT!"

Dr. Dipen N. Sinha, Physicist - Los Alamos National Laboratory

"I am a great fan of this program. Congratulations to the authors on a great job!"



Dr. Bruce Bean - Dept. of Neurobiology, Harvard Medical School

"A true Windows graphics package for the scientist... SUPER PROGRAM!"

Paul K. Wallace - Dept. of Microbiology and Immunology, The Medical College of Pennsylvania

FEATURES INCLUDE:

- Many chart types, including line, scatter, column, bar, area, error bars, hi-lo-close, spline, step, box, QC charts, polar plots and waterfall plots.
- Create charts in multiple WYSIWYG windows with zooming, scrolling, and easy double-click editing of all graphic elements.
- Sophisticated "layer" system makes it easy to put multiple graphs on a single page.
- Function plotting, statistics, t-Test, histogram, regression, curve fitting to user-defined models, and much more.
- A powerful scripting language lets you create custom applications. Also supports DDE and DLL.
- Superior publication-quality output. Makes beautiful color slides.
- Network and multi-user packs available.
- 3D and contour module now available for \$125.00 (\$150 Overseas).
- Available as a DLL - Ideal platform for OEM applications.



For More Information
Call 1-800-969-7720

Microcal Software, Inc., 22 Industrial Drive East, Northampton, MA 01060 (413) 586-2013 Fax (413) 586-0149

Separation of Metals Bonded With Two-Sided Tape

Ultrasonic cleaning in hot kerosene enables separation without damage.

Langley Research Center, Hampton, Virginia

A procedure has been developed to separate, without pulling, bending, or prying, objects that have been temporarily bonded together with two-sided tape. The need for the technique arose as follows:

A National Institute of Standards and Technology test specimen made of 200-series nickel, 0.050 in. (1.3 mm) thick, was to be lapped to a flatness of 0.0000 to 0.0002 in. (0 to 5 μ m) prior to vacuum brazing. The specimen had to be bonded to a block of 17-4 PH stainless steel to hold it for the lapping procedure. In preparation for bonding, the specimen was ground flat on one side. Then it was bonded to the block by use of two-sided tape. The thinness and softness of the nickel specimen made it vulnerable to bending, thereby necessitating the development of a technique to remove it from the block after lapping, without bending it or otherwise degrading its flatness.

Because of unacceptable results obtained by use of a typical hot kerosene bath, the new procedure was introduced. Specimens bonded to blocks were placed in kerosene in an ultrasonic cleaning unit and the temperature of the kerosene was adjusted to 180 °F (82 °C). The parts separated, and all signs of adhesive were gone within minutes. The use of ultrasonics in this debonding procedure has made it possible to maintain gap tolerances of less than 0.0005 in. (13 μ m).

The debonding procedure is simple. In a more systematic version of the procedure, the bonded objects to be separated are placed in a tank that is equipped with an ultrasonic transducer and that is large enough to hold and completely submerge the parts in kerosene. The kerosene is heated to a temperature between 180 °F (82 °C) and 220 °F (104 °C). The ultrasound is turned on before the parts have reached 170 °F (77 °C) to ensure that the kerosene penetrates between the pieces and starts to dissolve the adhesive. When the temperature of the parts has reached about 180 °F (82 °C), the parts can be removed from the kerosene and separated by sliding or pushing them apart. The nickel specimen (or other part of interest) is then cleaned in trichloroethane to remove kerosene residue. It is then placed in an ultrasonic cleaning unit with a cleaning solution and heated to 120 \pm 10 °F (49 \pm 6 °C) for 5 minutes. Finally, the specimen is rinsed thoroughly, first in deionized water, then in isopropyl alcohol. After drying with a hot-air gun, the specimen is ready for vacuum brazing.

The ability to remove tapes and protective papers, regardless of age, by use of this procedure has been proved. Four-

month-old protective paper was removed from 6061 Al in 20 minutes at 150 °F (66 °C) with no adhesive residue. A 5-year-old protective paper was removed from Inconel 625* with little effort. The paper came off in 15 minutes. The removal of the adhesive, which had dried out completely, took an additional 20 minutes at 180 °F (82 °C). Masking tape comes off metals completely in less than 5 minutes at 150 °F (66 °C). This procedure is gen-


erally applicable in the removal of protective backing from metals as received, or in removing temporary bonding tape from metal specimens without damage to the specimens.

*"Inconel" is a registered trademark of the INCO family of companies.

This work was done by Michael L. Kelly of Langley Research Center. No further documentation is available.

LAR-14495

Heavy hitter.



Bruce Coleman photo

He's one of the most formidable natural combat systems in existence, and we can tell you exactly how many force-pounds he'll exert at the point of impact.

NTS can also simulate shock with some of the world's most sophisticated dynamic test equipment: 45,000 force-lb. to 200 g's; 25,000 g's pyroshock; hydroshock to 30 g's, 30 ms. Other capabilities include acoustic levels to 170 dB, acceleration of 800 g's/250 lb., thermal vacuum to 10⁻⁸ torr, static loads exceeding 100,000 lbs, EMI/RFI of 200 V/m to 40 GHz, fast cookoff, environmental chambers for any environment conceivable, and a full range of engineering services that include FMEA, fine grid and stick model FEA, and mathematical behavior analysis.

For testing that really packs a punch, call or write NTS.



Engineers and technicians: Employment opportunities are available

**National
Technical
Systems**

24007 Ventura Blvd.
Calabasas, CA 91302
West (800) 677-2NTS
East (800) 723-2NTS

For More Information Circle No. 690



Advancing-Front Algorithm for Delaunay Triangulation

Computational grids are generated from arbitrary nodal points.

Ames Research Center, Moffett Field, California

An efficient algorithm performs Delaunay triangulation to generate unstructured grids for use in computing two-dimensional flows. As used here, "unstructured" means specified in terms of arbitrarily located points (nodes). Delaunay triangulation solves the problem of which pairs of nodes to connect with straight-line segments so as to obtain an optimum tessellation of the grid area. The Delaunay triangulation of a given set of nodes is unique. In addition, it maximizes the smallest angle in the grid — a feature that is desirable in some applications.

Figure 1 illustrates the basic principles of Delaunay triangulation. Consider a plane containing some nodes. The plane can be divided into polygonal areas, called "Dirichlet regions," each of which is the locus of all points that are closer to a given node than to any other node. Each vertex of a polygon is equidistant from several (usually three) nodes. A circle centered on the vertex is drawn through the (usually three) nodes.

This circle is called the "circumcircle," and unless one or more of the nodes of the circumcircle lie on the boundary of the grid, no other node lies within the circumcircle. Provided that there are three nodes on the circumcircle, the nodes can be connected with straight lines to form a triangle. (As explained subsequently, a slightly different procedure must be used when the number of nodes on the circumcircle exceeds three). This process is repeated until every node is connected by straight lines, thereby constructing the grid out of triangles.

Figure 2 illustrates how the algorithm performs the Delaunay triangulation, starting from a line of nodes that defines a boundary and advancing across a field of nodes. The algorithm involves the following steps for each pair of adjacent nodes along the boundary:

1. Find any node on the correct side of the boundary.
2. Construct a circle through this node and the two nodes in question on the boundary.
3. Find the node (if any) closest to the center of the circle. (Do not count nodes on the circle or on the wrong side of the boundary.)
4. If no node was found in step 3, then the node found in step 1 is the correct one

to use in the Delaunay triangulation. If a node was found in step 3, then repeat step 2, using this node instead of the node found in step 1.

5. Repeat the foregoing steps at all points along the boundary. The edges of the Delaunay triangles thus constructed can be regarded as a new boundary or front. By performing steps 1 through 5 along the new boundary, one causes the front to advance. The process is repeated until all the nodes are incorporated into the grid.

It can happen that four points lie on the circumcircle. This situation typically occurs when a mesh-generating algorithm has specified nodes that lie within roundoff er-




Figure 1. **Delaunay Triangles** are constructed by connecting nodes with straight lines according to rules described in the text. The large dots denote nodes. The solid lines denote Delaunay triangles. Dotted lines indicate borders of Dirichlet regions. The dashed circle through three nodes is a circumcircle.




Figure 2. An **Advancing-Front Delaunay Triangulation** is shown at two different stages of completion.

ror of a perfect rectangle. (Redundancies of higher order could occur in principle but are rare in practice.) In such a case, two points present themselves as candidates to be the next point incorporated into the grid, and selection of the wrong one could result in crossed gridlines, which are not allowed. The algorithm selects whichever one of the two candidate nodes lies on the correct side of the advancing boundary.

Once a grid has been generated, one can optionally call upon an additional subalgorithm that removes diagonal lines from quadrilateral cells that are nearly rec-

tangular. The resulting approximately rectangular grid can reduce the cost per iteration of a flow-computing algorithm.

This work was done by Marshal L. Merriam of **Ames Research Center**. Further information may be found in AIAA paper 91-0792, "An Efficient Advancing Front Algorithm for Delaunay Triangulation."

Copies may be purchased [prepayment required] from AIAA Technical Information Service Library, 555 West 57th Street, New York, New York 10019, Telephone No. (212) 247-6500.
ARC-13092

Algorithm for Enlargement of Digitized Images

DIEBRA synthesizes higher spatial resolution better than do prior algorithms.

NASA's Jet Propulsion Laboratory, Pasadena, California

The Digital Image Enlarging Balanced Reconstruction Algorithm (DIEBRA) enlarges a digitized image composed of square pixels in such a way as to make the image look more like the real scene. If a digitized image is merely expanded to larger pixels or groups of pixels by use of a simple scale factor, the resulting larger squares, which correspond directly to the original pixels, lend an appearance of blockiness. DIEBRA synthesizes the enlarged image at a greater number of pixels, smoothing out the blockiness while providing resolution finer than that of the original pixels and, therefore, closer to that of the scene.

Prior techniques for reduction of blockiness and partial reconstruction of high-resolution image data have typically involved interpolation between pixels as though the pixels were point sources, followed by resampling of the interpolated image data at the higher resolution. Such techniques smooth out the blockiness and give the appearance of higher resolution, but the variances in the local brightness of the resulting images are smaller than those of the corresponding real scenes, and the resulting images exhibit only marginal correlation with true high-resolution imagery.


DIEBRA is based on a more-realistic treatment of pixels, not as points but as areas that represent spatial-resolution elements or fields of view of the imaging instrument. In this treatment, the brightness of each picture element is understood to be the brightness in the scene averaged over the field of view or resolution element with weighting by the point-spread and/or other response function of the instrument.

Lacking information on the response function of the instrument, one can also obtain adequate results by assuming a non-weighted averaging over each original pixel and attempting to recover the high-resolution imagery by use of a square-wave filtering kernel.


The prototype version of DIEBRA enlarges the image to 3 x 3 times the original number of pixels. A 5 x 5-original-pixel

construction kernel (see figure) is moved across the image in jumps between centers that correspond to those of the original pixels. At each jump, polynomial fits are performed along the horizontal, vertical, and diagonal lines through the center, and only the interpolated values in the 3 x 3 new pixels in the central original pixel are retained.

Next, the interpolated brightness in the



The **Reconstruction Kernel**, shown here schematically, is moved across the image in increments that correspond to the original pixels.



The Superstar of Mathematical Software

Macsyma Now Costs \$349.00*

An Unbeatable Value on PCs and Workstations

Macsyma not only offers the most complete and reliable portfolio of mathematical capabilities, it now has an unbeatable price. Macsyma's new PC version runs as a regular Windows 3.1 application with many improvements.

- World's best trig simplification and best differential equation packages are now even stronger. Factoring of large integers is 1,000 times faster.
- Color Scientific Graphics includes graphic windows with user controls for rotate, zoom, hardcopy printing, postscript output, colors, plot labels. Also, plotting of parameter surfaces, improved hidden line removal.
- New screen display of special math symbols, exponents, and Greek letters makes output more readable.†
- Easy-to-use hypertext† on-line help system with 1,500 text entries, 500 executable examples and demonstrations. Function templates† indicate function names and argument slots.


If you want the best mathematical software at a price the competition can't touch, call 1-800-MACSYMA (1-800-622-7962) or FAX 617-646-3161. Quantity discounts and academic prices are available. *Small workstations start at under \$1,000. Call For Demo Diskette †only on PC at this time.

Macsyma Inc.

20 Academy Street, Arlington, MA 02174

For More Information Circle No. 614

Need ball bearing slides?



See pages 8-41.

Get precision-engineered ball bearing slides with the Green Button™ safety release.
Get custom or standard

slide solutions.

Get the catalog. Call 1-800-626-9484.



**GENERAL
DEVICES**
Electronic Hardware
Manufacturers

General Devices Company, Inc.
1410 S. Post Rd.
P.O. Box 39100
Indianapolis, IN 46239-0100
FAX: 317-898-2917

Equipment Slides • Cabinets & Enclosures
Hardware & Accessories • Racks
Metal Fabrication • Custom Engineering

© 1992 General Devices Company, Inc.

For More Information Circle No. 315

Unmatched performance in noncontact measurement.

Our **fiber-optic** and **capacitive** noncontact measurement systems offer submicron resolution and high frequency response for a range of demanding applications:



Accumeasure System II



MTI-2000 Fotonic Sensor

- Vibration and modal analysis
- Runout and bearing analysis
- Gap and positioning control
- Thickness measurement
- Surface finish inspection

Our experienced engineers are ready to help you solve your measurement problems. Call us with your application: **1-800-342-2203**.

MTI Instruments

968 Albany-Shaker Road
Latham, New York 12110
518/785-2464 FAX: 518/785-2806



DIVISION OF MECHANICAL TECHNOLOGY INC.

For More Information Circle No. 337

central pixel of each new 3×3 block of pixels is increased or decreased and recursively interpolated until the mean brightness in the block matches that in the corresponding original pixel. This results in a reconstructed image that has greater contrast and that matches the real scene more closely than do images reconstructed by other techniques.

This work was done by William J. Rhea of Caltech for **NASA's Jet Propulsion Laboratory**. For further information, Circle 35 on the TSP Request Card.
NPO-18368

Books and Reports

These reports, studies, handbooks are available from NASA as Technical Support Packages (TSP's) when a Request Card number is cited; otherwise they are available from the National Technical Information Service.

Elements of Theory of Multidimensional Complex Variables

A system of multidimensional complex numbers and analytic functions thereof is described.

Two reports describe elements of a theory of multidimensional complex variables, with emphasis on three dimensions. Other algebras of hypercomplex numbers have been studied since the early nineteenth century in attempts to generalize the familiar theory of ordinary (two-dimensional) complex variables. Such attempts have been motivated largely by the importance and usefulness of analytic functions of ordinary complex variables in applications such as the calculation of two-dimensional potential flows, electrostatic fields, and other important physical phenomena. However, those algebras have not been completely satisfactory because of difficulty in application. The results of preliminary studies of the new theory suggest that analytic functions of the new three-dimensional complex variables should be useful in numerous applications, including representing of three-dimensional flows and potentials.

The first report introduces the general theory. A system of multidimensional complex numbers is defined with respect to an N -dimensional vector space having an algebra that is a commutative ring (with unity) with respect to multiplication but is in general not a division algebra. In the special cases of one and two dimensions, the system reduces to real and ordinary complex numbers, respectively. This system, based on a commutative algebra, is fundamentally different from other systems based on noncommutative, division algebras that generalize ordinary complex variables by way of quaternions.

NASA Tech Briefs, January 1993

Multiple Pages Intentionally Left
Blank

The new three-dimensional system is a direct analog of the ordinary two-dimensional system of complex numbers and variables. Based on the new algebra, the report defines functions of a three-dimensional variable and develops significant elements of a theory of analytic functions of one three-dimensional variable. One notable element includes conditions of analyticity analogous to the well-known Cauchy-Riemann conditions of analyticity in two dimensions. It is shown how the parts of an analytic function of a three-dimensional variable provide components of solenoidal and irrotational harmonic vectors in three dimensions.

The second report presents further developments in the theory of analytic functions of a single three-dimensional variable and applies the theory to the representation of ideal flows. A three-dimensional velocity and a three-dimensional complex potential are defined in terms of analytic functions of a three-dimensional variable. Components of the complex potential are shown to be related to a three-dimensional velocity potential and three-dimensional stream functions.

It is shown that solenoidal and irrotational harmonic vectors of the types described in the first report are provided also by the vector terms of a certain trigonometric-series expansion of every elementary analytic function of a three-dimensional complex variable. ("Elementary analytic function," as used here, means an analytic function extended from the set of ordinary complex analytic functions.) The primary part (defined as the first real vector term in such an expansion) of every elementary analytic function of one three-dimensional variable represents an axisymmetric flow. Simple examples of such flows include a uniform stream, stagnation-point flow, source flow, flow due to a doublet (dipole), and flow over a sphere.

This work was done by E. Dale Martin of Ames Research Center. To obtain copies of the reports, "Some Elements of a Theory of Multidimensional Complex Variables: Part I. General Theory" and "Some Elements of a Theory of Multidimensional Complex Variables: Part II. Expansions of Analytic Functions and Application to Fluid Flows," Circle 68 on the TSP Request Card. ARC-12843

Is your subscription about to expire?


Check the expire date. If it is less than 6 months now is the time to fill out a new qualification form before your subscription expires.

Introducing "OTTO".

The First True Autosync Scan Converter.

When you need to convert your high-resolution images to broadcast quality video, you need it done right the first time, without adjustments and configuration "guesswork".

Meet "OTTO", the first true Autosync Scan Converter from the leaders in scan conversion technology.



Folsom
RESEARCH



526 East Bidwell Street, Folsom, CA 95630
Tel: 916.983.1500 ■ Fax: 916.983.7236

For More Information Circle No. 540

Powerful Multi-Axis Motion Control


Easy As...

POINT →

CLICK

MOVE

Servo
32 Bit DSP
Encoder Inputs
Limit Inputs
Home Switch
68000 μ Proc
 ± 10 Volt Cmd



Stepper
Microstepping
750 K Step/Sec
Digital I/O Lines
2³² Count Range
Step / Direction
CW / CCW

Windows™

Macintosh®

High performance motion control boards for PC/386/486 ISA Bus & Macintosh NuBus Computers. Easy-To-Use software with pull down menus, interactive motion control windows and graphical programming tools. Full line of Servo Amplifiers, Stepper Drivers and Interface Units. 3-Axis boards from \$1,095.

nuLogic Inc

475 Hillside Avenue Needham, MA 02194
Phone 617-444-7680 Fax 617-444-2803

For More Information Circle No. 663



Monolithic Continuous-Flow Bioreactors

Oxygen is provided through selectively permeable membranes.

NASA's Jet Propulsion Laboratory, Pasadena, California

Monolithic ceramic matrices that contain many small flow passages have been shown to be useful as continuous-flow bioreactors. The ceramic matrix containing

the passages is made by extruding and firing a suitable ceramic, for example cordierite (made of alumina, magnesia, and silica) or steatite (made of magnesia and

silica). The pores in the matrix provide an attachment medium for a film of cells and allow free movement of solution. The ceramic matrix material must be one that is not toxic to the micro-organisms to be grown in the reactor.


In a reactor of this type, liquid nutrients flow over, and liquid reaction products flow from, a cell culture immobilized in one set of channels while oxygen flows to, and gaseous reaction products (e.g., carbon dioxide) flow from, the culture in an adjacent set of passages. The cells live on the inner surfaces of the passages that contain the flowing nutrient and in the pores of the walls of those passages. They thus have ready access to the nutrients and oxygen in the channels. They generate the continuous high yield characteristic of immobilized cells, without the large expenditure of energy that would otherwise be incurred if it were necessary to pump the nutrient solution through a dense biomass as in bioreactors of other types.

A monolithic ceramic bioreactor can be configured so that the nutrient- and gas-flow passages are parallel or perpendicular to each other, for example (see figure). The walls of the gas-flow passages are coated with a hydrophobic (permselective) membrane; e.g., polypropylene film containing submicron pores. This film does not allow water or nutrients to pass but allows oxygen to flow from the gas passages through the ceramic and into the biofilm — the layer of cells immobilized in and on the ceramic.

Many important biological reactions tend to become limited by the difficulty of providing oxygen and would benefit from the plentiful supply of oxygen through the matrix walls. Among them are fermentation by *Acetobacter aceti* to produce acetic acid, production of antibiotic by *Penicillium chrysogenum*, and resolution of L-amino acids from racemic mixtures by *Trigonopsis variabilis*.

The selective-transfer property of the ceramic wall was demonstrated in experiments with murine-murine hybridoma cells, which produce a monoclonal antibody to human fibronectin. A cordierite slab containing passages was inoculated with the cells and sandwiched between porous polypropylene membranes. Nutrient medium was pumped through the passages in the porous ceramic while a gaseous mixture of air and carbon dioxide was pumped along both membranes.

In one experiment, the cell colony — initially 2.4×10^8 cells — grew exponentially for the first 100 hours, then more gradual-



RADIOGRAPHY

Radiography is just one of the many applications possible with KeveX X-RAY's patented portable X-ray source, the PXS.

The PXS can create new market opportunities for your products. The design eliminates the bulk associated with conventional X-ray systems allowing your products to be portable, lightweight and compact.

Some new products to date include:

- A portable real-time imaging system for detection of tampered products in the field
- A radically different altimeter for the next generation of aircraft
- An on-line thickness gauge used in 100°C environments
- A compact X-ray fluorescence system
- A tabletop double crystal diffractometer
- An airborne meteorological device for measuring particle distribution


All possible because of the self-contained compact X-ray energy source, the PXS.

KeveX X-RAY integrated a miniature X-ray tube and a high voltage power supply into one compact, 5 lb. package. Operational from a 12 volt DC battery, this highly regulated, highly stable source has all the high voltage components molded internally. As a result there are no high voltage cables or connectors to work around.

Designed, manufactured, and sold only by KeveX X-RAY. Call or write KeveX X-RAY today for information on our complete line of portable sources including the 10 micron focal spot PXS.

keveX X-RAY

P.O. Box 66860
Scotts Valley, CA 95066 408-438-5940



Rows of Nutrient-Liquid Passages are parallel or perpendicular to rows of gas passages. Cells grow on and in the walls between nutrient and gas passages. The cells have plentiful supplies of both nutrient solution and oxygen.

ly until, after 250 hours, it produced monoclonal antibody at a constant rate of 1.2 milligrams per hour. Because the cells continued to secrete antibody, oxygen must have been supplied to them in adequate quantity.

This work was done by Gregory Stephanopoulos, Julia A. Kornfield, and Gerald A. Voecks of Caltech for **NASA's Jet Propulsion Laboratory**. For further information Circle 4 on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Edward Ansell
Director of Patents and Licensing
Mail Stop 305-6
California Institute of Technology
1201 East California Boulevard
Pasadena, CA 91125

Refer to NPO-18542, volume and number of this NASA Tech Briefs issue, and the page number.

Books and Reports

These reports, studies, handbooks are available from NASA as Technical Support Packages (TSP's) when a Request Card number is cited; otherwise they are available from the National Technical Information Service.

Water-Conserving Plant-Growth System

Nutrient solution is supplied only as utilized by seedlings.



A report presents further information about the plant-growth apparatus described in "Tubular Membrane Plant-Growth Unit." (KSC-11375), NASA Tech Briefs, Vol. 16, No. 2 (1992) page 113. The apparatus provides nutrient solution to the roots of seedlings

NASA Tech Briefs, January 1993

NEW

TOTALAB™ THERMAL ANALYSIS.

Precision is more affordable than ever.



Harrop's TOTALAB System is proof that thermal analysis instrumentation — DTA, TGA, and dilatometers — need not be expensive to be effective. TOTALAB is easy to use and designed for years of reliable operation. Analysis modules are available up to 1600°C. For data storage and more sophisticated analysis the new CYBER 702 digital data acquisition system is unique in its use of standard spreadsheet software. Or check out Harrop's traditional analog instrumentation. Either way, TOTALAB is the way to go for affordable — and effective — thermal analysis.

For more information, contact Harrop Industries, Inc., 3470 E. Fifth Ave., Columbus, Ohio 43219-1797. Phone: 614/231-3621. TELEX: 810 482 1645 FAX: 614/235-3699.

HARROP
INDUSTRIES, INC.



FIRE OUR IMAGINATION!

For More Information Circle No. 506

without flooding. It also conserves water by helping to prevent evaporation from the plant bed.

The system includes plant-growth units that contain porous ceramic tubes and concentric seedling holders supported by slotted mesh frames. Several seedlings extend their roots into the airspace between the seedling holder and the ceramic tube, where they draw nutrient solution by capillary action of the solution through the tube.

Within each growth unit, two ceramic tubes are joined in parallel to inlet and outlet manifolds. A flexible-sided reservoir feeds the inlet manifold. A miniature gear pump draws the nutrient solution through the tubes and returns it to the reservoir. The pump creates a suction that is large enough to prevent the solution from leaking freely through the tubes but is small enough to allow the solution to be withdrawn through the pores of the tube by capillary action.

The seedling holders shade the roots and prevent them from drying. Each seedling holder is a sheet of polyethylene that is wrapped around a ceramic tube and braced in place by soft plastic foam. The seedlings grow upward between the flaps at the openings in the seedling holders on the upper sides of the tubes.

This device was developed for supporting plant growth in space. There also may be

applications for growing plants with a minimum of water, such as in arid environments.

This work was done by Thomas W. Dreschel and Christopher S. Brown of The Bionetics Corp. for Kennedy Space Center. To obtain a copy of the report, "Porous tube plant growth nutrient delivery system for the Space Shuttle mid-deck locker Plant Growth Unit (PGU)," Circle 13 on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Kennedy Space Center [see page 20]. Refer to KSC-11536.

Isotonic and Isokinetic Exercise During Bed Rest

Brief, intense activity prevents deterioration of peak oxygen uptake, a measure of work capacity.

Regular, high-intensity isotonic leg exercise maintains peak oxygen uptake at normal levels during extended periods of bed rest, but high-intensity isokinetic exercise does not, a study has found. The study, which is described in detail in the report, was intended to explore the effectiveness of exercise in maintaining fitness during

long missions in microgravity so that crewmembers will be able to keep up the arduous work of building and expanding the Space Station.

In the study, 19 male volunteers, 32 to 42 years old, were confined to bed for 30 days in a 6°-head-down position. Five subjects did no exercise. Seven did isotonic leg exercise (cycling). Seven did isokinetic exercise (knee flexion and extension) on a Lido ergometer. The exercise was done in a supine position for two 30-minute periods a day. Various power levels were used for isotonic exercise, including some near the peak for each subject, as measured before bed rest began. The isokinetic exercise was done in sets of maximal contractions.

The subjects' peak oxygen uptake, heart rate, and volumes of plasma and red blood cells were measured frequently. Other tests included ultrasound and magnetic imaging of the legs to measure changes in muscles; magnetic imaging spectroscopy of the arms and legs to measure changes in the energy states of the muscles; and measurements of the concentrations of hormones in blood, the densities of bones, the calcium contents of cells, the composition and fluid balance of the body, cognitive performance, and mood.

For the subjects who did not exercise, the peak oxygen uptake fell an average of 18.2 percent during the 30 days. For those



You can find any electronic component out here.

who did isotonic exercise, it rose an average of 2.6 percent. For the group that performed isokinetic exercise, it fell by 9.1 percent.

The study showed that intermittent, intense exercise of short duration is more effective than is similar exercise at lower intensity for longer times measured in previous studies. Although the precise reason is not clear, intense short-term exercise seems to maintain the volumes of plasma and red blood cells at normal levels.

This work was done by J. E. Greenleaf of Ames Research Center, C. E. Wade of the Letterman Army Institute of Research, and E. M. Bernauer, T. S. Trowbridge, and A. C. Ertl of the University of California at Davis. To obtain a copy of the report, "Work Capacity During 30 Days of Bed Rest With Isotonic and Isokinetic Exercise Training," Circle 3 on the TSP Request Card. ARC-12180

Temperature Affects Fatty Acids in *Methylococcus Capsulatus*

Cis/trans ratios of monounsaturated fatty acids in membranes vary with temperature.

According to a report, the temperature of growth of the thermotolerant, methane-oxidizing bacterium *Methylococcus capsulatus* (Bath) affects both the proportion of monounsaturated fatty acids and the *cis/trans* ratio of these acids in the cell membrane. Because a suboptimum growth temperature is a potential stress factor, it may be possible to use such *cis/trans* ratios as indices of the stresses upon methane-oxidizing microbial communities, which are believed to play a major role in the nitrogen cycle and in the degradation of complex (particularly hydrophobic) organic compounds. In addition, research in the microbiology of methanotrophs is increasing because of the possible commercial exploitation of these organisms as biocatalysts or as sources of useful polymers; knowledge of the effect of temperature on the ability of methanotrophs to utilize methane may be useful in the optimization of conditions of growth.

In experiments described in the report, cultures of *M. capsulatus* (Bath) were grown in a mineral-salts medium with a continuous flow of a gaseous mixture of equal parts of methane and air at temperatures of 30, 37, and 45 °C. Cells in the early stationary phase were harvested by centrifugation, and the lipids were extracted. Methyl esters of the lipids were analyzed by gas/liquid chromatography. Monoenoic

methyl esters were separated into *cis* and *trans* fractions by thin-layer chromatography on soft silica gel G plates impregnated with silver nitrate. The zones that corresponded to *cis* and *trans* unsaturates were eluted from the silica gel by use of chloroform, and the distribution of the isomers was determined by gas chromatography. The positions of the double bonds of *cis* and *trans* monoenoics were determined by ozonolysis followed by gas/liquid-chromatographic analysis of the fragments.

From the results of these analyses, it was concluded that *M. capsulatus* (Bath) grew most readily at 45 °C: the cell yields were greatest at this temperature, and the doubling time at this temperature (3.8 h) was approximately a third of the doubling time at 30 °C (13 h). Growth at 30 °C resulted in the highest proportion of monounsaturated fatty acid (about 71 percent), with a *cis/trans* ratio of 1.3. Growth at 37 °C and 45 °C resulted in higher *cis/trans* ratios (8.1 and 6.5, respectively) and enhanced synthesis of the $\Delta 11$ and $\Delta 12$ positional isomers of the 16-carbon monounsaturate (where the number that follows Δ denotes the position of the double bond relative to the carboxylic end of the molecule).

This work was done by Linda L. Jahnke of Ames Research Center. For further information, Circle 19 on the TSP Request Card. ARC-12792



In here.

The new D.A.T.A. Parametric Access Library—D.A.T.A./P/A/L/™ can make a world of difference in how electronics professionals everywhere access electronic components.

This CD-ROM version of the D.A.T.A. books lists over 1.25 million integrated circuits and discrete semiconductors from more than 1000 manufacturers. And it does it with the speed and ease only CD-ROM can provide. D.A.T.A./P/A/L/ gives you the fastest access to the largest database in the industry. And it's also the most affordable at only \$295 per component category, or \$1930 for the complete library on a single disc. It's also available for use on any DOS network. To subscribe to the power of D.A.T.A./P/A/L/, call 800-447-4666 today.

D.A.T.A.

The mark D.A.T.A./P/A/L/ with design is a trademark of Information Handling Services, Inc. Prices applicable in the U.S. only.



You're looking at a new and better way to measure temperature!

It's the Mikron M190 infrared non-contact thermometer for permanent and semi-permanent installations. It's fast, accurate, reliable and computer-interactive!

- Accuracy: $\pm 0.25\%$ of reading
- Resolution: 0.1°C
- Through-lens sighting and sharp focussing
- Push button selected Peak and Valley functions
- Digital and analog output
- Software permits remote operation from computer
- Temperature range: 250 to 3000°C



445 W. Main St., Wyckoff, NJ 07481 U.S.A.
TEL: 201-891-7330 • FAX: 201-891-1205

Made in U.S.A.

For More Information Circle No. 333


HIGH POWER TRANSDUCERS DRIVEN BY MAGNETOSTRICTIVE TERFENOL-D

Features

- ☐ Highest Energy Density
- ☐ Low-Voltage Operation
- ☐ High Amplitude
- ☐ Wide Bandwidth
- ☐ No Poling, Aging or Fatigue
- ☐ Wide Temperature Range
- ☐ Excellent Acoustic Coupling

Applications

- ☐ Borehole Seismic
- ☐ Vibrators
- ☐ Acoustic Oceanography
- ☐ Underwater Communications
- ☐ Vibration and Noise Control
- ☐ Sonic Welding
- ☐ High Energy, Low Frequency Audio



The highest strain and energy density of any sonic transducer drive material available today.

Terfenol-D transducers operate at low voltage. The inherent low elastic wave speed

designed into high-tech Terfenol-D means transducers operate well at low frequencies...with excellent acoustic coupling to media such as water...and Terfenol-D offers wide band width.

Standard units are available for your immediate evaluation, or our engineers can design and manufacture a complete system to bring a competitive edge to your marketplace. Call us toll-free in the USA at 800-327-7291.



ETREMA PRODUCTS, INC.

ETREMA PRODUCTS, INC.

A Subsidiary of EDGE Technologies, Inc.
306 South 16th ■ Ames, IA 50010 USA
515/232-0820 ■ FAX: 515/232-1177

New on the Market

Cubital America Inc., Troy, MI, has unveiled the Solider 5600 **Data Front End (DFE) workstation** designed to increase the productivity of rapid prototyping systems. It enables on-site performance of such operations as subdividing large objects, stitching cracks between surfaces, increasing surface thickness, and eliminating redundant facets as well as Boolean operations between objects. The DFE's range of data formats includes ASCII, binary STL, SDRC's Universal files, AutoCAD's DXF, Digital Terrain Models, and VDAFS.

For More Information Circle No. 800



The Nifty Fifty, a 50 MHz 486 DX2 color LCD **notebook PC**, has been introduced by Ergo Computing Inc., Peabody, MA. It offers the speed, storage capacity, and expansion capability of a high-end desktop PC in a 6.7-lb. package (with battery) that measures just 8.5" x 11" x 2". Fully compatible with the MS-DOS, NT, UNIX, and OS-2 operating systems, the PC can be configured with 4, 8, or 16 MB of RAM. An optional expansion module accommodates two ISA 16-bit cards.

For More Information Circle No. 792

Kaman Instrumentation Corp., Colorado Springs, CO, has announced a **noncontact position sensing system** that can be customized to meet specific OEM requirements. The new SMU-9000 features sensors with measuring ranges to 40 mm, resolution to one part in half a million, 7.5 to 15 Vdc at 20 mA input power, and on-board voltage regulation.

For More Information Circle No. 780



A CFC- and methyl chloroform-free **release agent/dry lubricant** is available from Miller-Stephenson Chemical Co., Danbury, CT. MS-122N/CO2 is a Teflon-life, TFE release agent suited for polyurethanes, acrylics, polypropylene, phenolics, foams, rubber mold-

ings, epoxies, polycarbonates, polystyrene, pre-preg fabrication, and filament winding. The material contains no silicones and produces no discernable transfer or migration.

For More Information Circle No. 796

Mizar Inc., Carrollton, TX, has announced a **multiprocessor digital signal processing module** for the VMEbus capable of achieving peak speeds of 200 MFLOPS. The MS 7770 features four Texas Instruments TMS320C40 digital signal processors, which are fully interconnected for high-speed interprocessor communication. Each processor has three more 20-MB/sec communications ports to enable easy interconnection of multiple boards for such architectures as a 3D-mesh, ring, or hypercube.

For More Information Circle No. 788



HyperConverter, a stand-alone board from Expert Graphics, Atlanta, GA, enables easy and cost-effective **conversion of high-resolution computer graphics to NTSC- or PAL-compatible video**. The board automatically accommodates any input resolution up to 1024 x 768, 76 Hz (noninterlaced) in Super VGA, VGA, 8514, and XGA. Also capable of handling 16 and 24 bit graphics, it crisply reproduces images on a standard television set.

For More Information Circle No. 784

Workstation Technologies Inc., Irvine, CA, has introduced the **WTI-PrimeTime™**, a self-contained **television tuner** that gives desktop computers access to broadcast and cable video signals. Targeted for system integrators and OEMs, the tuner is available for Macintosh, IBM, and IBM-compatible computers; receives both UHF/VHF antenna input and cable signals in real time; and provides output to video digitizing cards.

For More Information Circle No. 786


Announcing CHANNEL EXPO- The Micro Channel® Product Showcase and Technical Conference running concurrently with BUSCON and SOFTCON



FEBRUARY 9-11, 1993
SAN JOSE CONVENTION CENTER
SAN JOSE, CA

The National Software Conference For System Engineers

and



BUSCON/93 WEST™

FEBRUARY 9-11, 1993
SAN JOSE CONVENTION CENTER
SAN JOSE, CA

Because There's a Soft Side To Every Hard Sell



Today's system solutions call for an integrated approach to hardware and software. That's why we've put **BUSCON** and **SOFTCON** together.

BUSCON, the leading trade show and conference for bus boards and other elements of systems architecture, now runs concurrently with **SOFTCON**, the national software conference for system engineers. The combined focus of **BUSCON** and **SOFTCON** bridges the gap for system integrators, engineers, and their managers seeking total solutions.

Coordinated by *Electronic Design*, **BUSCON** and **SOFTCON** offer the hardware and software solutions you need now. Our flexible format allows you to mix and match sessions from either program. And both conferences offer entry to the combined **BUSCON/SOFTCON** exhibit hall.

If you're looking for system solutions you can use now, then plan to attend **BUSCON '93 West** and **SOFTCON '93 West**, February 9-11, 1993 at the San Jose Convention Center, San Jose, CA. For more information, just return the coupon or call (800) 243-3238 or fax (203) 857-4075.



Yes, I want more information about integrated system solutions at BUSCON and SOFTCON.

Name _____

Title _____

Company _____

Address _____


City _____ State _____ Zip _____

Phone _____ Fax _____

Return to: CMC, 200 Connecticut Avenue, Norwalk, CT 06856-4990
(800) 243-3238, fax (203) 857-4075.

BS22

Edmund Scientific



PRECISION OPTICS STOCK AND CUSTOM

- OEM Optics
 - Spherical
 - Elliptical • Parabolic
 - Surface Mirrors
 - Optical Flats
 - Gold Coated Mirrors
 - Beam Splitters
 - Laser Optics
 - Simple Lenses
 - Achromats • Prisms
 - Fiber Optics
 - Fresnel Lenses
 - Magnifiers
 - Polarizers • Filters
- ## OPTICAL INSTRUMENTS
- Microscopes • Lasers
 - Collimators • Reticles
 - Comparators

Free Reference Catalog For Your Technical Library

Need Help? Our optical engineering department can provide expertise to help match our optics to your specific application. 204 page catalog features over 8000 optical and scientific products, complete with technical data and prices. **Call today!**

TEL: 1-609-573-6250

FAX: 1-609-573-6295

Serving Industry For Over Half A Century



Edmund Scientific Co.

Dept. 13B1, N922 Edscorp Bldg., Barrington, NJ 08007

For More Information Circle No. 461

You write the specs



NEW FOR OEMs! FLEXIBLE NONCONTACT POSITION SENSORS

Let us customize our SMU-9000 inductive position sensors to your requirements. We can adapt sensor size (we offer the world's smallest), packaging, and more. We combine this flexibility with outstanding performance: superior resolution, thermal stability, submersibility, etc. Call for assistance and a quote.

800-552-6267

Kaman Instrumentation, 1500 Garden of the Gods Rd.
Colorado Springs, Colorado 80907
Phone 719-599-1132, Fax 719-599-1823

KAMAN

New on the Market




Applied Data Systems Inc., Baltimore, MD, has engineered a palm-size **32-bit RISC-based video display system** for embedded applications. Dubbed the Pixel Press, the 3.1" x 5.1" module contains a 32-bit processor, 786 KB of EPROM, a parallel interface, an RS-232 debug port, and a voltage supervisor. Requiring just 700 ma at 5 volts, it provides a video output of 1024 x 768 non-interlaced resolution with 16 colors.

For More Information Circle No. 774


A stand-alone, high-performance, multi-platform **project visualization system** is available from Computervision Corp., Bedford, MA. The CVpvs™ allows AEC, mechanical, and manufacturing users to visualize any large-scale 3D CAD project to gain a better understanding of structure and appearance from every angle. At any stage of development, users can perform dynamic shaded viewing, animation, and 3D model simulations.

For More Information Circle No. 782



The FSU **force sensor** from NMB Technologies Inc., Chatsworth, CA, accurately measures weight and force in consumer and industrial products. Comprising a full strain-gauge Wheatstone bridge installed on a small aluminum bending beam, the sensor is available in rated capacities from 2.2 pounds to 1 pound with normal output of .5 mv/V. The FSU's .5" height permits its use in compact designs.

For More Information Circle No. 790



Digital Equipment Corp., Maynard, MA, has unveiled Alpha AXP—an advanced **64-bit computing architecture** comprising a complete set of systems, software, applications, and services. The universal platform offers a choice of three open software environments as well as open standards and hardware and network interconnects. Alpha AXP is designed to run commercial and scientific applications faster and at a lower cost and to explore advanced applications such as virtual reality, multimedia, artificial intelligence, simulation, and voice recognition.

For More Information Circle No. 778



BeamCAD and BeamCAD Plus **software for modeling laser beam propagation through optical systems** has been released by Coherent Instrument Division, Auburn, CA. The user specifies the beam characteristics (M^2 , waist diameter and location, and wavelength), then the software calculates beam width, wavefront radius of curvature, distance to beam waist, and Rayleigh range at each point specified in the optical system.

For More Information Circle No. 794


SpectraSource Instruments, Westlake Village, CA, has developed a series of low-cost 12-bit **CCD imaging systems**. The HPC-2 and MCD-1200 models, tailored for low-light and medical applications, offer image digitization at 325 kilo pixels per second and feature low read-out noise, low dark current, and wide dynamic range. The MCD-1200 enables scripting, external device triggering and control, and automatic multi-frame sequencing.

For More Information Circle No. 798

The industry's first family of **switching regulator power ICs** to break the 1 MHz barrier has been introduced by Harris Semiconductor, Melbourne, FL. At 1 MHz, the three HIP506X series chips can switch up to ten amps at 60 volts DC in less than three nanoseconds with ultra-low switching losses. They permit designers to employ current mode controlled PWM (pulse width modulation) fixed frequency switching techniques to produce miniaturized power supplies exceeding 1 MHz.

For More Information Circle No. 776

New Literature



Strawberry Tree Computer Instruments & Controls, Sunnyvale, CA, has published a catalog of **data acquisition and control** products for MS-DOS and Macintosh computers. The company's high-performance plug-in boards feature software selection of input type with built-in linearization, automatic calibration, and self-diagnostics. Icon-based WorkBench software permits easy measurement, analysis, and control with no programming.

For More Information Circle No. 714

A four-color brochure from DFI Pultruded Composites Inc., Erlanger, KY, outlines its **pultruded composites** capabilities and depicts pultruded structural profiles for various applications. The publication provides criteria for fiber selection, form, and placement; reviews the advantages of carbon reinforcing fibers; and discusses composite tolerances and the manufacturing expertise necessary to achieve them.

For More Information Circle No. 706

A 460-page **measurement and control** design handbook and buyer's guide has been published by EIL Instruments Inc., Hunt Valley, MD. Featured products include sensors, transducers, transmitters, controllers, counters, timers, ratemeters, analog and digital displays, recorders, data loggers, and test equipment.

For More Information Circle No. 708




The Tango line of DOS-based **electronic design automation (EDA)** software for PCs and compatibles is described in a brochure from ACCEL Technologies Inc., San Diego, CA. The EDA tools feature schematic-entry, various levels of packages for printed circuit board layout and autorouting, and programmable logic device design.

For More Information Circle No. 710

Heaters, sensors, and controls are showcased in an 850-page catalog from Watlow Electric Manufacturing Co., St. Louis, MO. Featured heaters include band and nozzle, cable, cartridge, ceramic fiber, flexible, radiant, strip, and tubular and process assemblies. Also highlighted are infrared sensors, ramping controls, microprocessor-based digital controls, alarms and limits, thermostats, and power switching devices.

For More Information Circle No. 702



Federal Marketing Services Inc., Rockford, IL, has released two new **ISO-9000 training** volumes. The *About ISO-9000 Workbook* reviews the purpose and benefits of ISO-9000 and provides guidelines for swift and cost-effective certifications, audits, assessments, and documentation. The *How To Write Your ISO-9000 Manual* trains management teams in the basics of the certification process, documentation, details of the ISO-9001 standard, formats, and reference methods.

For More Information Circle No. 712

A brochure describing the scientific data analysis capabilities of LabVIEW and LabWindows **instrumentation software** is offered by National Instruments, Austin, TX. The programs feature libraries for spectral, time, numerical, statistical, and regression analysis. They are easily customized and integrated for applications in medical monitoring, vibration analysis, process control, data acquisition, and test and measurement.

For More Information Circle No. 704

FREE LITERATURE

PEAK PERFORMANCE IN NOISE CONTROL.

SONEX pyramid sheets have a seamless, sound-absorbing surface that's visually attractive, acoustically effective. They're a great new product from the leader in acoustical material, illbruck. Use the reader service number below to get free literature. Or call toll-free today. **1-800-662-0032.**



For More Information Circle No. 404

COOL IT.

with Master Bond Thermal Conductive Adhesive

SUPREME11A0HT

- Room temperature or heat cure
- Highly electrically insulative
- Excellent vibration and shock resistance
- High peel and shear strength
- Outstanding chemical resistance
- Low shrinkage
- Convenient packaging

Master Bond Inc.
Adhesives, Sealants & Coatings

For information, call or write:
Master Bond Inc.,
154 Hobart St.
Hackensack, NJ 07601
201-343-8983

For More Information Circle No. 444

POSITIONS WANTED

Seeking ME position in machine design/development, automation, mechanisms. MS/BSME, FE/EIT with 2½ years in mechanical design/development of automated road maintenance equipment, 2¼ years as an aerospace engineer, and six years in machine shop design/fabrication, maintenance, and repair. 2D/3D AutoCAD, MILSPECS, kinematics, project management, and vendor/contractor coordination; some hydraulics and electrical. Call Ed Schultheis at (916) 753-4240.
Box Number 66

Ph.D in aerospace engineering; ten years of teaching and research experience in aerospace and mechanical engineering; teaching and research interests in aircraft design, aerodynamics, stability and control, propulsion, and thermofluid sciences. Willing to develop new curricula/courses. Interested in an industry or academic position in one of these areas.
Box number 67

Analytical chemist seeks position as senior or R&D analytical chemist. Experience in methods development, instrument design, vacuum technology, marketing support, technical supervision, hazardous materials, client training, and applications lab.
Box number 68

Recent grad (BSME). Hands-on person interested in work involving design and construction in the energy conversion or product and materials testing fields. Strong interest in alternate energy development.
Box number 69

BSME with experience in design and analysis of pressure vessels, piping and supporting structures, inspection and test of pressure vessels. Worked on IBM mainframe and PCs using finite element and structural design software for stress analysis. Performed plant inspection of modifications to equipment and components.
Box number 70

Aerospace/mechanical engineer with Ph.D in aerospace engineering seeks an R&D position in the field of computational aerodynamics. Eight years of experience in CFD of compressible/incompressible flows, propulsion, and heat transfer. Fortran, C and Unix proficient. Excellent publication record. Willing to relocate, available now.
Box number 71

BSEE honor student looking for entry level position in lightwave testing and measurement and/or microprocessor design. Experience in digital control system design and implementation, statistical analysis of parametric data, and computer programming. Proficient in C, Pascal, HPbasic, Assembler, MS-DOS, and UNIX. Michael Piszczek, Rd 3 Box 364C, Bernville, PA 19506, (215) 488-7725.
Box number 72

A certified NARTE (National Association of Radio and Telecommunication Engineers Inc.) senior engineer with extensive design experience in MIL-STD 461/462, RF, shielding, bonding (both analog and digital), computer and medical equipment, and test planning, procedure and proposal.
Box number 73

Mechanical/project engineer. BSME/MSME/PE. Capital and small project experience in design with cost estimating. Scheduling of pressure vessel, heat exchange, pumps, and pipe support for refinery and petrochemical. Cryogenic storage and transfer system design specification, project coordination of new and repair equipment for the Air Force.
Box number 74

Operation manager with 20 years professional experience. Six years in mechanical and civil engineering. 15 years in the hydro-turbine industry; held positions as operations manager, engineering manager, design and document control su-

pervisor, and senior mechanical draftsman. Designed the post-earthquake retrofitting gang forms for the piers of the Bay Bridge. Designed most of Hoover Dam's turbines replacement parts.
Box number 75

Extra-mile senior tooling specialist with over 28 years in the machining industry. Able to take tooling and prototype projects through concept, design, fabrication, assembly, testing, and refinements. Seeking permanent top-level position. Please write: Craig W. Bailey, 211 W. Sola Street, Unit #A, Santa Barbara, CA 93101-3040; or telephone: (805) 966-7652.
Box number 76

Mechanical engineer with experience in the operation, maintenance, performance testing, instrumentation, and control of marine, industrial, and utility power plant systems and equipment. Project engineer on EPRI-sponsored project. Control systems engineer with Bailey Controls and Bechtel Power Corp. BSME, BSEE (pending), Licensed Professional Mechanical Engineer, and Licensed Marine Engineer.
Box number 77

Human factors engineer. Ph.D in engineering psychology. Over 30 years experience in manned-space human factors. Areas include: man-machine function allocation, definition of displays and controls requirements, development of operator procedures, planning and conduct of man-in-the-loop simulations.
Box number 78

ME, PE, and MBA with strong manufacturing background seeks contract employment. Willing to travel but not relocate from Texas home. Full or part-time. Long-term or trouble shooting. Experienced in source inspection, audits, continuous improvement, and pragmatic solutions that will not break your organization or unduly provoke your staff.
Box number 79

MSME, BS in aerospace engineering. Experience in manufacturing environment. Areas of strength include strong analytical background, computer programming and modeling. Extensive studies in heat transfer, fluid dynamics, and computational mechanics. Work experience in stress analysis, analysis, fatigue testing, durability, testing, dynamic, and model testing, and finite element modeling.
Box number 80

Quality manager/mechanical engineer/MBA. Expertise in space propulsion, ordnance, and composite materials. Seven years aerospace and industrial manufacturing. Trained in quality assurance (TQM, SPC, ISO 9000, MIL-Q-9858, NHB 5200.4). Experienced in commercial and government program management. Proposed, negotiated, and administered budgets in excess of \$5M. Strong computer skills, DOD clearance. Seeks challenging position in a high-tech environment.
Box number 81

Software and knowledge engineer with extensive background in AI and expert systems technology. Scientific programming plus development of graphic editor using IBM PC and mainframes. Software: MVS, TURBO C, TURBO PROLOG. Languages: C, PROLOG, PL/1, REXX, BASIC. Many years of experience in various phases of software life cycle from functional specification to implementation. Education: MSEE, Ph.D.
Box number 82

Electrical and electromechanical engineer with laboratory and industrial experience in research, development and testing of various electromagnetic systems including rotating machines, electromagnetic actuators, other magnetic components including those using controlled permanent magnets; and in field and circuit modelling and calculations using original methods and computer simulation. Education: MSEE, Ph.D.
Box number 83

Systems engineer (BSME, MSSE, PE, Cert. Bus. Mgt.). 20+ years experience in systems and component design and analysis, and in liquid-propellant rocket engines (combustion devices, turbo-pumps, hydraulic and pneumatic valves, and controls). Additional skills in electro-hydraulic/mechanical flight control servo actuation systems and simulation (FORTRAN and CSMP). Seeking a full or contract position in engineering or marketing. Excellent references.
Box number 84

Searching for a job with electronics in computer information. Knowledge of Zenith G line VCR mechanism, Hitachi Ultravision Projection Television, Sony Projection Television, SMD soldering procedures, VCR mechanisms, Skew, cross-hatch, PLL, acquisition time, settling time, installation of radios, VR512, Pinch Cam, Capstan, and TV Test Patterns. Technical writing background includes block diagrams and accurate schematics.
Box number 85

Creative and hardworking analyst and programmer (last six years in aerospace). Experienced in software development, requirements analysis, technical writing, software development methodology, etc. Strong skills in translating Russian technical texts. Proven ability to solve difficult problems. Reliable and self-motivated. Flexible in working arrangements. Call/FAX 713/777-5886, 24 hours.
Box number 86

Ph.D organic chemist with 20 years experience in materials and process R&D. Synthesis, formulation, and process R&D on BMI's cyanates, PMR-15, epoxies, and acetylene-terminated polyimides; engineering polymers as matrix resins for advanced composites; specification and procedure development; interpretation of DSC, FTIR, RMS, HPLC; and mechanical testing on resins and composites.
Box number 87

To Request Resumes:

To obtain resumes corresponding to the above **Positions Wanted Ads**, fill out this form and mail to: *NASA Tech Briefs*, 41 East 42nd St., New York, NY 10017. ATTN: Jim Westbrook, or call 1-800-944-NASA and ask for Jim Westbrook.

Send resumes for the following box numbers (limit 5):

Box _____ Box _____ Box _____

Box _____ Box _____


Name: _____

Company Name: _____

Street Address: _____

City/State/Zip: _____

To submit an ad for inclusion in this column, send a copy of your resume and a 50-word summary to: *NASA Tech Briefs*, 41 East 42nd St., New York, NY 10017, ATTN: Jim Westbrook.



VIRTUAL REALITY CHECK

The "reality check." That crucial phase of the design process that determines whether or not your design can survive the transition from blueprints to the real world.

The reality check can be frightening because it forces you to ask tough questions. Could your design be lighter? Or faster? Or run more quietly? Can manufacturing produce it? Do your current vendors have the components you need? And so on.

Fortunately there's NDES. The National Design Engineering Show & Conference, March 8-11, 1993 in Chicago's McCormick Place North.

Here you'll find the answers to all the questions a "reality check" can conjure up. At NDES you'll examine over 25,000 components, systems and services from over 900 leading manufacturers. Everything from mechanical and electrical components ... to sensors and controls ... plastics and materials ... and the latest design hardware and software.

**For more information
call (203) 352-8239.**

There's also a complete applications-oriented Conference Program highlighting the latest design technologies and techniques. Have you heard the latest on fiber optic sensors? What about the newest benchmarking techniques? Or the emerging technologies in concurrent engineering? Sessions presented by industry experts will cover these and 56 other hot topics, including virtual reality.

So before your design moves on to the manufacturing process, make sure it can pass the "reality check." Just bring your questions to NDES. You'll find the answers you're looking for.



**National
Design Engineering
Show & Conference™**

**March 8-11, 1993
McCormick Place North
Chicago, IL**

NDES. We help designs make it in the real world.

Take advantage of National Manufacturing Week

Register for NDES and get free admission to these concurrent NMW events:

- International Control Engineering Expo (ICEE)
- National Plant Engineering & Maintenance Show and Conference (PEM)

Register now for discounted admission!

SAVE \$15! Register for NDES before February 5, 1993. After that date, bring this form with you to the show and present it to an attendee typist. You'll still pay only \$10. Registration without this form is \$25.

Mail to: The National Design Engineering Show, P.O. Box 552, Brookfield, IL 60513-0552. Note: Registration is for exhibits only. Please, only one registration per person.

Photocopy this form for additional registrants. For the trade only. No one under 18 admitted.

1. General Information (Please print clearly)

First Name										M.I.		Last Name										DES			
Job Title																									
Company Name																									
Division																									
Mailing Address												Dept. or M.S.													
City												State				Zip									
Country																									
Telephone												Fax												NAS	

2. Your Industry: (please check only one)

- A. ☐ Aerospace
- B. ☐ Agriculture
- C. ☐ Appliance/Consumer Products
- D. ☐ Automotive/Ground Transportation
- E. ☐ Communications
- F. ☐ Computers/Office Equipment/Systems
- G. ☐ Consulting
- H. ☐ Energy/Utilities
- J. ☐ Fabricated Metal Products
- K. ☐ Government/Defense
- L. ☐ Industrial/Commercial Machinery
- M. ☐ Medical/Pharmaceutical
- N. ☐ Mining
- P. ☐ Plastics/Elastomers/Materials
- Q. ☐ Printing/Publishing/Graphic Arts
- R. ☐ Process Manufacturing
- S. ☐ Sporting Goods/Leisure
- T. ☐ Other (please specify): _____

3. Number of employees in your company:

- A. ☐ 1-20
- B. ☐ 21-100
- C. ☐ 101-500
- D. ☐ 501-1000
- E. ☐ 1001-5000
- F. ☐ 5000+

4. Product Interest (check as many as apply):

- A. ☐ CAD/CAM/CAE/CIM
- B. ☐ Computer Hardware
- C. ☐ Coatings/Lubricants
- D. ☐ Electrical Components
- E. ☐ Electronic Components
- F. ☐ Electro-Optics
- G. ☐ Engineering Document Management/Imaging
- H. ☐ Hydraulics & Pneumatics
- J. ☐ Joining Systems/Adhesives/Fasteners
- K. ☐ Mechanical Components
- L. ☐ Metals/Alloys
- M. ☐ Nonmetals/Plastics/Elastomers
- N. ☐ Motion Control/Power Transmission/Fluid Power
- P. ☐ QA/QC/Testing
- Q. ☐ Sensors & Controls
- R. ☐ Shapes & Forms
- S. ☐ Other (please specify): _____



© Reed Publishing (USA) Inc., 1992. All rights reserved.
A part of the Reed International group.

It's the hottest thing in temperature calibrators.

From 212°F to 1202°F, Model 650 SE accurately calibrates thermistors, RTDs, thermocouples, and other instruments. The optional RS 232C interface of this microprocessor-controlled, multipurpose unit allows direct, simultaneous comparison of input signals with actual temperatures and lets you configure your own programs and produce documentation for full traceability. Other features: accuracy to $\pm 1.5^\circ\text{F}$; programmable memories/slope rates, switch-hold, mA input, 24 VDC output, analog output, and fast heat-up/cool-down.

For more information, contact AMETEK, Mansfield & Green Division, 8600 Somerset Drive, Largo, FL 34643. Tel: 813-536-7831. Fax: 813-539-6882.



AMETEK
MANSFIELD & GREEN DIVISION

For More Information Circle No. 417

License to exceed normal limits



Zirconia Fiber-Based Materials offer limitless possibilities

When you need exceptionally high temperatures, low thermal conductivity or resistance to chemical attack, choose one of Zircar's Zirconia fiber-based materials. Bulk fibers, flexible textiles, rigid boards or cylinders: nobody knows how to take Zirconia to the limit like Zircar!

Zircar
FIBROUS CERAMICS

P.O. Box 458, Florida, NY 10921
Tel: (914) 651-4481 Fax: (914) 651-3192



Subject Index

A

ACOUSTIC PROPAGATION
Pressure-coupled acoustic-transducer assembly
page 36 LAR-14263

ACOUSTO-OPTICS
Demonstration AOTF imaging spectrometer
page 54 NPO-18410

ADHESIVE BONDING
Separation of metals bonded with two-sided tape
page 81 LAR-14495

AGRICULTURE
Water-conserving plant-growth system
page 89 KSC-11536

AIRFOILS
Viscous/inviscid interaction on an oscillating airfoil
page 71 ARC-12472

ALGORITHMS
Advancing-front algorithm for Delaunay triangulation
page 82 ARC-13092
Algorithm for enlargement of digitized images
page 83 NPO-18368

ALLOYS
Electrochemical impedance spectroscopy of metal alloys
page 66 KSC-11575

AMPLIFIERS
Improved grid-array millimeter-wave amplifier
page 44 NPO-18548

ANALYTIC FUNCTIONS
Elements of theory of multidimensional complex variables
page 84 ARC-12843

B

BACTERIA
Temperature affects fatty acids in *Methylococcus Capsulatus*
page 91 ARC-12792

BED REST
Isotonic and isokinetic exercise during bed rest
page 90 ARC-12180

BICYCLE
Self-damping sprung wheel
page 70 MFS-28632

BIOCONVERSION
Temperature affects fatty acids in *Methylococcus Capsulatus*
page 91 ARC-12792

BIOREACTORS
Monolithic continuous-flow bioreactors
page 88 NPO-18542

BLACK BODY RADIATION
Calorimetric vacuum emissivity at 773 to 923 K
page 60 LEW-15104

BONDING
Separation of metals bonded with two-sided tape
page 81 LAR-14495

BOUNDARY ELEMENT METHOD
Analyzing stresses in orthotropic materials
page 68 LAR-14650

BRACKETS
Adjustable bracket for entry of welding wire
page 80 MFS-29837

C

CALORIMETERS
Calorimetric vacuum emissivity at 773 to 923 K
page 60 LEW-15104

CERAMICS
Monolithic continuous-flow bioreactors
page 88 NPO-18542

CHARGED PARTICLES
Effects of environmental electrical charges on spacecraft
page 55 NPO-18350

CIRCUITS
High-temperature-superconductor films in microwave circuits
page 46 LEW-15302

COMPLEX VARIABLES
Elements of theory of multidimensional complex variables
page 84 ARC-12843

COMPUTER COMPONENTS
Interface for MIL-STD-1553B data bus
page 48 LEW-15038

COMPUTERIZED SIMULATION
Simulating the SSF information system
page 67 NPO-18484

CRYOGENICS
Lightweight right-angle valve for cryogenics
page 72 MSC-21889

CRYOGENICS
Disk valve for cryogenics
page 72 MSC-21888

D

DATA PROCESSING EQUIPMENT
Interface for MIL-STD-1553B data bus
page 48 LEW-15038

DATA TRANSMISSION
Test-signal generator for SNR calibration
page 22 NPO-18495

DEFLECTION
Measuring deflections of propeller and fan blades
page 36 LEW-15287

DIFFERENTIAL INTERFEROMETRY
Differential interferometry for spacecraft navigation
page 55 NPO-18417

DIGITAL TECHNIQUES
Test-signal generator for SNR calibration
page 22 NPO-18495
Algorithm for enlargement of digitized images
page 83 NPO-18368

DIRECT POWER GENERATORS
Dummy cell would improve performance of fuel-cell stack
page 42 MSC-21919

DISKS (SHAPES)
Disk valve for cryogenics
page 72 MSC-21888

E

ELECTRIC GENERATORS
Dummy cell would improve performance of fuel-cell stack
page 42 MSC-21919

ELECTRICAL IMPEDANCE
Electrochemical impedance spectroscopy of metal alloys
page 66 KSC-11575

ELECTRO-OPTICS
Low-crossstalk composite optical crosspoint switches
page 42 KSC-11405

ELECTROCHEMICAL CORROSION
Electrochemical impedance spectroscopy of metal alloys
page 66 KSC-11575

ELECTRONIC EQUIPMENT
Effects of environmental electrical charges on spacecraft
page 55 NPO-18350

EMISSION
Calorimetric vacuum emissivity at 773 to 923 K
page 60 LEW-15104

END EFFECTORS
Robot avoids collisions with obstacles
page 48 KSC-11570

EXERCISE PHYSIOLOGY
Isotonic and isokinetic exercise during bed rest
page 90 ARC-12180

F

FATTY ACIDS
Temperature affects fatty acids in *Methylococcus Capsulatus*
page 91 ARC-12792

FIBER COMPOSITES
More about the Farley three-dimensional braider
page 78 LAR-14047

FIBER OPTICS
Noncontact measurement of shaft speed, torque, and power
page 30 LEW-15099

FLEXING
Machine tests optical fibers in flexure
page 40 LEW-15128

FRACTURE MECHANICS
Analyzing stresses in orthotropic materials
page 68 LAR-14650

FUEL CELL POWER PLANTS
Dummy cell would improve performance of fuel-cell stack
page 42 MSC-21919

FUNCTIONS (MATHEMATICS)
Elements of theory of multidimensional complex variables
page 84 ARC-12843

G

GLASS
Apparatus splits glass tubes longitudinally
page 79 KSC-11547

H

HEAD DOWN TILT
Isotonic and isokinetic exercise during bed rest
page 90 ARC-12180

HEAT PIPES
Mapping temperatures on heat pipes
page 58 KSC-11577

HIGH TEMPERATURE SUPERCONDUCTORS
Research on bi-based high-temperature superconductors
page 65 MFS-27264
High-temperature-superconductor films in microwave circuits
page 46 LEW-15302

HOHLRAUMS
Calorimetric vacuum emissivity at 773 to 923 K
page 60 LEW-15104

HOT FILM ANEMOMETERS
Measuring Tollmien-Schlichting instabilities in laminar flow
page 73 LAR-14132

ADVERTISERS INDEX

3M Electric Specialties Division	(RAC 436)	64
Aerospace Optics, Inc.	(RAC 309)	19
Algor Interactive Systems, Inc.	(RAC 449)	74
Ametek, Mansfield & Green Division	(RAC 417)	98
AMP, Inc.	(RAC 613)	26-27
Amtec Engineering, Inc.	(RAC 534)	60
Anvil Cases	(RAC 650)	67
ARSoftware	(RAC 435)	100
Ashlar, Inc.	(RAC 530)	5
Astro-Med, Inc.	(RAC 602)	2
Autodesk, Inc.	(RAC 504)	1
Avtech Electrosystems	(RAC 310)	101
Bancomm	(RAC 658)	50
BBN Systems and Technologies	(RAC 692)	66
Boeing Computer Services	(RAC 497)	9
BUSCON/93WEST	(RAC 420)	93
Cadkey, Inc.	(RAC 558)	21
C. Itoh Technology, Inc.	(RAC 424)	41
Cole-Parmer Instrument Co.	(RAC 416,574)	16,51-53
Communications Specialties, Inc.	(RAC 480)	101
Conax Buffalo	(RAC 691)	79
Concurrent Computer Corp.	(RAC 339)	43
Contemporary Cybernetics Group	(RAC 322)	15
D.A.T.A. Business Publications	(RAC 625)	90-91
Data Translation	(RAC 549)	23
DSP Development Corporation	(RAC 622)	COV IV
Edmund Scientific Co.	(RAC 461)	94
Elmo Mfg. Corp.	(RAC 509)	46
EPIX, Inc.	(RAC 675)	100
ESL	(RAC 390)	101
Etrema Products, Inc.	(RAC 592)	92
Farrand Controls	(RAC 452)	101
Fluid Dynamics International, Inc.	(RAC 391)	11
Folsom Research	(RAC 540)	87
Frequency Devices, Inc.	(RAC 640)	18
General Devices Co., Inc.	(RAC 315)	84
Glassman High Voltage, Inc.	(RAC 487)	31
Gould, Inc.	(RAC 418,484)	7,37
Hardigg Cases	(RAC 478)	55
Harrop Industries, Inc.	(RAC 506)	89
IBM Corporation		17
Illbruck, Inc.	(RAC 404,368)	95,102
INCO Specialty Powder Products	(RAC 652)	63
John Fluke Mfg. Co., Inc.	(RAC 510)	25
Kaman Instrumentation Corp.	(RAC 644)	94
Keithley Metrabyte	(RAC 619)	29
Keve X-Ray	(RAC 646)	88
Macsyma, Inc.	(RAC 614)	83
Magnetic Engineering, Inc.	(RAC 414)	100
Master Bond, Inc.	(RAC 444)	95
MathSoft, Inc.	(RAC 421)	39
Microcal Software, Inc.	(RAC 694)	80
Microstar Laboratories	(RAC 651)	100
Mikron Instrument Co., Inc.	(RAC 333)	92
Minco Products, Inc.	(RAC 541)	76
Mitchell and Gauthier Associates, Inc.	(RAC 580)	COV III
MTI Instruments	(RAC 337)	84
National Design Engineering Show & Conference	(RAC 304,312)	59,97
National Instruments	(RAC 681)	3
National Technical Systems	(RAC 690)	81
Nicolet Instruments Corp.	(RAC 526)	61
nuLogic, Inc.	(RAC 663)	87
Numerical Algorithms Group	(RAC 528)	102
Olympus Corporation	(RAC 334,335)	COV II
Patton & Patton Software Corporation	(RAC 499)	65
Precision Filters, Inc.	(RAC 415)	4
PSDI	(RAC 670)	68
Pure Tech, Inc.	(RAC 382)	100
Quantum Optics Company	(RAC 386)	101
RGB Spectrum	(RAC 467,469,479)	10,56,57
Rolyn Optics Co.	(RAC 458)	100
Sensoray	(RAC 674)	100
Stanford Research Systems	(RAC 364)	49
Stereographics Corporation	(RAC 503)	45
Strawberry Tree Structural Research & Analysis Corporation	(RAC 446)	73
Systran Corporation	(RAC 432)	100
Tektronix, Inc.	(RAC 637)	32-35
Teledyne Solid State	(RAC 517)	47
Velmet, Inc.	(RAC 605)	71
Zircar Products, Inc.	(RAC 621)	98
Z-World Engineering	(RAC 439)	100

*RAC stands for Reader Action Card. For further information on these advertisers, please circle the RAC number on the Reader Action Card in this issue. This index has been compiled as a service to our readers and advertisers. Every precaution is taken to insure its accuracy, but the publisher assumes no liability for errors or omissions.

Subject Index (Continued from page 98)

HYDROGEN
Compact Raman spectrometers would detect hydrogen
page 22 KSC-11441

HYSTERESIS
Research on bi-based high-temperature superconductors
page 65 MFS-27264

IMAGE PROCESSING
Algorithm for enlargement of digitized images
page 83 NPO-18368

IMAGING SPECTROMETERS
Demonstration AOTF imaging spectrometer
page 54 NPO-18410

INFORMATION SYSTEMS
Simulating the SSF information system
page 67 NPO-18484

INFRARED IMAGERY
Development of infrared imager for Spacelab
page 57 LEW-15188

INSPECTION
Voice-recognition system records inspection data
page 50 MFS-29780

INTEGRATED CIRCUITS
Interface for MIL-STD-1553B data bus
page 48 LEW-15038

INVISCID FLOW
Viscous/inviscid interaction on an oscillating airfoil
page 71 ARC-12472

ISOLATORS
Six-degree-of-freedom magnetic vibration isolator
page 75 MFS-26170

ISOTHERMS
Mapping temperatures on heat pipes
page 58 KSC-11577

LAMINAR FLOW
Measuring Tollmien-Schlichting instabilities in laminar flow
page 73 LAR-14132

LASER APPLICATIONS
More about laser scanner tests for single-event upsets
page 56 NPO-18494

LEAKAGE
Compact Raman spectrometers would detect hydrogen
page 22 KSC-11441

LOW TEMPERATURE TESTS
Machine tests optical fibers in flexure
page 40 LEW-15128

MAGNETIC PROPERTIES
Research on bi-based high-temperature superconductors
page 65 MFS-27264

MAGNETIC SUSPENSION
Six-degree-of-freedom magnetic vibration isolator
page 75 MFS-26170

MANIPULATORS
Robot would reconfigure modular equipment
page 77 GSC-13408
Robot avoids collisions with obstacles
page 48 KSC-11570

MEMBRANES
Monolithic continuous-flow bioreactors
page 88 NPO-18542

THE TECHNOLOGY CONNECTION

To Advertise Call (800) 944-NASA

Technologies for Transfer

AIRCRAFT

Software License Available

ELECTRIC

LOAD

ANALYSIS

PROGRAM

Version 3.0

Contact: GRUMMAN CORPORATION
CORPORATE LICENSING OFFICE A19B-GHQ
Bethpage New York 11714-3580
FAX: 516-575-3631

GRUMMAN®

AELAP copyrighted 1990 Grumman Aerospace Corporation

Databases/Information Searches

This is what the **Federal Laboratories Database** can put at your fingertips:

- 2,000 Federal Laboratories, Facilities and Centers
- \$70 billion in R&D
- expertise in 170 Critical Technologies
- specialized laboratory equipment

For information on the PC (\$495) and Macintosh (\$695) versions of the FLD contact the:

Mid-Atlantic Technology Applications Center
800-257-2725

Technology Transfer Publications

Are You Serious About Technology Transfer?

If so, you'll profit from *Technology Access Report*, the leading independent, practical newsletter in the field. *Technology Access Report* will help you master the process and increase your returns from technology transfer. You will find licensing and spinoff opportunities from universities and federal labs, for all industries and technologies.

Special Offer:—order your valuable, exclusive *Technology Access Resource Kit*:

- * Concise, durable annotated directory of the key tech transfer resources
- * Current issue of *Technology Access Report*
- * Comprehensive, five-year guide to *Technology Access Report* articles
- * Discount coupon worth \$50 towards your subscription (regularly \$447 for 12 monthly issues)
- * All for just \$9.95 (Amex/MC/Visa, cash or check).

Call 1-800/959-1059, fax 510/549-4342 or write to Technology Access Subscriber Services, P.O. Box 2189, Berkeley, CA 94702

Professional Services

Desk Top Publishing

Expert in publishing and all types of technical writing. Quality service & quick response. Guaranteed satisfaction. P.E., Veteran, Ph.D. (408) 436-8696.

Spanish Language

Translation of Engineering and Technical Documents

HispAmer
Tel: 415-291-8557
Fax: 415-433-5150

Patent View

Full text & image U.S. Patents weekly on CD-ROM. Chemical, electrical, mechanical subsets available. Call Rapid Patent @ 1-800-336-5010 ext. 900.

Professional Services

INVENTORS

If you have an invention for sale or license, write for our FREE booklet explaining how we can help you. Kessler Sales Corp Dept. C-76-3 Fremont, Ohio 43420


(Continued on page 101)

ORBIT WORKS®

Version 4.0

The MS-DOS PC software for the planning and analysis of space systems, spacecraft orbits, and operations.

280,000 times faster than real time!
Over 50 "TOOLS," INCLUDING:



- Polar and Equatorial Views of Orbits
- Flexible Synthesis of Symmetric Constellations
- Coverage of Points/Gap Time Statistics
- Detailed Pointing/Range Geometry
- Sun Geometry

SPECIAL PRICE OF \$395 (List Price \$595)

For More Information Call:
(800) 257-0073 or (301) 459-3773
Fax (301) 459-3776

ARSoftware

The Science and Technical Software Company

8201 Corporate Drive, Suite 1110
Landover, MD 20785-2230 USA

For More Information Circle No. 435

Real-Time Network


The SCRAMNet™ Network combines the real-time speed of replicated shared memory with the flexibility of a fiber optic LAN to get microsecond response from multi-vendor computers. It offers distinct advantages in critical simulations. Brochure highlights system's features.



Systran Corp., 4126 Linden Avenue, Dayton, OH 45432-3068 USA.
Phone (513) 252-5601 or 1-800-252-5601.

For More Information Circle No. 432

NEW! Little PLC™ \$195



Program It In C

Our new **Little PLC™** measures only 4.33 x 2.85 inches and can mount on standard DIN rail. This miniature controller costs only \$195, including 8 optically isolated inputs and 8 relay driver outputs. Low cost expansion cards allow you to add more inputs and outputs: digital and analog. It has dual RS-485 serial I/O, battery backed memory and time/date clock, programmable timers and a watchdog. Our easy to use and affordable **Dynamic C™** integrated development system also costs \$195. You can write simple programs in an hour, or you can develop major applications with 20,000 lines of C language.


Z-World Engineering

1724 Picasso Ave., Davis, CA 95616
(916) 757-3737 Fax: (916) 753-5141
24 hr. Automatic Fax: (916) 753-0618
(Call from your fax, request catalog #18)

For More Information Circle No. 439

INTELLIGENT DATA ACQUISITION

NEW!



Microstar Laboratories new e Series Data Acquisition Processors™ have on-board intelligence: a real-time software environment for quick development and fast operation. They run under DOS, Windows, or OS/2. Learn about this new hardware and software solution from a leader in the field. Free color catalog includes an easy-to-use approach to DSP. Call now—206-453-2345.


MICROSTAR

LABORATORIES™

Tel (206) 453-2345

Fax (206) 453-3199

For More Information Circle No. 651



4 MEG VIDEO Model 10

Flexible Image Processor and Application Accelerator For The PC/AT


- 8 to 8000 Pixels per Line
- 2 to 19 MHz sampling/display rate
- 10 MIPs Programmable Accelerator
- 4 Megabytes of Reconfigurable Image Memory
- RS-170, RS-330, and CCIR input/output
- Variable timing for nonstandard formats
- Genlock to external timing sources
- Analog or digital inputs
- Software programmable timing/resolution

EPIX®

3005 MacArthur Blvd., Northbrook, IL 60062
708-498-4002 FAX: 708-498-4321

For More Information Circle No. 675

HIGH PURITY PVD MATERIALS



*Whether for R&D or production,
Pure Tech manufactures the
high quality product you need*

PURE TECH
PO Box 1319, Carmel, NY 10512
TEL (914) 878-4499 • FAX (914) 878-4727

For More Information Circle No. 382




**FREE!
130
Page
Catalog**

**"Optics
for
Industry"**

Free 130 page product catalog from Rolyn, world's largest supplier of "Off-the-Shelf" optics. 24-hour delivery of simple or compound lenses, filters, prisms, mirrors, beamsplitters, reticles, objectives, eyepieces plus thousands of other stock items. Rolyn also supplies custom products and coatings in prototype or production quantities. **ROLYN OPTICS Co.**, 706 Arrowgrand Circle, Covina, CA 91722-2199, (818)915- 5707, FAX (818)915-1379

For More Information Circle No. 458

**Sensors
in...**



**...Data
out**

SENSORAY Model 419 for the IBM-PC combines sensor excitation, A/D conversion and digital processing in a compact 16-channel plug-in-board.

SENSORAY (503) 684-8005
FAX(503) 684-8164

For More Information Circle No. 674



**Magnetic
engineering
inc.**
P.O. Box 2480
215 S. Second Ave.
Frisco, CO 80443

(303) 668-1255 (303) 668-1242 FAX

**WE SPECIALIZE IN
HIGH ENERGY
MAGNETIC MATERIALS,
ASSEMBLIES AND
HEAVY GAUGE
PRECISION WOUND
CUSTOM COILS**

For More Information Circle No. 414

Official NASA CAPS



Black cap with gold leaves and official NASA insignia. Only \$9.95 each!

Please send (insert quantity) one-size-fits all NASA caps. Add \$5.00 for handling and shipping charges. NY residents add sales tax to total. TOTAL Enclosed: \$ _____

Name _____

Address _____

City _____

State _____ Zip _____

Mail payment to: **Nasa Tech Briefs, Dept. F**
41 East 42nd Street, Suite 921
New York, NY 10017

For credit card order call (212) 490-3999

Scan Do™

Computer-To-Video Scan Converter




Discover what a no-software-drivers-needed, flicker-free, worldwide compatible, 2.9 pound video scan converter can do! Call **516-273-0404** now! (Or FAX us at **516-273-1638**.)

☒ Communications
☒ Specialties, Inc.

...especially for high performance computer video.

For More Information Circle No. 480

FREE OPTICS CATALOG 50 Pages



QUANTUM OPTICS new 50-page catalog offers the best combination of quality, price and delivery on precision optics of all types for imaging and other applications. Catalog stock and custom-coated optics: mirrors, lenses, prisms, wave plates, and others. OEM capability.


QUANTUM OPTICS COMPANY

PO BOX 237, POMFRET, CONNECTICUT, 06258
(203) 974-6000 FAX (203) 974-6002

For More Information Circle No. 386

Precision Positioning Anywhere!

Farrand linear and rotary Inductosyn® transducers provide absolute and incremental positioning information accurate to ± 40 microinches, ± 0.5 arc second, or better. Rugged and reliable, our position transducers operate anywhere, even under extreme conditions—vibration, temperature from 10°K to 160°C , shock, high pressure, vacuum, and dust or oil films.



Call 914/761-2600 or fax 914/761-0405.


FARRAND CONTROLS

DIVISION OF RUHLE COMPANIES, INC.
99 WALL STREET—VALHALLA, NY 10595

For More Information Circle No. 452

LASER DIODE DRIVERS

HIGH SPEED HIGH POWER



Avtech offers over 80 different fast laser diode drivers. See our free 113-page general catalog for:

- Peak currents from 100 mA to 500 Amps
- Pulse widths from 200 ps to 1 ms
- Rise times as low as 100 ps
- Plug-in diode bias insertion units
- Lab instrument or miniature module format
- 250 other fast pulse generators, amplifiers, samplers, transformers and fast pulse accessories


AVTECH
ELECTROSYSTEMS

P.O. Box 265, Ogdensburg
New York 13669
(315) 472-5270

P.O. Box 5120, Station F
Ottawa, Canada K2C 3H4
(613) 226-5772
Fax: (613) 226-2802

For More Information Circle No. 310

Record, Playback, and Analyze at 500MS/s



With ESL's ViewPoint signal analysis system!

- 32 to 256 MBytes real-time storage
- 200 MHz analog bandwidth
- Single and dual channel systems
- 10 KS/s to 500 MS/s digital I/O
- Embedded i860 processing and analysis
- Flexible acquisition and playback modes

ESL, A Subsidiary of TRW
High Throughput Products
495 Java Drive, P.O. Box 3510
Sunnyvale, CA 94088-3510
408.743.6213

TRW

For More Information Circle No. 390

Subject Index

(Continued from page 99)

METHANE

Temperature affects fatty acids in *Methylococcus Capsulatus*
page 91 ARC-12792

MICROWAVE CIRCUITS

High-temperature-superconductor films in microwave circuits
page 46 LEW-15302

MICROWAVES

Improved grid-array millimeter-wave amplifier
page 44 NPO-18548

MILLIMETER WAVES

Improved grid-array millimeter-wave amplifier
page 44 NPO-18548

MODULES

Robot would reconfigure modular equipment
page 77 GSC-13408

MOISTURE RESISTANCE

Fail-safe pressure plug
page 75 MSC-21898

MULTILAYER INSULATION

Improved composite flexible blanket insulation
page 62 ARC-11955

N

NUCLEOPHILES

Poly(1,2,4-triazoles) via aromatic nucleophilic displacement
page 64 LAR-14440

O

OCEAN SURFACE

Degree of development of waves and bias in radar altimetry
page 60 NPO-18392

OPTICAL FIBERS

Machine tests optical fibers in flexure
page 40 LEW-15128

OPTICAL FILTERS

Demonstration AOTF imaging spectrometer
page 54 NPO-18410

OPTICAL SWITCHING

Low-crossstalk composite optical crosspoint switches
page 42 KSC-11405

P

PHYSICAL FITNESS

Isotonic and isokinetic exercise during bed rest
page 90 ARC-12180

PIEZOELECTRIC TRANSDUCERS

Pressure-coupled acoustic-transducer assembly
page 36 LAR-14283

PIPES (TUBES)

Apparatus splits glass tubes longitudinally
page 79 KSC-11547

PLANTS (BOTANY)

Water-conserving plant-growth system
page 89 KSC-11536

PLUGS

Fail-safe pressure plug
page 75 MSC-21898

POLYMERS

Poly(1,2,4-triazoles) via aromatic nucleophilic displacement
page 64 LAR-14440

PREFORMS

More about the Farley three-dimensional braider
page 78 LAR-14047

PRESSURE REDUCTION

Fail-safe pressure plug
page 75 MSC-21898

PRESSURE SENSORS

Single-tip probe senses pressure or temperature
page 74 LEW-15296

PROPELLER BLADES

Measuring deflections of propeller and fan blades
page 36 LEW-15287

PULSE COMMUNICATION

Telemetry tests of the advanced receiver II
page 56 NPO-18459

R

RADIATION EFFECTS

Effects of environmental electrical charges on spacecraft
page 55 NPO-18350

RADIO ALTIMETERS

Degree of development of waves and bias in radar altimetry
page 60 NPO-18392

RADIO RECEIVERS

Telemetry tests of the advanced receiver II
page 56 NPO-18459

RAMAN SPECTROSCOPY

Compact Raman spectrometers would detect hydrogen
page 22 KSC-11441

REDUCED GRAVITY

Development of infrared imager for Spacelab
page 57 LEW-15188

REENTRY SHIELDING

Improved composite flexible blanket insulation
page 62 ARC-11955

ROBOTICS

Robot avoids collisions with obstacles
page 48 KSC-11570

Robot would reconfigure modular equipment
page 77 GSC-13408

Adjustable bracket for entry of welding wire
page 80 MFS-29837

ROTATING SHAFTS

Noncontact measurement of shaft speed, torque, and power
page 30 LEW-15099

S

SANDWICH STRUCTURES

Improved composite flexible blanket insulation
page 62 ARC-11955

SCANNING

X-ray and acoustic measurements yield stiffness
page 28 LAR-14108

SEA LEVEL

Degree of development of waves and bias in radar altimetry
page 60 NPO-18392

SEALS (STOPPERS)

Disk valve for cryogenics
page 72 MSC-21888

Lightweight right-angle valve for cryogenics
page 72 MSC-21889

SIGNAL TO NOISE RATIOS

Test-signal generator for SNR calibration
page 22 NPO-18495

SINGLE EVENT UPSETS

Effects of environmental electrical charges on spacecraft
page 55 NPO-18350

More about laser scanner tests for single-event upsets
page 56 NPO-18494

SPACE NAVIGATION

Differential interferometry for spacecraft navigation
page 55 NPO-18417

SPACE SHUTTLE PAYLOADS

Water-conserving plant-growth system
page 89 KSC-11536

SPACE STATIONS

Simulating the SSF information system
page 67 NPO-18484

SPACECRAFT ENVIRONMENTS

Effects of environmental electrical charges on spacecraft
page 55 NPO-18350

SPACELAB

Development of infrared imager for Spacelab
page 57 LEW-15188

SPECTROSCOPY

Electrochemical impedance spectroscopy of metal alloys
page 66 KSC-11575

GUIDE TO NOISE CONTROL. FREE.



This brochure gives you detailed information about the industry's finest noise killers—**SONEX** acoustical sheets, baffles and ceiling tiles. For your free copy, use the reader service number below. Or call this number toll-free today. **1-800-662-0032.**

illbruck

© 1991, illbruck, inc.

For More Information Circle No. 368

Subject Index (Continued from page 101)

SPEECH RECOGNITION

Voice-recognition system records inspection data page 50 MFS-29780

SPLITTING

Apparatus splits glass tubes longitudinally page 79 KSC-11547

STIFFNESS

X-ray and acoustic measurements yield stiffnesses page 28 LAR-14108

STRESS ANALYSIS

Analyzing stresses in orthotropic materials page 68 LAR-14650

SUPERCONDUCTORS

Research on bi-based high-temperature superconductors page 65 MFS-27264

SUPERSONIC WIND TUNNELS

Single-tip probe senses pressure or temperature page 74 LEW-15296

SWITCHING

Low-crosstalk composite optical crosspoint switches page 42 KSC-11405

SYNTHESIS (CHEMISTRY)

Poly(1,2,4-triazoles) via aromatic nucleophilic displacement page 64 LAR-14440

T

TELEMETRY

Telemetry tests of the advanced receiver II page 56 NPO-18459

TEMPERATURE SENSORS

Single-tip probe senses pressure or temperature page 74 LEW-15296

THERMAL INSULATION

Improved composite flexible blanket insulation page 62 ARC-13095

THERMOCHROMIC MATERIALS

Mapping temperatures on heat pipes page 58 KSC-11577

TOLLIEN-SCHLICHTING WAVES

Measuring Tollmien-Schlichting instabilities in laminar flow page 73 LAR-14132

TORQUEMETERS

Noncontact measurement of shaft speed, torque, and power page 30 LEW-15099

TRIANGULATION

Advancing-front algorithm for Delaunay triangulation page 82 ARC-13092

TURBINE BLADES

Measuring deflections of propeller and fan blades page 36 LEW-15287

TWO DIMENSIONAL FLOW

Advancing-front algorithm for Delaunay triangulation page 82 ARC-13092

U

ULTRASONIC CLEANING

Separation of metals bonded with two-sided tape page 81 LAR-14495

ULTRASONIC WAVE TRANSDUCERS

Pressure-coupled acoustic-transducer assembly page 36 LAR-14283

ULTRASONICS

X-ray and acoustic measurements yield stiffnesses page 28 LAR-14108

V

VALVES

Disk valve for cryogenics page 72 MSC-21888

VALVES

Lightweight right-angle valve for cryogenics page 72 MSC-21889

VEHICLE WHEELS

Self-damping sprung wheel page 70 MFS-28632

VERY LONG BASE INTERFEROMETRY

Differential interferometry for spacecraft navigation page 55 NPO-18417

VIBRATION ISOLATORS

Six-degree-of-freedom magnetic vibration isolator page 75 MFS-26170

VISCOUS FLOW

Viscous/inviscid interaction on an oscillating airfoil page 71 ARC-12472

VOICE DATA PROCESSING

Voice-recognition system records inspection data page 50 MFS-29780

W

WAVE AMPLIFIERS

Improved grid-array millimeter-wave amplifier page 44 NPO-18548

WEAVING

More about the Farley three-dimensional braider page 78 LAR-14041

WELDING

Adjustable bracket for entry of welding wire page 80 MFS-29837

WHEELCHAIRS

Self-damping sprung wheel page 70 MFS-28632

WIRE

Adjustable bracket for entry of welding wire page 80 MFS-29837

X

X RAY ANALYSIS

X-ray and acoustic measurements yield stiffnesses page 28 LAR-14108

FORTRAN 90

Ordinarily you might have waited years before you were actually able to implement a new language standard - but not this time. You can discover all the rich new features of Fortran 90 using a fully tested, commercially available compiler. A compiler developed specifically to meet the new ANSI/ISO standard - the NAG Fortran 90 Compiler. NAG's twenty plus years of involvement in the Fortran community and close monitoring of the standards committee's activities has helped us develop a compiler which was ready to ship the same day the standard was formally adopted.

Twenty years ago when someone said Fortran, they meant Fortran 66. Ten years ago it was Fortran 77. For the nineties and beyond - it's Fortran 90. The NAG F90 compiler is supported on most UNIX workstations. License fees start at \$537 up to \$5200. Call NAG today to order your copy or obtain information. If you prefer, you can contact NAG electronically at:

litdesk@nag.com


NAG

Numerical Algorithms Group
1400 Opus Place, Suite 200
Downers Grove, IL 60515
(708) 971-2337
FAX: (708) 971-2706

For More Information Circle No. 528

It's NEW
for the 90's
and it's ANSI
Standard X3.198-1992

The Big Picture Just Got Bigger!



DADiSP

*The Standard Worldwide —
adopted by thousands of scientists and
engineers for data analysis and graphics.*

Just Point-and-Click...

DADiSP works the way you do — from input to output. DADiSP's point-and-click menus put *you* in control: from Data Collection, Reduction and Management, through Visual Data Analysis and Hypothesis Testing, on to final output with DADiSP's *outstanding* Presentation Quality Graphics.

DADiSP is currently in use in engineering, laboratory data collection, matrix processing, manufacturing, science, signal processing, chemical and mechanical applications in automotive, aerospace, defense, medical, and other industries.



CALL
1-800-777-5151

for your free DADiSP Trial Kit. DADiSP is available for SUN, HP, IBM, NeXT, DEC, Concurrent, and Silicon Graphics workstations, and of course, IBM PC compatibles.



One Kendall Square, Cambridge, MA 02139
617-577-1133, FAX: 617-577-8211

For More Information Circle No. 622

Australia & New Zealand-Interworld Electronics, (03) 563-7066; Austria-Norma Goerz Instruments GmbH, (02236) 6910; Belgium-Electronique-Mesures, (02) 384-7309; Denmark-Engberg, (042) 25-1777; Finland-Integra OY, (021) 557-547; France-SM2i, (01) 34-89-78-78; Germany-I.H.L. (0631) 99226; Ingenieurbüro Köhler, (069) 9765-000; PDV Systeme (0521) 80761; Hungary-Selectrade Computer, (01) 163-2905; India-Dynalog Microsystems, (022) 517-0514; Israel-Racom, (03) 491922; Italy-BPS Computers, (02) 660-14267; Japan-Astrodesign, (044) 751-1011; Korea-Echo Microsystems, (02) 704-5378; Netherlands-Peelk Instruments (010) 4152722; Portugal & Spain-Novatron, (04) 452-0811; Sweden-SYSTEC, (013) 11-01-40; Switzerland-Urech & Harr, (061) 61-13-25; Taiwan-Advantech, (02) 351-2117; Howching (02) 505-0525; U.K.-Adept Scientific, (0462) 480055